





MIDI POLYPHONIC SYNTHESIZER
SUPER JX

MKS-70

Owner's Manual



The Roland MKS-70 is fully programmable 12 voice polyphonic sound module that can cover up to 88 keys. To make the best use of it, please read the owner's manual thoroughly.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of un-insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

INSTRUCTIONS PERTAINING TO A RISK OF FIRE, ELECTRIC SHOCK OR INJURY TO PERSONS.

IMPORTANT SAFETY INSTRUCTIONS

WARNING When using electric products, basic precautions should always be followed, including the following:

1. Read all the instructions before using the product.
2. To reduce the risk of injury, close supervision is necessary when a product is used near children.
3. Do not use this product near water- for example, near a bathtub, washbowl, kitchen sink, in a wet basement, or near a swimming pool, or the like.
4. This product should be used only with a cart or stand that is recommended by the manufacture.
5. This product, either alone or in combination with an amplifier and headphones or speakers, may be capable of producing sound levels that could cause permanent hearing loss.
Do not operate for a long period of time at a high volume level or at level that is uncomfortable. If you experience any hearing loss or ringing in the ears, you should consult an audiologist.
6. The product should be located so that its location or position does not interfere with its proper ventilation.
7. The product should be located away from heat sources such as radiators, heat registers or other products that produce heat.
8. The product should avoid using in where it may be effected by dust.
9. The product should be connected to a power supply only of the type described in the operating instructions or as marked on the product.

10. The power-supply cord of the product should be unplugged from the outlet when left unused for a long time.
11. Do not tread on the power-supply cord.
12. Do not pull the cord but hold the plug when unplugging.
13. When setting up with any other instruments, the procedure should be followed in accordance with instruction manual.
14. Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.
15. The product should be serviced by qualified service personnel when:
 - A: The power-supply cord or the plug has been damaged; or
 - B: Objects have fallen, or liquid has been spilled into the product; or
 - C: The product has been exposed to rain; or
 - D: The product does not appear to operate normally or exhibits a marked change in performance; or
 - E: The product has been dropped, or the enclosure damaged.
16. Do not attempt to service the product beyond that described in the user-maintenance instructions. All other servicing should be referred to qualified service personnel.

SAVE THESE INSTRUCTIONS

Radio and television interference

*Warning - This equipment has been verified to comply with the limits for a Class B computing device, pursuant to Subpart J, of Part 15, of FCC rules. Operation with non-certified or non-verified equipment is likely to result in interference to radio and TV reception.

The equipment described in this manual generates and uses radio-frequency energy. If it is not installed and used properly, that is, in strict accordance with our instructions, it may cause interference with radio and television reception.

The equipment has been tested and found to comply with the limits for a Class B Computing device in accordance with the specifications in Subpart J, of Part 15, of FCC Rules. These limits are designed to provide reasonable protection against such an interference in a residential installation.

However, there is no guarantee that the interference will not occur in a particular installation. If the equipment does cause interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by the following measure:
 • Disconnect other devices and their interconnect cables at one time. If the interference stops, it is caused by either the other device or its I/O cable.

These devices usually require shielded programmed shielded I/O cables. For Roland devices, you can obtain the proper shielded cable from your dealer. For non-Roland devices, contact the manufacturer or dealer for assistance.

If your equipment does cause interference to radio or television reception, you can try to correct the interference by using one or more of the following measures:

• Turn the TV or radio antenna(s) and the interconnect cable(s) to one side or the other of the TV or radio.

• Move the equipment farther away from the TV or radio.
 • Plug the equipment into an outlet that is on a different circuit than the TV or radio. (This is, make certain the equipment and the radio or television are on circuits controlled by a 15-amp circuit breaker or fuse.)

• Consider installing a filtered interconnect shielded with coaxial cable leads between the interface and TV.

If necessary, you should consult your dealer or an experienced radio/television technician for additional suggestions. You may find helpful the following booklet prepared by the Federal Communications Commission:

"How to Identify and Resolve Radio-TV Interference Problems"

The booklet is available from the U.S. Government Printing Office, Washington, D.C. 20540, Stock No. DDA-200-002-46-4

Bescheinigung des Herstellers /Importeurs

Hiermit wird bescheinigt, daß der/die/das

ROLAND PROGRAMMABLE POLYPHONIC SYNTHESIZER MKS-70

(Gerät, Typ, Beschreibung)

in Übereinstimmung mit den Bestimmungen der

Amtsbl. Vfg 1046 / 1984

(Anstaltsverfügung)

funkt-entstört ist.

Der Deutschen Bundespost wurde das Inverkehrbringen dieses Gerätes angezeigt und die Berechtigung zur Überprüfung der Serie auf Einhaltung der Bestimmungen eingeräumt.

Roland Corporation Osaka / Japan

Name des Herstellers/Importeurs

Please read the separate volume "MIDI", before reading this owner's manual.

Copyright © 1986 by ROLAND CORPORATION

All rights reserved. No part of this publication may be reproduced in any form without the written permission of ROLAND CORPORATION.

SUPER JX

サウンド・チャート / Sound Chart



PATCH MAP

| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|---|---------------------------------|---------------------------------|----------------------------------|---------------------------------|----------------------------------|----------------------------------|--------------------------------|----------------------------------|
| A | ELECTRIC PIANO 1 | BACK and FORTH CHASE | VOICES | AFRICAN MALLETS | IS THIS FAT? | BREATHING BRASS | LOW STRINGS PAD | DCO WAWW 1 |
| | 83 PIANO 4 39 HARMO 1 | 49 BACK-SAW 41 SHORT SAW 1 | 11 VOICE HISS 10 VOICES A | 27 MARIMBA B 44 TICK 2 | 74 GOWESTBRS 2 74 GOWESTBAS 2 | 1 HORNZ 1 76 POLY BRASS | 88 STRINGS 1 56 LO STRINGS | 14 WAVEOLA 2 32 TABLE 1 |
| B | CHORUSED PIANO | METAL CHASE | EUPHONIUM CHOIR | METAL ON WOOD | OBESE FIFTHS | SLOW BRASS | ORCHESTRATED FLUTE | TIBETAN BELLS |
| | 52 E. GRANO 1 83 PIANO 4 | 20 E./PIANO A 77 GAMELANET | 90 CHOIR 1 HORNZ 1 | 92 MARIMBA 45 TICK 3 | 4 FAT FIFTH 46 TICK 4 | 7 S/BRASS B 6 S/BRASS A | 69 FLUTE 1 88 STRINGS 1 | 63 MISC BOX 64 WINDCHIMES |
| C | METALLIC E.PIANO 1 | SLAP BACK PAD | HOLLOW VOICES | STEEL DRUM BAND | POLY SYNTH | STAB BRASS:8VA | BOWED STRINGS | SYNTH BELLS |
| | 82 PERKEPIANO 43 RESO-TINK 6 | 51 PIANO 1 70 FRETNOT 1 | 100 GOWESTVOX 68 HOLLOW PAD | 62 DRYSTLDRUM 36 REELSTEEL 1 | 73 POLYSYNTH 2 76 POLY BRASS | 74 GOWESTBAS 2 75 GOWESTBAS 1 | 55 ARCO STRNG 55 ARCO STRNG | 94 SYNTHBELL 2 40 RESO-TINK 2 |
| D | JAZZ ORGAN | DANCING FLUTES | SUONDRACK | CELESTE | BIG DIGITAL | SAMPLE BRASS | REVERB STRINGS | HAND BELL CHOIR |
| | 58 BEE-THREE 38 ORGAN PEC | 69 FLUTE-1 69 FLUTE-1 | 56 LO STRINGS 67 SOUNDTRACK | 78 CELESTE 2 43 RESO-TINK 6 | 16 RASPWAVE 1 48 WAVE-TINK 3 | 11 VOICE HISS 3 MELLOW BRS | 9 R/STRING B 8 R/STRING A | 96 VIBES 39 HAROM 1 |
| E | ELECTRIC PIANO 2 | BACKWARDS PAN L>R. | CALIOPE | CLOCK VIBES | CATHEDRAL ORGA | HORN SECTION | CELLO-ORCHESTR | DCO WAVE 2 |
| | 29 TINES B 28 RHODES A | 49 BACK SAW 70 FRETNOT 1 | 33 BREATH 60 CALIOPE | 95 XMAS BELLS 43 RESO-TINK 6 | 61 PIPE ORGAN 61 PIPE ORGAN | 5 SAXOPHONES 2 HORNS 2 | 54 CELLO SECT 88 STRINGS 1 | 15 WAVEOLA 3 47 WAVE-TINK 2 |
| F | METALLIC E.PIANO 2 | SYNTH BASS/PAD | MELLOW PAD | STICK VIBES | TOUCH POLY SYNTH | WINDY FLUTE | SLOW HIGH STRINGS | DCO WAVE 3 |
| | 83 PIANO 4 79 AGOGO BELL | 12 PAD 1 66 SYNTH BASS | 3 MELLOW BRS 3 MELLOW BAS | 24 VIBE TINK 23 VIBISH A | 17 TOUCH POLY 17 TOUCH POLY | 33 BREATH 69 FLUTE 1 | 89 STRINGS 2 57 HI STRINGS | 14 WAVEOLA 2 50 TOYZ-TINK 1 |
| G | ROCK ORGAN | E.BASS/E.PIANO | SYNC PAD | BOTTLE MARIMBA | SYNTH SOLO | WOOD METALLET | SLOW HUGE STRINGS | DCO WAVE 4 |
| | 58 BEE-THREE 59 ORGAN 1 | 83 PIANO 4 65 E.BASS | 19 SYNC SOLO 1 19 SYNC SOLO 1 | 26 ATTACK 1 27 MARIMBA B | 18 SYNTHLEAD 1 18 SYNTHLEAD 1 | 37 LOG-DRAM A 26 ATTACK 1 | 89 STRINGS 2 57 HI STRINGS | 13 WAVEOLA 1 32 TABLE 1 |
| H | ACOUSTIC PIANO | SYNTH BASS/CLAV | STRING/HORN X-FADE | XYLOPHONE | SYNC:SOLO | MAY,S-PAD | STICK BELLS | HIGH TINEY PIANO |
| | 22 PIANO 1-B 21 PIANO 1-A | 30 FUNK CLAV 1 66 SYNTH BASS | 1 HORNZ 1 88 STRINGS 1 | 26 ATTACK 1 25 MARIMBA A | 19 SYNC SOLO 1 19 SYNC SOLO 1 | 91 MAY,S WIND 67 SOUNDTRACK | 35 STICKY 1 34 BELLS A | 53 PIANO 3 42 RESO-TINK 4 |

SUPER JX

PATCH MEMORY



| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|----------|--------------------|-------------------|--------------------|-----------------|------------------|-----------------|--------------------|------------------|
| A | ELECTRIC PIANO 1 | BACK/FORTH CHASE | VOICES | AFRICAN MALLET | IS THIS FAT ? | BREATHING BRASS | LOW STRINGS PAD | DCO WAVE 1 |
| B | CHORUSED PIANO | METAL CHASE | EUPHONIUM CHOIR | METAL ON WOOD | OBESSE FIFTHS | SLOW BRASS | ORCHESTRATED FLUTE | TIBETAN BELLS |
| C | METALLIC E.PIANO1 | SLAP BACK PAD | HOLLOW VOICE | STEEL DRUM BAND | POLY SYNTH | STAB BRASS 8VA | BOWED STRINGS | SYNTH BELLS |
| D | JAZZ ORGAN | DANCING FLUTES | SOUNDTRACK | CELESTE | BIG DIGITAL | SAMPLE BRASS | REVERB STRINGS | HAND BELL CHOIR |
| E | ELECTRIC PIANO 2 | BACKWARDS PAN L>R | CALIOPE | GLOCK VIBES | CATHEDRAL ORGAN | HORN SECTION | CELO ORCHESTRA | DCO WAVE 2 |
| F | METALLIC E.PIANO 2 | SYNTH BASS/PAD | MELLOW PAD | STICK VIBES | TOUCH POLY SYNTH | WINDY FLUTE | SLOW HIGH STRINGS | DCO WAVE 3 |
| G | ROCK ORGAN | E.BASS/E.PIANO | SYNC PAD | BOTTLE MARIMBA | SYNTH SOLO | WOOD METALLET | SLOW HUGE STRINGS | DCO WAVE 4 |
| H | ACOUSTIC PIANO | SYNTH BASS/CLAV | STRING/HORN X-FADE | XYLOPHONE | SYNC SOLO | MAY'S PAD | STICK BELLS | HIGH TINEY PIANO |

TONE MEMORY

| | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|------------|-------------|-------------|-------------|--------------|-------------|------------|--------------|-------------|--------------|-------------|
| 00 | | HORNS 1 | HORNS 2 | MELLOW BRS | FAT FIFTH | SAXPHONES | S/BRASS A | S/BRASS B | R/STRINGS A | R/STRINGS B |
| 10 | VOICES A | VOICE HISS | PAD 1 | WAVEOLA 1 | WAVEOLA 2 | WAVEOLA 3 | RASPWAVE 1 | TOUCH POLY | SYNTH LEAD 1 | SYNC SOLO 1 |
| 20 | E/PIANO A | PIANO 1-A | PIANO 1-B | VIBISH A | VIBE TINK | MARIMBA A | ATTACK 1 | MARIMBA B | RHODES A | TINES B |
| 30 | FUNK CLAV 1 | WAVE TINK 1 | TABLE 1 | BREATH | BELLS A | STICKY 1 | REEL STEEL 1 | LOG-DRUM A | ORGAN PERC | HARMO 1 |
| 40 | RESO-TINK 2 | SHORT SAW | RESO-TINK 4 | RESO-TINK 6 | TICK 2 | TICK 3 | TICK 4 | WAVE-TINK 2 | WAVE-TINK 3 | BACK SAW |
| 50 | TOYZ-TINK 1 | PIANO 1 | E-GRAND 1 | PIANO 3 | CELO/SECT | ARCO-STRNG | LO-STRINGS | HI-STRINGS | BEE-THREE | ORGAN 1 |
| 60 | CALIOPE | PIPE ORGAN | DRYSTLDRUM | MUSIC BOX | WINDCHIMES | E-BASS | SYNTH-BASS | SOUNDTRACK | HOLLOW PAD | FLUTE 1 |
| 70 | FRENOT 1 | BIG OL PAD | STABBRASS 2 | POLY-SYNTH 2 | GOWESTBRS | GOWESTBRS1 | POLY BRASS | GAMELANET | CELESTE 2 | AGOGO BELL |
| 80 | SYNDULCIMR | GUITARCLAV | PERKPIANO | PIANO 4 | SYNC LEAD | SEQ 1 | RECORDERS | BRIGHT BOW | STRINGS 1 | STRINGS 2 |
| 90 | CHOIR | MAY'S WIND | MARIMBA | METALLET | SYNTHBELL 2 | XMAS BELLS | VIBES | CHURCHBELL | RES BELL | KALIMBA 2 |
| 100 | GOWESTBOX | | | | | | | | | |

INT MEMORY

PRESET MEMORY

Parameter Table

| | | | |
|----|------------|----|------------|
| 11 | DCO-1 RANG | 21 | DCO-2 RANG |
| 12 | DCO-1 WF | 22 | DCO-2 WF |
| 13 | DCO-1 TUNE | 23 | DCO XMOD |
| 14 | DCO-1 LFO | 24 | DCO-2 TUNE |
| 15 | DCO-1 ENV | 25 | DCO-2 FTUN |
| | | 26 | DCO-2 LFO |
| | | 27 | DCO-2 ENV |

| | |
|----|----------|
| 31 | DCO DYNA |
| 32 | DCO MODE |

| | |
|----|-----------|
| 41 | MIX DCO-1 |
| 42 | MIX DCO-2 |
| 43 | MIX ENV |
| 44 | MIX DYNA |
| 45 | MIX MODE |

| | |
|----|----------|
| 51 | HPF FREQ |
| 52 | VCF FREQ |
| 53 | VCF RES |
| 54 | VCF LFO |
| 55 | VCF ENV |
| 56 | VCF KEY |
| 57 | VCF DYNA |
| 58 | VCF MODE |

| | |
|----|-----------|
| 61 | VCA LEVEL |
| 62 | VCA MODE |
| 63 | VCA DYNA |
| 64 | CHORUS |

| | |
|----|-----------|
| 71 | LFO WF |
| 72 | LFO DELAY |
| 73 | LFO RATE |

| | | | |
|----|------------|----|------------|
| 81 | ENV-1 ATT | 91 | ENV-2 ATT |
| 82 | ENV-1 DECY | 92 | ENV-2 DECY |
| 83 | ENV-1 SUS | 93 | ENV-2 SUS |
| 84 | ENV-1 REL | 94 | ENV-2 REL |
| 85 | ENV-1 KEY | 95 | ENV-2 KEY |

Patch Factor Table

| | |
|----|-------------------|
| 11 | A/B BALANCE |
| 12 | DUAL DETUNE |
| 13 | UPPER SPLIT POINT |
| 14 | LOWER SPLIT POINT |
| 15 | PORTAMENTO TIME |
| 16 | BEND RANGE |
| 17 | KEY MODE |
| 18 | TOTAL VOLUME |

| | |
|----|-----------------|
| 21 | AFTER TOUCH VIB |
| 22 | AFTER TOUCH BRI |
| 23 | AFTER TOUCH VOL |

MIDI Function Table

| | |
|----|-------------------|
| 11 | MODE |
| 12 | CONTROL CHANNEL |
| 13 | PATCH PROG CHANGE |
| 14 | SYSTEM EXCLUSIVE |

| | | | |
|----|---------------|----|---------------|
| 21 | CHANNEL A | 31 | CHANNEL B |
| 22 | A PROG CHANGE | 32 | B PROG CHANGE |
| 23 | A AFTER TOUCH | 33 | B AFTER TOUCH |
| 24 | A MIDI VOLUME | 34 | B MIDI VOLUME |




| | | | |
|----|-------------------|----|-------------------|
| 31 | A TONE NUMBER | 41 | B TONE NUMBER |
| 32 | A CHROMATIC SHIFT | 42 | B CHROMATIC SHIFT |
| 33 | A KEY ASSIGN | 43 | B KEY ASSIGN |
| 34 | A UNISON DETUNE | 44 | B UNISON DETUNE |
| 35 | A HOLD | 45 | B HOLD |
| 36 | A LFO MOD. DEPTH | 46 | B LFO MOD. DEPTH |
| 37 | A PORTAMENTO | 47 | B PORTAMENTO |
| 38 | A BENDER | 48 | B BENDER |

| | |
|----|-------------------|
| 51 | CHASE PLAY LEVEL |
| 52 | CHASE PLAY MODE |
| 53 | CHASE PLAY TIME |
| 54 | CHASE PLAY SWITCH |






MKS-70 Operation Table

Play Mode



Patches




Edit Mode




Tones

Master Tune

Write Mode




Copying




Panel Description

• Front Panel



• Rear Panel



FEATURES

- The MKS-70 features the memory capacity that can store up to 64 different programs (Patches) which are the combinations of sounds and performance control functions. Any of these Patches can be called instantaneously by pushing relevant buttons.
 - Provided with six Key Modes, the MKS-70 allows wide variety of performance effects.
 - The Chase Playing function makes it possible to output two sounds in slightly shifted timing.
 - The MIDI Mono Mode makes the MSK-70 useful for the Guitar Controller.
 - Using the Memory Cartridge, the memory capacity can be easily expanded.
 - The Alpha Dial serves to make the operation quicker.
 - Using the Programmer PG-800, you can synthesize sounds much easier and quicker.
 - The 32 figure Fluorescent Indicator Panel Display can be clearly seen even in dark place.
 - The five output jacks serve to create a huge stereo space.
-


IMPORTANT NOTES

- The appropriate power supply for this unit is shown on its name plate. Please make sure that the line voltage in your country meets the requirement.
- Please do not use the same socket used for any noise generating device (such as motor, variable lighting system).
- This unit might not work properly if turned on immediately after turned off. If this happens, simply turn it off and turn it on again a few seconds later.
- Before setting up this unit with other devices, turn this unit and all the other units off.
- This unit might be heated while operating, but there is no need to worry about it.
- Use a soft cloth and clean only with a mild detergent.
- Do not use solvents such as paint thinner.
- Avoid using this unit in excessive heat or humidity or where it may be affected by direct sunlight or dust.
- Operating this unit near a neon, fluorescent lamp, TV or CRT Display may cause noise interference. If so, change the angle or the position of the unit.
- The MKS-70 features memory back-up system that retains the data even when switched off. The battery that supports the back-up circuit should be replaced every five years. Call for the Roland service station for the battery replacement. (The first replacement may be required before five years, depending on how long it had passed before you purchased the unit.)
- Please make a memo of the data or save it onto cartridge before having the MKS-70 repaired. There is no way for restoring the lost data.

CONTENTS

| | |
|---|-----------|
| Panel Description | 3 |
| Important Notes | 4 |
| Connection | 6 |
| 1 Outline of the MKS-70 | 8 |
| 2 Operation | 10 |
| 1. MKS-70's Three Operation Modes | 10 |
| 2. Playing Mode | 11 |
| a. Setting MIDI Channel | 11 |
| b. Patch Selection | 13 |
| c. Key Mode | 14 |
| d. Quick Edit | 18 |
| e. Function Display | 20 |
| f. Tuning | 20 |
| 3. Editing Mode | 21 |
| a. Tone Editing | 21 |
| b. Patch Editing | 29 |
| c. Naming | 36 |
| d. Setting MIDI Functions | 37 |
| 4. Writing Mode | 40 |
| a. Writing a Tone | 42 |
| b. Writing a Patch | 42 |
| c. Writing MIDI Functions | 43 |
| d. Saving and Loading | 43 |
| 5. System Exclusive | 44 |
| 3 Error Messages | 46 |
| Specifications | 53 |

CONNECTION



- ① Connect the MIDI OUT connector on the transmitter to the MIDI IN connector on the MKS-70 using the supplied MIDI cable.
- ② Connect the Output Jack on the MKS-70 to the input jack on the amplifier using the supplied audio cable.

• **MIDI Connectors**

| | |
|------|---|
| IN | Connect the MIDI device that controls the MKS-70, such as MIDI Keyboard, MIDI Guitar Controller, computer, etc. |
| OUT | Through this connector, the Exclusive or Program Change message is sent out from the MKS-70. |
| THRU | Through this connector, the exact copy of the message fed into the MIDI IN is sent out. |

• **Output Jacks**

| Jack(s) used | Output |
|--------------|--|
| e | Monaural Output of the mixture of Tone A and Tone B |
| a d | Stereo Output of the mixture of Tone A and Tone B |
| b c | b: Monaural Output of Tone A c: Monaural Output of Tone B |
| a b | Stereo Output of Tone A |
| c d | Stereo Output of Tone B |
| a b c d | a b: Stereo Output of Tone A c d: Stereo Output of Tone B |

* When the Key Mode is set to WHOLE (see page 14), connecting an amplifier to b and c will cause unequal distribution of the sounds, but this is not because of the trouble of the unit.

• **Output Level Switch**

This switch serves to select the output level depending on the type of the amplifier connected to the Mix Output Jack.

* This switch has no effect on the Parallel Output Jack.

1 OUTLINE OF THE MKS-70

To make the best use of the MKS-70's functions, please read the following explanation, before going to "OPERATION".

The MKS-70 is a MIDI sound module which can be played by the MIDI messages sent from the external device on the set MIDI Channel.

■ MKS-70's Sound Structure

The MKS-70 has two sections: **Block A** and **Block B**. Each Block consists of six **Sound Modules**, and each **Sound Module** contains two DCO's, a VCF, a VCA and two Envelope Generators. So, you may consider each Block as a six voice polyphonic synthesizer.

Two different MIDI receive channels (**Channel A** and **Channel B**) are assigned to the corresponding Blocks.

■ MKS-70's Memory Structure

● Tone

The MKS-70 can retain 100 different sounds (**Tones**) from number 1 to 100 in each internal memory and memory cartridge. 50 Tones can be rewritten, other 50 Tones are non-volatile.

A Tone is assigned to each Block, and a Tone consists of various **Parameters**. Using the optional programmer PG-800, the parameters can be more easily edited.


● Patch



The MKS-70 can retain up to 64 different combinations of a Tone or Tones and various performance controlling functions in each internal memory and memory cartridge. This combination is called a **Patch**. In other words, a **Patch** consists of a Tone or a pair of Tones and performance controlling functions which we call **Factors** in this manual. Normally, to change sounds during live performance, select a different Patch.


● MIDI



The MKS-70 features several **MIDI Functions** which determine how the unit is played by the external controller. The setting of MIDI Functions can be stored in the internal memory or the memory cartridge.

MKS-70 Memory Structure



 : Select INTERNAL or CARTRIDGE by using 

 : Protect Switch OFF

 Calling
 Writing

2 OPERATION

1. MKS-70's Three Operation Modes

The MKS-70 has three operation modes: Playing Mode, Editing Mode and Writing Mode.

- **Playing Mode**

In the Playing mode, you can call a Patch you like and play it. This mode also allows to perform Quick Editing. (e.g. Tone selection, Key Mode selection, etc.)

- **Editing Mode**

The Editing mode allows to edit Patch Factors, Tone Parameters and MIDI Functions. In the Editing mode, you can name the Patch and Tone. Editing does not automatically rewrite the previous data unless taking an appropriate writing procedure. That is, the edited data will be erased when the unit is turned off.

- **Writing Mode**

The Writing mode allows to write the edited data into the internal memory or onto the memory cartridge.

2. Playing Mode

- ▶ Turn on the MKS-70, then MIDI transmit unit, then finally the amplifier.

When the MKS-70 is turned on, the Display responds with:

```
***** ROLAND MKS-70 *****
```

- * While the above indication is shown, the muting circuit is working, therefore no sound is obtained.

In several seconds later, the Display shows the basic Playing mode indication:

```

I - A1 ELECTRIC PIANO 1   39   83.
-----
a   b           c           d   e

```

The indication represents:

Ⓐ **Voice Memory Area**

I: MKS-70's internal memory
C: Memory Cartridge

Ⓑ **Patch Number**

A Patch is shown in the combination of an alphabet of A to H and a number of 1 to 8 such as A3, H1, etc.

Ⓒ **Patch Name**

Ⓓ **Tone Number of Tone B**

Ⓔ **Tone Number of Tone A**

This is the indication of a usual playing mode.

a. Setting MIDI Channel


The MKS-70 requires to set different MIDI channels (Channel A and B) for Tone A and Tone B.

How to set MIDI Channel


How to set MIDI channels on the MKS-70 differs depending on the type of MIDI device connected.

The following is an example for setting MIDI channel.


- **Controller featuring single MIDI Transmit Channel**
(e.g. Alpha JUNO, JX-8P, Roland Piano)



- **Controller featuring more than one MIDI Transmit Channel**
(e.g. MKB-1000·300·200, JX-10)



- **Controller featuring MIDI Mono Mode**
(GUITAR + GK-1 + GM-70)




Setting MIDI Channel A

- ① Push the MIDI Button.

The indicator on the MIDI Button lights up and the unit is in the MIDI Function editing mode.

- ② Push 1 then 2 of the Patch Memory/Number Buttons **7**.


"21" appears at the lined space of the Display. This is the MIDI Function number. The number shown at the far-right of Display is the MIDI Channel number.



- ③ Select the MIDI channel you want with the Alpha Dial.

Setting MIDI Channel B:

- ④ Push 3 then 1 of the Patch Memory/Number Buttons **7**.



- ⑤ Using the Alpha Dial, select the MIDI channel you want.

- ▶ The MIDI channel you set will be erased when the unit is turned off. If you wish to retain the channel setting, write it as explained on page 43 "Writing MIDI Functions".

When the MIDI signal is sent on the set channel, the MIDI Message Indicator flashes.

MIDI MESSAGE



Connection with MIDI Guitar Controller (Mono Mode)

The MKS-70 features the Mono Mode that is exclusively useful when used with a guitar controller. In the Mono mode, the MKS-70 receives signal from each string separately to each module. This gives the effect of creating the realistic guitar sound.

When the MKS-70 is set to the Mono mode, or the Mono mode command is received, the Mono Mode Indicator lights up.



When the Mono mode is selected, the channels are assigned to the strings as shown below.

| | |
|------------|------------|
| 1st string | ch (n) |
| 2nd string | ch (n + 1) |
| 3rd string | ch (n + 2) |
| 4th string | ch (n + 3) |
| 5th string | ch (n + 4) |
| 6th string | ch (n + 5) |

* n represents the MIDI channel number currently selected.

When "A WHOLE" Key Mode is selected, or "B WHOLE" Patch is in use, the channels up to n + 11 are available.

The strings of the channel number higher than 17 ch will be ignored.

- ▶ When the MKS-70 receives the command to select a certain channel number, it has the priority.

The set of channel numbers assigned to the six strings in the Channel A is called **Channel Group A**, and that of the Channel B is **Channel Group B**.

How to turn to the Mono Mode

- ① Push the MIDI Button.
- ② Push 1 of the Patch Memory/Number Buttons twice ⑦.
- ③ Rotate the Alpha Dial until the following indication appears in the Display.



The MIDI Mono Mode Indicator lights up.



*** The MKS-70's Mono mode does not allow to set a different sound for each note separately, because each channel is not perfectly independent.**

b. Patch Selection

During live performance, you may usually set the MKS-70 to the Playing mode and select a patch in the internal memory or in the cartridge.

How to change Patches


- ① By pushing the CART Button, select whether to use the Patch in the internal memory or the memory cartridge.



Here, the previous Patch still remains.

- ② Assign the Patch you like by pushing the appropriate Patch Memory Buttons.

Now, the new patch is called ready to be used.



As the Display shows, the cartridge memory is not selected yet.



c. Key Mode

1) MKS-70's Six Key Modes

The **Key Mode** decides how to assign the two sound blocks.


- **Dual (DUAL)**

The Dual Mode turns the MKS-70 to the six voice polyphonic that allows both the Tone A and Tone B to sound simultaneously. Each Tone can be separately taken through the Parallel Outputs giving the effect as if two sets of synthesizers are simultaneously played.

- **Touch Voice Select (T. VOICE)**


In this mode, either the Tone A or Tone B will sound depending how you play the keyboard. That is, when you play the keyboard harder than the set level (threshold level), the Tone A is selected and when you play softer than the set level, the Tone B sounds. In other words, when the level is set higher, stronger key pressure is needed to obtain Tone A. Naturally, within the set level, dynamics can be obtained.

The threshold level is where the Upper Split Point (on page 30) is set. So, to change the threshold level, move the Upper Split Point.



- **Corss Fade (X-FADE)**

This mode is a kind of Dual. As shown in the picture, the volume of the Tone A decreases by stronger key touch, and the volume of the Tone B decreases by weaker key touch. This mode, therefore, can be effectively used to change the volume balance of the Tones by changing the playing manners. You cannot obtain this effect if using the Tones whose dynamics are all turned off.



- **A whole (A WHOLE)**

In the A Whole mode, both of the two sound blocks will have the Tone A in 12 voice polyphonic.

- **B Whole (B WHOLE)**

In the B Whole mode, both of the two sound blocks will have the Tone B in 12 voice polyphonic.

● **Split (SPLIT)**

There are two kinds of Split modes depending on whether the Channels A and B are set to the same MIDI channel number or to different numbers.

SPLIT I : The Channels A and B are set to the same MIDI channel number.

The MKS-70's Split system allows to set the lowest Key Number with "Upper Split Point" (see page 30 "Split Point"), and the highest Key Number with "Lower Split Point". The Tone A will sound when the signal higher than the lowest Key Number you set is received, and the Tone B will sound when the signal lower than the highest Key Number set is received.


Split I mode is effective when the MKS-70 is used with a MIDI controller that features a single MIDI channel. Here, set the MIDI channel of the MKS-70's Channels A and B to the same number as the controller.

SPLIT II: The Channels A and B are set to different MIDI channel numbers.


The key information sent on the channel A will sound the Tone A, and that sent on the channel B will sound the Tone B.

The Split II mode is effective when the MKS-70 is used with the MIDI controller that features more than one channel number.

Example)



Example)




2) Key Mode and the Receive MIDI Channel

Table-1


| KEY MODE | TONE | RECEIVE CHANNEL | |
|----------------------------|------------------------|-----------------|-----------------|
| | | MIDI POLY MODE | MIDI MONO MODE |
| DUAL T. VOICE X-FADE | TONE A TONE B | CHANNEL A | CHANNEL GROUP A |
| | | (CHANNEL B)* | (CHANNEL B)* |
| A WHOLE | TONE A | CHANNEL A | CHANNEL GROUP A |
| B WHOLE | TONE B | CHANNEL B | CHANNEL GROUP B |
| SPLIT | I TONE A TONE B | CHANNEL A | CHANNEL GROUP A |
| | | CHANNEL GROUP B | CHANNEL GROUP B |
| | II TONE A TONE B | CHANNEL A | CHANNEL GROUP A |
| | | CHANNEL B | CHANNEL GROUP B |

*On the Channel B, only Program Change messages are received.


<DUAL> <T. VOICE> <X-FADE>
POLY MODE




<A WHOLE>
POLY MODE



MONO MODE




MONO MODE




*The dotted lines represent Program Change Message


<B WHOLE>
POLY MODE




<POLY MODE>
POLY MODE



MONO MODE



MONO MODE



d. Quick Edit

The following three Factors can be edited even during live performance just by touching the relevant buttons without turning to the Edit mode. This is called **Quick Edit** mode.

- { Key Mode Selection
- { Tone Number Selection
- { Chase Playing On/Off

► The edited data, however, does not remain in memory unless you take the appropriate writing procedure explained on page 41.

1) Key Mode Selection


① Push the SHIFT Button.

The corresponding indicator lights up, and the Patch Memory Buttons A to F now work for selecting a Key Mode.



② Push the relevant button to select the Key Mode you want.

The buttons correspond to the Key Modes as follows:



The Display shows the selected Key Mode.



In about two seconds, the Display returns to the usual Playing mode indication.

③ Push the SHIFT Button.


The indicator goes out.

2) Tone Number Selection

Make sure that the MKS-70 is in the Playing mode.

- ① Push ► or ◀ button to select the Tone A or B.

The digit moves to the lower left to the Tone Number which is to be changed.




- ② Push the SHIFT Button.

The indicator on the Shift Button lights up and the Patch memory Buttons 0 to 9 now work for selecting a Tone Number.



- ③ By pushing the relevant buttons, select the Tone Number you want.

- ④ Push the ENTER Button.



- ⑤ Push the SHIFT Button.


The indicator goes out.

3) Chase Playing

The Chase Playing function makes it possible to play one of the two Tones slightly later than the other Tone or repeat playing.

- Pushing the Chase Button turns the Chase Playing function on or off.

When the Patch Factor "54 CHASE PLAY" (see page 54) of the selected Patch is set to OFF, pushing the Chase Play Button will turn the Chase Playing function on (the indicator lights up). On the contrary, when it is set to ON, pushing the same button will turn the effect off (the indicator goes out).



- How to set the sequence of the Tones or the delay time of the two Tones is explained on page 34 "Patch Editing".

e. Function Display

In the Playing mode, the Display of the MKS-70 can show the following three data.

MIDI Channel

The numbers of the MIDI Channels A and/or B and Control Channels are shown.

```
MIDI CH B *** A *** CNT ***
```

Tone Name

The Tone names used in the Patch currently selected are shown.

```
*****  
Tone B           Tone A
```

Key Mode

The Key Mode set in the Patch currently in use are shown.

When the Split I mode (page 15) is selected, the set Split Point is shown.

```
SPLIT           LO-*** UP-***
```

► Pushing the PARAM Button will call the above indication sequentially.

f. Tuning

① Push the TUNE Button.

```
MASTER TUNE           A=           Hz
```

② Rotating the Alpha Dial, tune the MKS-70 to the connected instrument.

* The pitch is shown in the Display from A = 437 to 446Hz in 1Hz step, but actually changes much more finely.

► You can change the pitch by using the Patch Memory/Number Button, setting only the lowest figure of the value.

③ Set the Protect Switch on the MKS-70 to the OFF position, then push the WRITE Button.

```
WRITE TUNE
```

④ Push the ENTER Button.

The Display responds with as below, showing that the tuning is completed.






```
WRITTEN TUNE
```

⑤ Return the Protect Switch to the ON position.

3. Editing Mode

The Editing mode allows you to recall and edit the data written in the internal memory or on the memory cartridge.

Pushing the EDIT Button (PATCH, TONE or MIDI) will light up the corresponding indicator, and the Display shows the name of the Patch Factor, Tone Parameter or MIDI Function and the value. This is the Edit mode.



Pushing the same Edit Button will return the unit to the Playing mode.

- ▶ Edited data does not remain in memory unless taking the appropriate Writing procedure explain on page 41. The edited Patch or Tone is erased when a different Patch or Tone, and the MIDI Factor is erased when the unit is switched off.

a. Tone Editing

A Tone consists of various Tone Parameters, so, a Tone can be edited by changing the values or settings of the parameters.

There are two methods of Tone Editing:

- (1) Call the Patch to be edited and while actually listening to the sound, edit the Tone A and B of which the Patch consists.

You can select the Tone A or B by using the ► and ◀ buttons.










- (2) Call a Tone A or B and edit a single Tone while listening to the sound.





Call the Tone to be edited in the Key Mode of either A Whole or B Whole. Even in other mode, you can edit a Tone by turning down the volume of the other Tone (See page 29).

PARAMETER TABLE

DCO (Digitally Controlled Oscillator)


DCO is the digitally controlled oscillator that controls the pitch and generates the waveforms that are the sound source of the synthesizers. Owing to its digital control system, this offers superior pitch stability compared to the VCO (Voltage Controlled Oscillator). the MKS-70 has 2 DCO's.

| Parameter | | Data Value | Function | Programmer | |
|-----------|----------------------|------------|---|---|--|
| Number | Display | | | | |
| 11 | DCO1 RANG | 2' | This is to change the pitch range of the DCO in exact one octave steps from 2' to 16' (2', 4', 8', 16'). 8' is standard. |  | |
| | DCO-1 Range | 4' | | | |
| 21 | DCO2 RANG | 8' | | | |
| | DCO-2 Range | 16' | | | |
| 12 | DCO1 WF | SAWT | This is to choose the output waveform of the DCO. SAWT:  (Saw Tooth) PULS:  (Pulse Wave) SQUR:  (Square Wave) NOIS:  (Noise) |  | |
| | DCO-1 Waveform | PULS | | | |
| 22 | DCO2 WF | SQUR | | | |
| | DCO-2 Waveform | NOIS | | | |
| 13 | DCO1 TUNE | + 12 | This changes the frequency (pitch) of the DCO, in semi-tone steps. •Variable Range: ± 12 (±1 Octave) |  | |
| | DCO-1 Tune | 00 | | | |
| 24 | DCO2 TUNE | 00 | | | |
| | DCO-2 Tune | - 12 | | | |
| 14 | DCO1 LFO | | When the LFO output is modulating the DCO, this parameter is used to adjust the depth of the modulation. For vibrato effect, select "SINE" with the LFO Waveform. |  | |
| | DCO-1 LFO Depth | | | | |
| 26 | DCO2 LFO | 99 | | | |
| | DCO-2 LFO Depth | | | | |
| 15 | DCO1 ENV | 00 | When the ENV output is modulating the DCO, this parameter is used to adjust the depth of the modulation. |  | |
| | DCO-1 Envelope Depth | | | | |
| 27 | DCO2 ENV | | | | |
| | DCO-2 Envelope Depth | | | | |

| Parameter | | Data Value | Function | Programmer |
|-----------|--------------------|------------|---|---|
| Number | Display | | | |
| 23 | DCO XMOD | XMOD | <ul style="list-style-type: none"> • X MOD: DCO-1 and DCO-2 affect each other, pitch, harmonic contents and waveform. • SNC 2: Both SYNC 1 and X MOD work together. • SNC 1: The pitch is determined by DCO-1, and the harmonic contents by DCO-2. The waveform is determined by the DCO-2's synchronization to DCO-1. • OFF: Each DCO-1 and DCO-2 can have different pitch and waveform. |  |
| | Cross Modulation | SNC 2 | | |
| | | SNC 1 | | |
| | | OFF | | |
| 25 | DCO2 FTUN | +50 | The frequency (pitch) of the DCO-2 can be adjusted with this parameter. • Variable range... ± 50 cent |  |
| | DCO-2 Fine Tune | -50 | | |
| 31 | DCO DYNA | 3 | When the DCO's pitch is controlled by the ENV, and the amount of the ENV is controlled by Dynamics (Key Touch), this parameter adjusts the sensitivity of Key Touch. (Note 1) |  |
| | DCO Dynamics Range | 2 | | |
| | | 1 | | |
| | | OFF | | |
| 32 | DCO MODE | 0-1 | This selects the polarity of the Envelope curve. Normally, \wedge is used. In \vee mode, ADSR pattern will be all inverted. |  |
| | DCO Envelope Mode | 0-1 | | |
| | | 0-2 | | |
| | | 0-2 | | |


Note 1

Depending on the position of the Dynamics Range Selector, the tone color alteration differs as shown below.



Note 2

Envelope Key Follow






OFF: All Keys have the same Envelope time.

- ①: The highest Key A has the ENV time exactly half length of the lowest Key D's.
- ②: The Key B has the ENV time exactly half length of the lowest Key D's.
- ③: The Key C has the ENV time exactly half length of the lowest Key D's.



MIXER




This is where the volume balance of the DCO-1 and DCO-2 is controlled.

| Parameter | | Data Value | Function | Programmer | |
|-----------|----------------------|--------------------|--|---|---------------|
| Number | Display | | | | |
| 41 | MIX DCO1 | 99 | This adjusts the level of DCO-1. |  | |
| | DCO-1 Level | | | | |
| 42 | MIX DCO2 |) | This adjusts the level of DCO-2. | | |
| | DCO-2 Level | | | | |
| 43 | MIX ENV | 00 | When ENV controls the DCO-2's level, this sets the amount of ENV signal. | | |
| | DCO-2 Envelope Depth | | | | |
| 44 | MIX DYNA | 3 2 1 OFF | When the DCO-2's level is controlled by ENV Depth and then by Dynamics, this sets the sensitivity of the Key Touch. [NOTE 1] |  | |
| | DCO-2 Dynamics Range | | | | |
| 45 | MIX MODE | 0-1 | Normally, ^ is used, and in v mode, ADSR pattern will be inverted. |  | |
| | DCO-2 Envelope Mode | 0-1 | | | 0-1 : ENV 1 ^ |
| | | 0-2 | | | 0-1 : ENV 1 v |
| | | 0-2 | | | 0-2 : ENV 2 ^ |
| | | 0-2 | 0-2 : ENV 2 v | | |

VCF (Voltage Controlled Filter)


The output signal goes to the Mixer then to the VCF to be filtered. Each VCF lets lower frequency harmonics pass and cuts off the higher ones. In other words, it is a usual low pass filter. By controlling the cutoff point and resonance, the waveform changes, thereby the tone color alters.






| Parameter | | Data Value | Function | Programmer |
|-----------|-----------------------------------|------------------|--|---|
| Number | Display | | | |
| 51 | HPF FREQ | 3 2 1 0 | The HPF (High-Pass Filter) is a filter that passes higher frequency harmonics and cuts off the lower ones. As you increase the value, cutoff point goes up, lower frequency harmonics being cut off. |  |
| | High-pass Filter Cutoff Frequency | | | |
| 52 | VCF FREQ | 99) 00 | This is for changing the cutoff point of the VCF. As you decrease the value, cutoff frequency will come down, and the waveform gradually becomes approximation of a sine wave, then the sound will fade out. |  |
| | Cutoff Frequency | | | |

| Parameter | | Data Value | Function | Programmer |
|-----------|----------------|---------------|---|---|
| Number | Display | | | |
| 53 | VCF RES | 99) 00 | <p>This emphasizes the cutoff point. As you increase the value, the created sound will become more unusual, more electronic in nature.</p> <p>This controls the cutoff point by the waveform selected at the LFO section. Increasing the value deepens the modulation.</p> <p>This controls the cutoff point of the VCF in each note with the ENV curve set in the ENV section. As you increase the value, tone color within one note changes more drastically.</p> <p>This can shift the cutoff point by key position (pitch). At 100%, it prevents any inconsistency in the harmonic contents caused by pitch alteration.</p> <p>Parameter value 83 (=Programmer's Knob''8'')= 100%</p> |  |
| | Resonance | | | |
| 54 | VCF LFO | | | |
| | LFO Depth | | | |
| 55 | VCF ENV | | | |
| | Envelope Depth | | | |
| 56 | VCF KEY | 00 | <p>This can shift the cutoff point by key position (pitch). At 100%, it prevents any inconsistency in the harmonic contents caused by pitch alteration.</p> <p>Parameter value 83 (=Programmer's Knob''8'')= 100%</p> | |
| | Key Follow | | | |
| 57 | VCF DYNA | 3 | <p>When the VCF is controlled by ENV and Key Touch (Dynamics), this parameter determines the sensitivity of the Key Touch. (Note 1)</p> |  |
| | Dynamics Range | 2 | | |
| | | 1 | | |
| | | OFF | | |
| 58 | VCF MODE | 0-1 | <p>This is to select the polarity of the Envelope curve that controls VCF. Usually ^ may be used. In v mode, ADSR pattern will be inverted.</p> <p>0-1: ENV1 ^ 0-1: ENV1 v 0-2: ENV2 ^ 0-2: ENV2 v</p> |  |
| | Envelope Mode | 0-1 | | |
| | | 0-2 | | |
| | | 0-2 | | |

VCA (Voltage Controlled Amplifier)/
Chorus





After filtered in the VCF, the signal is fed to the VCA where the volume (amplitude) of the sound is controlled.

| Parameter | | Data Value | Function | Programmer |
|-----------|-----------|------------|--|---|
| Number | Display | | | |
| 61 | VCA LEVEL | 99 | <p>This is to adjust the volume level, and can be effectively used in the writing mode. If it is set too high, sound may be distorted.</p> |  |
| | VCA Level |) | | |
| | | 00 | | |

| Parameter | | Data Value | Function | Programmer |
|-----------|--------------------|------------|--|---|
| Number | Display | | | |
| 62 | VCA MODE | ENV2 | This is to select whether to control the VCA by the signal from the ENV-2 () or by the Gate signal (). |  |
| | VCA Mode | GATE | | |
| 63 | VCA DYNA | 3 | This parameter determines the sensitivity of the Key Touch (Dynamics effect). (Note 1) |  |
| | VCA Dynamics Range | 2 | | |
| | | 1 | | |
| | | OFF | | |
| 64 | CHORUS | 2 | 2: Rich Chorus effect is obtained. 1: Expansive Chorus effect is obtained. OFF: Chorus is off |  |
| | Chorus Mode | 1 | | |
| | | OFF | | |






LFO (Low Frequency Oscillator)

This oscillator generates extremely low frequency, so produces a vibrato or growl effect by controlling the DCO or VCF.

| Parameter | | Data Value | Function | Programmer |
|-----------|--------------|------------|---|---|
| Number | Display | | | |
| 71 | LFO WF | SINE | This is for selecting the LFO output waveform. SINE:  (Sine Wave) SQR:  (Square Wave) RAND: Random |  |
| | LFO Waveform | SQR | | |
| | | RAND | | |
| 72 | LFO DELAY | 99 | This sets the time needed for the modulation by the LFO to start. |  |
| | Delay Time | 00 | | |
| 73 | LFO RATE | 99 | This sets the rate (frequency) of the LFO. | |
| | Rate | 00 | | |

ENV (Envelope Generator)


This generates the control voltage (Envelope) which controls the DCO, VCF and VCA, therefore, alters the pitch, tone color and volume in each note.

| Parameter | | Data Value | Function | Programmer |
|-----------|---------------------|------------|--|---|
| Number | Display | | | |
| 81 | ENV 1 ATT | | This determines the time required for the voltage to reach its maximum from the moment the key is played. |  |
| | ENV-1 Attack Time | | | |
| 91 | ENV 2 ATT | | | |
| | ENV- Attack Time | | | |
| 82 | ENV 1 DECAY | 99 | This determines the time required for the voltage to drop from the maximum to the sustain level. |  |
| | ENV-1 Decay Time | | | |
| 92 | ENV 2 DECAY |) | | |
| | ENV-2 Decay Time | | | |
| 83 | ENV 1 SUS | 00 | This sets the sustain level to which the voltage falls at the end of the decay time. Therefore, at its maximum setting, Decay Time Knob has no effect. |  |
| | ENV-1 Sustain Level | | | |
| 93 | ENV 2 SUS | | | |
| | ENV-2 Sustain Level | | | |
| 84 | ENV 1 REL | | This sets the time needed for the voltage to reach zero from the moment the key is released. |  |
| | ENV-1 Release Time | | | |
| 94 | ENV 2 REL | | | |
| | ENV-2 Release Time | | | |
| 85 | ENV 1 KEY | 3 | This changes the time required for an ENV curve to complete its curve (= ENV time). At OFF, all the pitches have the same ENV time. As the value is increased, higher keys have shorter ENV time. (Note 2) |  |
| | ENV-1 Key Follow | 2 | | |
| 95 | ENV 2 KEY | 1 | | |
| | ENV-2 Key Follow | OFF | | |


Tone editing can be done quicker and easier by using the optional programmer PG-800, but even without it, it can be done by calling each parameter by assigning the relevant parameter number and changing the value.

1) Editing without using the programmer

- ① Push the TONE of the Edit Buttons.
- ② By pushing the relevant buttons of the Patch Memory/Number Buttons **7**, assign the number of the parameter to be edited.



- ③ While actually listening to the sound, change the value of the parameter.




- ④ To continue to edit other parameters, repeat the steps ② and ③ as many times.
- ▶ **To call parameter, you can use the Alpha Dial instead of the Number Buttons **7**. Push the TONE then the PARAM Buttons, and rotate the Alpha Dial until the parameter you want is shown in the Display. Then push the VALUE of the Edit Buttons and change the value with the Alpha Dial.**
- ⑤ When editing is completed, push the TONE Button to return to the Playing mode.

2) Editing with the programmer PG-800

Editing will be much easier by using the programmer PG-800.

- ① As shown below, set up the programmer and the MKS-70 using the 6P DIN cable supplied with the PG-800.



- ② By moving the control knobs and switches on the programmer's panel, edit the Tone to your taste.

Here, you can turn the MKS-70 to the Editing mode by pushing the TONE Button, so that the Display shows the name and the value of the parameter currently in use.

When the switch or button on the programmer is even slightly moved, the value of the relevant parameter is changed. In other words, the value of the parameter remains intact if the relevant switch or the button is not moved at all.

The MKS-70 features Manual mode in which the whole panel setting on the programmer decides the Tone. That is, existing Tone written in memory has nothing to do with your sound synthesis. To turn the MKS-70 to the Manual mode, simply push the Manual Button on the programmer.

* The programmer does not work when the MKS-70 is set to the Writing mode or Bulk Damp mode (see page 45).

- ▶ If the Write Button on the programmer is accidentally pushed during Tone editing, the edited Tone will automatically rewrite the Tone previously written. To avoid this, be sure to set the Protect Switch on the MKS-70 to the PROTECT position (see page 40).

3) Recalling a Tone

"Recalling a Tone" is the function which can be used during Tone editing. While you are editing a Tone, you may want to call the original Tone which is intact, to probably compare it with the one you have edited.

PROCEDURE

- ① Push the ▶ button if editing the Tone A and push ◀ button if editing the Tone B, and the original Tone will be called.

```
*****  RECALL  *****
```

- ② Push the same button pushed in the step ① to return to the edited Tone.

* Naturally, the recalled Tone cannot be edited.

b. Patch Editing

1) Patch Factors

• Tone

```
1-A1 31  A TONE NUMBER  ***
41  B TONE NUMBER  ***
1-100
```

These Factors set the Tone Numbers of Tones A and B.

* The Tone Factor includes the Tone Number, but it does not include the contents (parameters) of the Tone.

```
11  A/B BALANCE  **
00-99
```

This Factor determines the volume balance of the Tone A and the Tone B. When the value is set around 50, the volumes of the both Tones are the highest, and as the value increases, the Tone B's volume decreases, the Tone A's volume remaining the highest. That is, when the value in the Display is 99, only the Tone A will be heard. When the value is smaller than 50, the opposite effect will be obtained.

```
32  A CHROMATIC SHIFT  ***
42  B CHROMATIC SHIFT  .***
-24-00-+24
```

These Factors can shift the pitches of the Tone A and Tone B separately in semi-tone steps in the range of 4 octaves; 2 octaves upper and lower. If the key exceeding A0 to C8 is played, it will be substituted by the highest or the lowest octave within the range.

● Key Mode

| | | |
|----|----------|-------|
| 17 | KEY MODE | ***** |
|----|----------|-------|

 DUAL
 T-VOICE
 X-FADE
 A WHOLE
 B WHOLE
 SPLIT

► See page 14.

| | | |
|----|-------------|-----|
| 12 | DUAL DETUNE | *** |
|----|-------------|-----|

 -50-00-+50

When the Key Mode is set to Dual, this Factor can detune the Tone B from the Tone A. At "+" value, the Tone B's pitch is raised and at "-" value, it is lowered.

● Split Point

| | | |
|----|-------------------|-----|
| 13 | UPPER SPLIT POINT | *** |
|----|-------------------|-----|

| | | |
|----|-------------------|-----|
| 14 | LOWER SPLIT POINT | *** |
|----|-------------------|-----|

 A0-C8

These Factors are the Upper Split Point and the Lower Split Point in the Split I mode (see page 15).

The Upper Split Point sets the lowest key number, and the Lower Split Point sets the highest key number. The signal higher than the Upper Split Point will play the Tone A and the signal lower than the Lower Split Point will play the Tone B. The value is shown with the octave and the note name; the lowest note is A0 and the highest note is C8 and the middle C is C4. ("+" indication represents #.)

► The Split Point can also be set by sending the Key On message from the connected MIDI controller, as well as using the Alpha Dial on the MKS-70. Call the relevant Factor, then play the appropriate key on the keyboard while holding down the C button of the Patch Memory Buttons ⑦.

● Key Assign

The MKS-70 has six modules for the Tone A and another six for the Tone B, altogether twelve modules. The following Factors determine how to assign these modules to the keys played.

In the MIDI Mono mode, these Factors are irrelevant.

| | | |
|----|--------------|-------|
| 33 | A KEY ASSIGN | ***** |
| 43 | B KEY ASSIGN | ***** |

POLY 1
POLY 2
UNISON 1
UNISON 2
MONO 1
MONO 2

POLY 1

This mode turns the MKS-70 to six voice polyphonic, assigning one module to each key pressed. This mode is ideal for the sound whose envelope curve is similar to the piano's or guitar's, therefore should be selected for usual performance.

POLY 2

This mode is very similar to Poly 1, assigning only one module to each key played. However, the same module as assigned to the key previously played is assigned to the note played later. So, this mode is ideal for the performance with portamento effect.

UNISON 1

In this mode, two sound modules are assigned to each key, therefore the created sound is richer than Poly mode. That is, each of the Tones A and B becomes three voice polyphonic.

UNISON 2

This is similar to the Unison 1 mode, but one of the two modules is one octave lower than the other, therefore creating even fatter sound than Unison 1.

MONO 1

This mode turns each of the Tones A and B to a single voice synthesizer that assigns one module to each key. When more than one key is played at a time, the last key has priority.

MONO 2

This mode turns each of the Tones A and B to the monophonic synthesizer that assigns all six modules to one key pressed. When more than one key is played at a time, the last key has priority.

Key Modes and Key Assign Modes

<DUAL>

→ Each of Tone A and Tone B is played in the individual Key Assign mode.

<TOUCH VOICE SELECT>

→ The Key Assign set with "43 B KEY ASSIGN" is ignored, and both of Tones A and B are played in the Key Assign mode set with "33 A KEY ASSIGN".

<CROSS FADE>

→ The Key Assign set with "43 B KEY ASSIGN" is ignored, and both of Tones A and B are played in the Key Assign mode set with "33 A KEY ASSIGN".

<A WHOLE>

→ The Key Assign set with "33 A KEY ASSIGN" is ignored, and both of Tones A and B are played in the Poly 1 Key Assign mode when the "37 A PORTAMENT" is set to OFF, and played in Poly 2 mode when the Portamento is ON.

<B WHOLE>

→ The Key Assign set with "43 B KEY ASSIGN" is ignored, and both Tones are played in Poly 1 mode when "47 B PORTAMENTO" is OFF, and played in Poly 2 when the Portamento is ON.

<SPLIT>

→ Each of Tones A and B is played in the individual Key Assign.

| | | |
|----|-----------------|-----|
| 34 | A UNISON DETUNE | *** |
|----|-----------------|-----|

| | | |
|----|-----------------|-----|
| 44 | B UNISON DETUNE | *** |
|----|-----------------|-----|

—50-00-+50

When the Key Assign is UNISON 1 or UNISON 2, this Factor can detune one of the two modules. "+" raises the pitch and "-" lowers.

• Total Volume

| | | |
|----|--------------|----|
| 18 | TOTAL VOLUME | ** |
|----|--------------|----|

—00-99

This Factor allows to set an individual volume of each Patch. This is useful to reduce the volume difference between the Patches.

• Aftertouch

Aftertouch is the change caused by playing the key harder after a usual manner. The MSK-70 features three Aftertouch effects, vibrato, brilliance and volume. The sensitivity of each Aftertouch can be set here. All the three Aftertouch effects can be obtained at a time, if you like.

| | | |
|----|-----------------|----|
| 21 | AFTER TOUCH VIB | ** |
|----|-----------------|----|

—00-99

Aftertouch causes the vibrato effect. At 00, no effect is obtained, and increasing the value deepens the effect.

| | | |
|----|-----------------|----|
| 22 | AFTER TOUCH BRI | ** |
|----|-----------------|----|

—00-99

Aftertouch causes the brilliance effect. At 00, no effect is obtained, and increasing the value deepens the effect.

| | | |
|----|-----------------|----|
| 23 | AFTER TOUCH VOL | ** |
|----|-----------------|----|

—00-99

Aftertouch causes volume alteration. At 00, no effect is obtained, and increasing the value deepens the effect.

● **Hold**

| | | | |
|----|---|------|-----|
| 35 | A | HOLD | *** |
| 45 | B | HOLD | *** |

ON
OFF

When the MKS-70 is receiving the Hold message from the MIDI IN, these Factors can turn on or off the Hold effect separately for the Tone A and Tone B.

● **Modulation**

| | | | |
|----|---|---------------|----|
| 36 | A | LFO MOD DEPTH | ** |
| 46 | B | LFO MOD DEPTH | ** |

00-99

When the MKS-70 is receiving Modulation message from the MIDI IN, these Factors can set the depth of the Vibrato effect separately for the Tone A and Tone B. At 00, no effect is obtained, and increasing the value deepens the effect.

● **Portamento**

| | | | |
|----|---|------------|-----|
| 37 | A | PORTAMENTO | *** |
| 47 | B | PORTAMENTO | *** |

ON
OFF

When the MKS-70 is receiving Portamento message from the MIDI IN, these Factors can turn on or off the Portamento effects separately for the Tone A and Tone B.

| | | |
|----|-----------------|-----|
| 15 | PORTAMENTO TIME | *** |
|----|-----------------|-----|

00-99

This Factor controls the portamento time. Higher value is longer portamento time.

● **Bender**

| | | | |
|----|---|--------|-----|
| 38 | A | BENDER | *** |
| 48 | B | BENDER | *** |

ON
OFF

When the MKS-70 is receiving Bender message from the MIDI IN, these Factors can turn on or off the Bender functions separately for the Tone A and Tone B.

16 BEND RANGE **

2-3-4-7-12

• Bender Range

When the MKS-70 is receiving Bender message from the MIDI IN, this Factor sets the maximum effect of the Bender. The value represents semitone; 2 is the major 2nd 3 is the minor 3rd, 4 is the major 3rd, 7 is the perfect 5th and 12 is one octave. When using the MIDI Guitar System, 12 may be the optimum value. Also, be sure to set the Bend range of the guitar system to the MKS-70's.

* The JX-10 does not work properly with the MKS-70's cartridge whose Bender Range is set to 12. This is because the JX-10's bend range is less than one octave, so change it to any other value.

• Chase Play

Chase Playing function can play one of the two Tones slightly later than the other Tone or repeat playing the sound. This function, therefore is available only in the Dual mode. Depending on the delay time and the Tone in use, the effects created differ: delay like effect, sound-on-sound like effect etc.

51 CHASE PLAY LEVEL **

00-99

This Factor sets the level of the delayed sound (= Tone B).

52 CHASE PLAY MODE ****

A-B-A-
A-B-
A-B

This Factor determines in what sequence the delayed sound should be played.

A-B-A-: In this mode, Tone A is played first, then Tone B, Tone A, Tone B, Tone A and so on.

A-B-: In this mode, Tone A is played first, then Tone B is played repeatedly.

A-B: In this mode, Tone A is first played, then Tone B. That is all to be played.

53 CHASE PLAY TIME **

01-99

Chase Play Time

This Factor sets the time between the first (Tone A) and the second (Tone B) sounds. Higher value is the longer time.

54 CHASE PLAY SWITCH ***

ON
OFF

This Factor turns on or off the Chase Playing function. If the Patch of the Chase Play ON is selected here, the Chase Play Button lights up, engaging the Chase Playing function.

Patch Factor Table

| | |
|----|-------------------|
| 11 | A/B BALANCE |
| 12 | DUAL DETUNE |
| 13 | UPPER SPLIT POINT |
| 14 | LOWER SPLIT POINT |
| 15 | PORTAMENTO TIME |
| 16 | BEND RANGE |
| 17 | KEY MODE |
| 18 | TOTAL VOLUME |


| | |
|----|-----------------|
| 21 | AFTER TOUCH VIB |
| 22 | AFTER TOUCH BRI |
| 23 | AFTER TOUCH VOL |

| | | | |
|----|-------------------|----|-------------------|
| 31 | A TONE NUMBER | 41 | B TONE NUMBER |
| 32 | A CHROMATIC SHIFT | 42 | B CHROMATIC SHIFT |
| 33 | A KEY ASSIGN | 43 | B KEY ASSIGN |
| 34 | A UNISON DETUNE | 44 | B UNISON DETUNE |
| 35 | A HOLD | 45 | B HOLD |
| 36 | A LFO MOD DEPTH | 46 | B LFO MOD DETPH |
| 37 | A PORTAMENTO | 47 | B PORTAMENTO |
| 38 | A BENDER | 48 | B BENDER |


| | |
|----|-------------------|
| 51 | CHASE PLAY LEVEL |
| 52 | CHASE PLAY MODE |
| 53 | CHASE PLAY TIME |
| 54 | CHASE PLAY SWITCH |

2) How to edit the Patch Factors

- ① Push the PATCH of the Edit Buttons.
- ② Using the Patch Memory/Number Buttons (1 to 8), assign the number of the Factor to be edited.



- ③ By rotating the Alpha Dial, change the value of the Factor.



- ④ To continue to edit other Factors, repeat the steps ② and ③ as many times.

► To select the Factor to be edited, you can use the Alpha Dial instead of the Patch Memory/Number Buttons. After pushing PATCH, then the PARAM buttons, rotate the Alpha Dial until the Factor you want appears in the Display, then push the VALUE of the Edit Buttons. Now, change the value by rotating the Alpha Dial.

- ⑤ When the editing is completed, push the PATCH Button to return to the Playing mode.

Now, the Patch Number flashes showing that the Patch is now edited but not yet written into memory.

c. Naming

A Tone can be named using up to 10 letters, and a Patch up to 18 letters.

① Make sure that the MKS-70 is in the Editing mode.

* If naming a Tone, using the ► or ◀ Button, select either the Tone A or B which is to be renamed.

* The MKS-70 is in the Editing mode when the TONE or the PATCH Button is lit.

② Push the NAME Button.

Patch Naming


I-A1 ELECTRIC PIANO 1

Tone Naming

I-A1 TONE-A 39 HARMO 1

③ Move the cursor to the letter to be changed using the ► or ◀ Button, then write the letter with the Alpha Dial or the Patch Memory/Number Buttons.

The letters available are as follows:



Number and Signs

| | | | | | | | |
|-------|---|---|---|---|---|---|---|
| SPACE | - | * | / | . | 9 | 0 | |
| A | B | C | D | E | F | G | H |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |

④ When the naming is completed, take the appropriate writing procedure that varies depending on whether you are writing a Tone or a Patch. (See page 41.)

* If you fail to write the Tone or Patch, the name will be erased.

* Please do not take the naming procedure in the middle of editing, or the edited data will be rewritten.

d. Setting MIDI Functions

1) MIDI Functions

- Mode

| | | |
|----|------|-------|
| 11 | MODE | ***** |
|----|------|-------|

OMNI OFF POLY
 OMNI OFF MONO

This Function selects one of the MIDI modes; POLY or MONO. Usually select Poly mode, and select Mono mode when the guitar controller is used.

* The MKS-70 is always in the OMNI OFF mode.

- Channel

| | | |
|----|-----------|----|
| 21 | CHANNEL A | ** |
|----|-----------|----|

| | | |
|----|-----------|----|
| 31 | CHANNEL B | ** |
|----|-----------|----|

1-16

This Function selects Channel A or B.

| | | |
|----|-----------------|----|
| 12 | CONTROL CHANNEL | ** |
|----|-----------------|----|

1-16

MIDI Control Channel number should be set in the following cases:

- (1) To change Patches with the Program Change message
- (2) To transfer the System Exclusive

- Program Change Receive

This Factor is to determine how the Program Change messages should work.

| | | |
|----|-------------------|-----|
| 13 | PATCH PROG CHANGE | *** |
|----|-------------------|-----|

ON
 OFF

When this Function is ON, the Program Change message sent on the Control Channel works to change the Patch Numbers on the MKS-70.

The Patch Numbers on the MKS-70 correspond to the Program Change Numbers as shown below.

| Received Program Change Number | Selected Patch Number |
|--------------------------------|-----------------------|
| 1 | 1 A1 |
| 64 | 1 H8 |
| 65 | C A1 |
| 128 | C H8 |

2 2 A PROG CHANGE ***

3 2 B PROG CHANGE ***

ON
OFF

When the Function 22 is ON, the Program Change message sent on the Channel A changes the Tone A. When the Function 32 is ON, the Program Change sent on the Channel B changes the Tone B.

The Tone Numbers on the MKS-70 correspond to the Program Change Numbers as shown below.

| Received Program Change Number | Selected Tone Number |
|--------------------------------|----------------------|
| 1 | 1 |
| 50 | 50 |
| 100 | 100 |

* When either the Channel A or Channel B is set to Control Channel Function ON, the Program Change message sent on that channel will change the Patches.

● Aftertouch

2 3 A AFTER TOUCH ***

3 3 B AFTER TOUCH ***

ON
OFF

This Function selects whether to receive or ignore the Aftertouch message.

● MIDI Volume

2 4 A MIDI VOLUME ***

3 4 B MIDI VOLUME ***

ON
OFF

This Function selects whether to receive or ignore the MIDI Volume message.

● System Exclusive

1 4 SYSTEM EXCLUSIVE ***

ON
OFF

This Function selects whether to receive or ignore the System Exclusive message.

► For the detailed explanation on the System Exclusive, refer to page 44.


MIDI Function Table

| | |
|----|-------------------|
| 11 | MODE |
| 12 | CONTROL CHANNEL |
| 13 | PATCH PROG CHANGE |
| 14 | SYSTEM EXCLUSIVE |


| | | | |
|----|---------------|----|---------------|
| 21 | CHANNEL A | 31 | CHANNEL B |
| 22 | A PROG CHANGE | 32 | B PROG CHANGE |
| 23 | A AFTER TOUCH | 33 | B AFTER TOUCH |
| 24 | A MIDI VOLUME | 34 | B MIDI VOLUME |

2) Setting MIDI Functions

- ① Push the MIDI of the Edit Buttons.
- ② Using the Patch Memory/Number Buttons 1 to 5, assign the number of the MIDI Function to be edited.



- ③ By rotating the Alpha Dial, change the value.



- ④ To continue to edit other MIDI Functions, repeat the steps ② and ③.

► To select a Function, the Alpha Dial can be used instead of the Patch Memory/Number Buttons. Push the MIDI Button then the PARAM Button, then rotate the Alpha Dial until the Function you want appears in the Display. Then push the VALUE of the Edit Buttons and change the value with the Alpha Dial.

- ⑤ When the editing is completed, push the MIDI Button to return to the Playing mode.

The edited data will be retained until the unit is turned off.

4. Writing Mode

Writing mode allows to write the edited data into the internal memory or onto the memory cartridge.

• Protect Switch

To write the data into the internal memory, set the Protect Switch on the MKS-70 to the OFF position, and to write onto the memory cartridge, set the Protect Switch on the cartridge to OFF.

Protect Switch ON

Usually, the Protect Switch should be set to the ON position to prevent accidental loss of the data in memory. With the Protect Switch set to ON, pushing the WRITE Button causes the Display to respond with as shown below, without the data being written.

MEMORY PROTECTED

Protect Switch OFF


OFF position should be selected when writing the data into memory. The switch, however, should be returned to the ON position after writing without fail.

• Memory Cartridge

Patches (A1 to H8), Tones (1 to 50) and MIDI Functions can be written into the memory cartridge.

Before connecting or disconnecting the memory cartridge, be sure to set the Protect Switch on the cartridge to the ON position.

As shown in the picture, securely connect the cartridge to the MKS-70 with the Protect Switch side facing upward.



JX-8P's Memory Cartridge

The memory cartridge of the JX-8P "M-16C" can be used as Tone Banks for the MKS-70. The JX-8P has only 32 Tones from Memory Numbers 1 to 32, therefore, assigning other number than 1 to 32 will cause the Display to respond with:

SELECT NO. 1-32

Reassign an appropriate Memory Number.

JX-10's Memory cartridge

The JX-10's memory cartridge for the Voice data (not for the sequencer data) can also be used with the MSK-70. However, the MIDI Functions of the JX-10 cannot be transferred to the MKS-70. Also, writing MIDI Functions on the MKS-70 does not erase the MIDI Functions on the JX-10. The Patch Factors "61-68 MIDI SEND" cannot be used on the MKS-70.

Other Memory Cartridge cannot be used with the MKS-70.

If using any cartridge other than the above two types, the following error message will be shown in the Display.

M I S M A T C H

If you wish to erase the previous data written on the cartridge and write the MKS-70's data on it, take the same Writing procedure twice more. The first time, the Display shows the same indication, and the second time, the writing is executed.

When a brand new cartridge is used, the same error message is shown in the Display. Take the same procedure as above.

■ Writing Procedure

You may normally enter to the Writing mode from the Editing mode, as you may wish to write the edited data. To enter to the Writing mode from the Playing mode, simply push the relevant Edit Button before pushing the WRITE Button.

► Pushing the WRITE Button in the Playing mode will cause the Display to respond with:

W R I T E M O D E

Now, push the relevant Edit Button. (The indicator lights up.)

a. Writing a Tone

1 to 50 Tone Numbers can be rewritten, but 51 to 100 are non-volatile. This fact applied to the Tones on the cartridge.

If any of the Tone Numbers 51 to 100 is assigned, the Display responds with:

SELECT NO. 1-50

Reassign the appropriate Tone Number.

- ① Set the Protect Switch on the destination memory (either the MKS-70 or the cartridge) to the OFF position.
- ② Push the WRITE Button.

WRITE TONE TO CART 39 OK?

The Tone Number currently in use is shown at the underlined position.

To write the Tone to other Tone Number:

- ③ Select the destination memory (either the internal memory or the memory cartridge) by pushing the Cartridge Button. Then using the Patch Memory/Number Buttons 0 to 9, assign the Tone Number where the Tone is to be written, then push the ENTER Button.
- ④ Push the ENTER Button.

To write the Tone to the Tone Number currently shown in the Display:

WRITTEN TONE

- ③ Push the ENTER Button.

The Display shows that the writing is completed then returns to the Playing mode indication.

b. Writing a Patch

- ① Set the Protect Switch on the destination memory (either the MKS-70 or the cartridge) to the OFF position.
- ② Push the WRITE Button.

WRITE PATCH TO CART A1 OK?

The Patch currently in use is shown at the underlined position.

To write the Patch to other location:

- ③ Select the destination memory (either the internal memory or the memory cartridge) by pushing the Cartridge Button. Then using the Patch Memory/Number Buttons 0 to 9, assign the location (Patch) where the Patch is to be written.
- ④ Push the ENTER Button.

To write the Patch to the location (Patch) currently shown in the Display:

- ③ Push the ENTER Button.

WRITTEN PATCH

The Display shows that the writing is completed then returns to the Playing mode indication.

*** When writing is completed, be sure to return the Protect Switch to the ON position.**

c. Writing MIDI Functions

- ① Set the Protect Switch on the MKS-70 to the OFF position.
- ② Push the WRITE Button.
- ② Push the ENTER Button.
- ③ Return the Protect Switch to the ON position.

* The MIDI Functions cannot be directly written on the cartridge, but can be transferred from the internal memory of the MKS-70.

d. Saving and Loading

The entire data of 64 Patches, 50 Tones and MIDI Functions can be transferred from the internal memory to the memory cartridge (=saving) or vice versa (=loading).

You should enter to the saving or the loading mode from the Playing mode.

● Saving

Saving is transferring the data from the internal memory of the MKS-70 to the memory cartridge.

- ① Make sure that the Protect Switch on the MKS-70 is set to the ON position.
- ② Set the Protect Switch on the memory cartridge to the OFF position.
- ③ Push the WRITE Button.

WRITE MODE

- ④ Rotate the Alpha Dial until the Display responds with:

COPY INTERNALMEMORY TO CARTRIDGE

- ⑤ Push the ENTER Button.

When the saving is done, the Display returns to the Playing mode indication.

- ⑥ Return the Protect Switch on the cartridge to the ON position.

• Loading

Loading is the transferring the data from the cartridge to the internal memory.

- ① Make sure that the Protect Switch on the cartridge is set to the ON position.
- ② Set the Protect Switch on the MKS-70 to the OFF position.
- ③ Push the WRITE Button.

WRITE MODE

- ④ Rotate the Alpha Dial until the Display responds with:

COPY CARTRIDGE TO INTERNALMEMORY

- ⑤ Push the ENTER Button.

When the loading is completed, the Display returns to the Playing mode indication.

- ⑥ Return the Protect Switch on the MKS-70 to the ON position.

5. System Exclusive

Using the MIDI System Exclusive, the Patch and Tone data in the MKS-70's internal memory can be transmitted to the receiver device. However, the receiver device must have the function of receiving the data. Here, we use the MKS-70 as a receiver.

To transmit and receive System Exclusive, take the following procedure first.

- ① Match the MIDI Control Channel numbers of the two MKS-70's.
- ② Set the MIDI Function "14 SYSTEM EXCLUSIVE" on the both MKS-70's to ON.

Now, take the following procedure, and the transmitter MKS-70 will transmit the corresponding data, and the receiver will receive it and therefore edited. (Bulk Dump explained later will replace the previous data in the receiver's memory.)

Patch Selection with System Exclusive

- This does not include the Patch selection with the Program Change message.

The whole data of the selected Patch is transmitted:

Patch Number

Patch Name

Values of all the Patch Factors

Values of all the Parameters of Tone A used in the selected Patch

Values of all the Parameters of Tone B used in the selected Patch

If the receiver MKS-70 is set to the Playing mode, the Display shows the flashing Patch Number and the Tone Numbers of the selected Patch instead of the usual Patch indication.

I-A1 ELECTRIC PIANO 1 39 83.

Flashing

Flashing Flashing

Tone Selection with System Exclusive

- This does not include the Tone selection with the Program Change messages.

The whole data of the selected Tone will be transferred:

Tone Number

Tone Name

Values of Tone Parameters

If the receiver is set to the Playing mode, the selected Tone Number will flash.

```
I-A1 ELECTRIC PIANO 1    39.  83
```

Flashing

Editing Patch Factors or Tone Parameters with System Exclusive

The edited values of the Patch Factors or Tone Parameters are transferred.

If the receiver is in the Playing mode, the selected Patch Number or the Tone Number(s) flashes.

• Bulk Damp

Bulk Damp is transferring all the 64 Patches and 50 Tones stored in the internal memory to the receiver device.

- * While in Bulk Damp, the MKS-70 cannot be played.

<How to Bulk Damp>

Set the Protect Switch on the receiver to the OFF position, then take the following procedure on the transmitter.

- ① Push the MIDI Button.

The indicator on the MIDI Button lights up.

- ② Push the WRITE Button.

The Display responds with:

```
WRITE MIDI
```

- ③ Rotate the Alpha Dial until the Display responds with:

```
MIDI BULK DUMP
```

- ④ Push the ENTER Button.

Now, Bulk Damp is executed, and the Display of the receiver responds with:

```
MIDI BULK LOAD
```

- * While the above indication is shown in the Display, the MKS-70 cannot be played.

- * Return the Protect Switch on the receiver to the ON position.

3 ERROR MESSAGES

1) MEMORY PROTECTED

When this error message is shown in the Display, the Protect Switch of the destination memory is set to the On position (during the Writing mode).

Set the relevant Protect Switch to the OFF position, and repeat the writing procedure.

2) INSERT CARTRIDGE

The cartridge is not properly connected.

Securely and correctly connect the cartridge to the MKS-70, and repeat the procedure.

3) MISMATCH

The cartridge connected is not appropriate for what you are going to do. Change the cartridges.

However, if you want to erase the previous data and write on that cartridge, take the same writing procedure two more times. The first time, the same indication "MISMATCH" is shown, and the second time, writing is done.

When a brand new cartridge is used, the same error message is shown. Do exactly the same as above.

4) NOT M-64C

This is shown when you try to write Patch, Tone or MIDI data onto the M-16C cartridge. Change it to the M-64C cartridge.

5) SELECT NO.1-50

This appears when you try to write a Tone Number 51 to 100 which can be edited but cannot be rewritten. Select the Tone Number 1 to 50.

6) SELECT NO.1-32

When you try to call a Tone other than 1 to 32 from the JX-8P's memory cartridge, this error message appears in the Display. Select the Tone Number 1 to 32.

7) MEMORY ERR

The data is not properly written into memory. If this error message is frequently shown, ask for your local Roland service station.

MODEL MKS-70 MIDI Implementation Chart

Date: Sep,6 1986
Version:1.00

| Function..... | | Transmitted | Recognized | Remarks |
|------------------|---|--------------------------------|-----------------------------------|---|
| Basic Channel | Default Changed | X X | 1-16 1-16 | memorized |
| Mode | Default Messages Altered | X X ***** | Mode 3,Mode 4 POLY , MONO X | memorized |
| Note Number | True voice | X ***** | 0-127 21-108 | |
| Velocity | Note ON Note OFF | X X | ○ v=1-127 X | |
| After Touch | Key's Ch's | X X | X * | |
| Pitch Bender | | X | * 2/3/4/7/12 semi 8bits reso. | |
| Control Change | 1 5 7 64 65 | X X X X X | ○ ○ * ○ ○ | Modulation Portamento time Volume Hold 1 Portamento Switch |
| Prog Change | True # | * 0-99 (0-127) 0-99 (0-127) | * 0-99 (0-127) 0-99 (0-127) | ** |
| System Exclusive | | * | * | |
| System Common | Song Pos Song Sel Tune | X X X | X X X | |
| System Real Time | Clock Commands | X X | X X | |
| Aux Messages | Local ON/OFF All Notes OFF Active Sense Reset | X X X X | X ○ (123-127) X X | |
| Notes | * Can be set to○orXmanually, and memorized. ** As tone # : 0-99(100-127 ignored if received.) As patch # : 0-127 See implementation notes for details. | | | |

Mode 1 : OMNI ON. POLY
Mode 3 : OMNI OFF. POLY

Mode 2 : OMNI ON, MONO
Mode 4 : OMNI OFF MONO

○ : Yes
X : No

MODEL MKS-70 MIDI Implementation

Date: Sep. 6 1986
Version: 1.00

1. TRANSMITTED DATA

| Status | Second | Third | Description |
|-----------|-----------|-------|--|
| 1100 nnnn | 0ppp pppp | | Program Change ppppppp = 0 - 127 (0 - 99) |

Notes : Program Change (TONE #) are transmitted on CHANNEL A and/or channel B according to KEY MODE.
Program Change (PATCH #) are transmitted on CONTROL CHANNEL

a. On CHANNEL A OR CHANNEL B :
TONE # is Transmitted if the corresponding function switch is ON.
ppppppp = 0 - 99 : TONE No. 1 - 100

b. On CONTROL CHANNEL :
PATCH # is Transmitted if the corresponding function switch is ON.
ppppppp = 0 - 63 : Internal Memory PATCH A1 - H8
64 - 127 : Cartridge Memory PATCH A1 - H8

2. RECOGNIZED RECEIVE DATA

| Status | Second | Third | Description |
|-----------|-----------|-----------|---|
| 1000 nnnn | 0kkk kkkk | 0vvv vvvv | Note OFF, velocity ignored |
| 1001 nnnn | 0kkk kkkk | 0000 0000 | Note OFF kkkkkkk = 0 - 127 (21 - 108) *1 |
| 1001 nnnn | 0kkk kkkk | 0vvv vvvv | Note ON kkkkkkk = 0 - 127 (21 - 108) *1 vvvvvvv = 1 - 127 |
| 1011 nnnn | 0000 0001 | 0vvv vvvv | Modulation vvvvvvv = 0 - 127 |
| 1011 nnnn | 0000 0101 | 0vvv vvvv | Portamento time vvvvvvv = 0 - 127 |
| 1011 nnnn | 0000 0111 | 0vvv vvvv | Volume vvvvvvv = 0 - 127 *2 |
| 1011 nnnn | 0100 0000 | 01xx xxxx | Hold 1 ON |
| 1011 nnnn | 0100 0000 | 00xx xxxx | Hold 2 OFF |
| 1011 nnnn | 0100 0001 | 01xx xxxx | Portamento ON |
| 1011 nnnn | 0100 0001 | 00xx xxxx | Portamento OFF |
| 1100 nnnn | 0ppp pppp | | Program Change ppppppp = 0 - 127 (0 - 99) *2,*3 |
| 1101 nnnn | 0vvv vvvv | | Channel After Touch vvvvvvv = 0 - 127 *2 |
| 1110 nnnn | 0vvv vvvv | 0vvv vvvv | Pitch Bender Change *2 |
| 1011 nnnn | 0111 1110 | 000m mmmm | Mono ON *2 |
| 1011 nnnn | 0111 1111 | 0000 0000 | Poly ON *2 |
| 1011 nnnn | 0111 1011 | 0000 0000 | ALL NOTES OFF *2 |

Notes : All messages except PATCH # (Program Change) are received from CHANNEL A and/or CHANNEL B according to KEY MODE.

*1 Note numbers outside of the range 21 - 108 are transposed to the nearest octave inside this range.

*2 Received if the corresponding function switch is ON.

*3 a. ON CHANNEL A OR CHANNEL B :
Received as TONE # if the corresponding function switch is ON.
ppppppp = 0 - 99 : TONE No. 1 - 100
b. ON CONTROL CHANNEL :
Received as PATCH # if the corresponding function switch is ON.
ppppppp = 0 - 63 : Internal Memory PATCH A1 - H8
64 - 127 : Cartridge Memory PATCH A1 - H8

3. TRANSMITTED EXCLUSIVE MESSAGES

3.1 When the 'Patch Bank' or 'Patch Number' is changed, the following exclusive messages (3.1.1 PGR and 3.1.2 APR) are sent in sequence.

3.1.1 Program Number (PGR)

| Byte | Description |
|-------------|---|
| a 1111 0000 | Exclusive status |
| b 0100 0001 | Roland ID # |
| c 0011 0100 | Operation code = PGR (program number) |
| d 0000 nnnn | Unit # = control channel, nnnn = 0 - 15 where nnnn + 1 = channel # |
| e 0010 0100 | Format type (JX-10) |
| f 0011 0000 | Level 2 Patch |
| g 0000 0001 | Group # |
| h 0000 0000 | PG# indicates the patch number |
| i 00pp pppp | Patch number |
| j 0000 0000 | NOP |
| k 1111 0111 | End of System Exclusive |

3.1.2 All Patch Parameters (APR)

| Byte | Description |
|-------------|---|
| a 1111 0000 | Exclusive status |
| b 0100 0001 | Roland ID # |
| c 0011 0101 | Operation code = APR (all parameters) |
| d 0000 nnnn | Unit # = control channel, nnnn = 0 - 15 where nnnn + 1 = channel # |
| e 0010 0100 | Format type (JX-10) |
| f 0011 0000 | Level 2 Patch |
| g 0000 0001 | Group # |
| h 00vv vvvv | Value (0 - 127) |
| i 1111 0111 | In sequence (51 byte total) End of System Exclusive |

3.2 Individual Patch Parameter (IPR) When the Patch Memory Factor is changed.

| Byte | Description |
|-------------|---|
| a 1111 0000 | Exclusive status |
| b 0100 0001 | Roland ID # |
| c 0011 0110 | Operation code = IPR (individual parameter) |
| d 0000 nnnn | Unit # = control channel, nnnn = 0 - 15 where nnnn + 1 = channel # |
| e 0010 0100 | Format type (JX-10) |
| f 0011 0000 | Level 2 Patch |
| g 0000 0001 | Group # |
| h 00pp pppp | Parameter # (0 - 51) |
| i 00vv vvvv | Value (0 - 127) |
| j 1111 0111 | End of System Exclusive |

Notes :

| parameter # | Function | Value |
|-------------|-------------------------------------|-------------------------------------|
| 0-17 | PATCH NAME 1..18 | In ASCII |
| 18 | U/L BALANCE | 0 - 127 |
| 19 | DUAL DETUNE | 0 - 127 |
| 20 | UPPER SPLIT POINT | 21 - 108 |
| 21 | LOWER SPLIT POINT | 21 - 108 |
| 22 | PORTAMENTO TIME | 0 - 127 |
| 23 | BEND RANGE 0aaaaaa | 0,32,64,96 |
| 52 | BEND RANGE 0bbbbbb | 0,1 |
| | BEND RANGE = bbbbbbaaaaaa | |
| | 0 = 2 Semi Tones | |
| | 32 = 3 Semi Tones | |
| | 64 = 4 Semi Tones | |
| | 96 = 7 Semi Tones | |
| | 128 = 12 Semi Tones | |
| | 160 = 12 Semi Tones | |
| | 192 = 12 Semi Tones | |
| | 224 = 12 Semi Tones | |
| 24 | KEY MODE 000000aa | 0 - 3 |
| 51 | KEY MODE 000000bb | 0 - 2 |
| | KEY MODE = bbaa | |
| | 0 = DUAL | |
| | 1 = SPLIT | |
| | 2 = A WHOLE | |
| | 3 = B WHOLE | |
| | 4 = X - FADE | |
| | 8 = T - VOICE | |
| 25 | TOTAL VOLUME | 0 - 127 |
| 26 | AFTER TOUCH VIBRATO | 0 - 127 |
| 27 | AFTER TOUCH BRILLIANCE | 0 - 127 |
| 28 | AFTER TOUCH VOLUME | 0 - 127 |
| 29 | UPPER TONE NUMBER | 0 - 99 |
| 30 | UPPER CHROMATIC SHIFT | 0 - 24 = 0 - (+24) semi tones |
| 31 | UPPER KEY ASSIGN | 104 - 127 = (-24) - (-1) semi tones |
| | 0 = Poly-1 | |
| | 1 = Unison-1 | |
| | 2 = Mono-1 | |
| | 4 = Poly-2 | |
| | 5 = Unison-2 | |
| | 6 = Mono-2 | |
| 32 | UPPER UNISON DETUNE | 0 - 127 |
| 33 | UPPER HOLD | 0 = OFF |
| | 1 = ON | |
| 34 | UPPER LFO MOD DEPTH | 0 - 127 |
| 35 | UPPER PORTAMENTO | 0 = OFF |
| | 1 = ON | |
| 36 | UPPER BENDER | 0 = OFF |
| | 1 = ON | |
| 37 | Undefined | |
| 38 | LOWER TONE NUMBER | 0 - 99 |
| 39 | LOWER CHROMATIC SHIFT | 0 - 24 = 0 - (+24) semi tones |
| | 104 - 127 = (-24) - (-1) semi tones | |
| 40 | LOWER KEY ASSIGN | 0 = Poly-1 |
| | 1 = Unison-1 | |
| | 2 = Mono-1 | |
| | 4 = Poly-2 | |
| | 5 = Unison-2 | |
| | 6 = Mono-2 | |
| 41 | LOWER UNISON DETUNE | 0 - 127 |
| 42 | LOWER HOLD | 0 = OFF |
| | 1 = ON | |
| 43 | LOWER LFO MOD DEPTH | 0 - 127 |
| 44 | LOWER PORTAMENTO | 0 = OFF |
| | 1 = ON | |
| 45 | LOWER BENDER | 0 = OFF |
| | 1 = ON | |
| 46 | Undefined | |
| 47 | CHASE LEVEL | 0 - 127 |
| 48 | CHASE MODE | 0 = A-B |
| | 1 = A-B-B- | |
| | 2 = A-B-A- | |
| | 1 - 127 | |
| 49 | CHASE TIME | 0 = OFF |
| 50 | CHASE PLAY | 1 = ON |

3.3 When the 'Tone Number' is changed, the following exclusive messages (3.3.1 PGR and 3.3.2 APR) are sent in sequence.

3.3.1 Program Number (PGR)

| Byte | Description |
|-------------|---|
| a 1111 0000 | Exclusive status |
| b 0100 0001 | Roland ID # |
| c 0011 0100 | Operation code = PGR (program number) |
| d 0000 nnnn | Unit # = control channel, nnnn = 0 - 13 where nnnn + 1 = channel # |
| e 0010 0100 | Format type (JX-10) |
| f 0010 0000 | Level 1 Tone |
| g 0000 00gg | Group # gg = 01 Tone A gg = 10 Tone B |
| h 0000 0000 | PG# indicates the tone number |
| i sttt tttt | Tone number |
| j 0000 0000 | NOP |
| k 1111 0111 | End of System Exclusive |

3.3.2 All Tone Parameters (APR)

| Byte | Description |
|-------------|---|
| a 1111 0000 | Exclusive status |
| b 0100 0001 | Roland ID # |
| c 0011 0101 | Operation code = APR (all parameters) |
| d 0000 nnnn | Unit # = control channel, nnnn = 0 - 15 where nnnn + 1 = channel # |
| e 0010 0100 | Format type (JX-10) |
| f 0010 0000 | Level # = 1 |
| g 0000 00gg | Group # gg = 01 Tone A gg = 10 Tone B |
| h 0vvv vvvv | Value (0 - 127) |
| : | In sequence (59 byte total) |
| i 1111 0111 | End of System Exclusive |

3.4 Individual Tone Parameter (IPR)
When the Parameter is changed.

| Byte | Description |
|-------------|---|
| a 1111 0000 | Exclusive status |
| b 0100 0001 | Roland ID # |
| c 0011 0110 | Operation code = IPR (individual parameter) |
| d 0000 nnnn | Unit # = control channel, nnnn = 0 - 15 where nnnn + 1 = channel # |
| e 0010 0100 | Format type (JX-10) |
| f 0010 0000 | Level # = 1 |
| g 0000 00gg | Group # gg = 01 Tone A gg = 10 Tone B |
| h 00pp pppp | Parameter # (0 - 58) |
| i 0vvv vvvv | Value (0 - 127) |
| : | h and i (repeatedly) |
| j 1111 0111 | End of System Exclusive |

Notes :

| Parameter # | Function | Value |
|-------------|---------------------|---|
| 0-9 | NAME-0..9 | In ASCII |
| 10 | Undefined | |
| 11 | DCO-1 RANGE | 0 - 31 = 16' 32 - 63 = 8' 64 - 95 = 4' 96 - 127 = 2' |
| 12 | DCO-1 WAVEFORM | 0 - 31 = Noise 32 - 63 = Sawtooth Wave 64 - 95 = Pulse Wave 96 - 127 = Square Wave |
| 13 | DCO-1 TUNE | 0 - 127 (-1 oct -- +1 oct) |
| 14 | DCO-1 LFO MOD DEPTH | 0 - 127 |
| 15 | DCO-1 ENV MOD DEPTH | 0 - 127 |
| 16 | DCO-2 RANGE | 0 - 31 = 15' 32 - 63 = 8' 64 - 95 = 4' 96 - 127 = 2' |
| 17 | DCO-2 WAVEFORM | 0 - 31 = Noise 32 - 63 = Sawtooth Wave 64 - 95 = Pulse Wave 96 - 127 = Square Wave |
| 18 | DCO-2 CROSSMOD | 0 - 31 = OFF 32 - 63 = SYNC 1 64 - 95 = SYNC 2 96 - 127 = XMOD (cross modulation) |
| 19 | DCO-2 TUNE | 0 - 127 (-1 oct -- +1 oct) |
| 20 | DCO-2 FINE TUNE | 0 - 127 (-50 cent -- +50 cent) |
| 21 | DCO-2 LFO MOD DEPTH | 0 - 127 |
| 22 | DCO-1 ENV MOD DEPTH | 0 - 127 |

| | | |
|----|---------------------|--|
| 23 | Undefined | 0 - 31 = OFF |
| 24 | Undefined | 32 - 63 = 1 |
| 25 | Undefined | 64 - 95 = 2 |
| 26 | DCO DYNAMICS | 96 - 127 = 3 |
| 27 | DCO ENV MODE | 0 - 31 = ENV-2 Inverted 32 - 63 = ENV-2 Normal 64 - 95 = ENV-1 Inverted 96 - 127 = ENV-1 Normal |
| 28 | MIXER DCO-1 | 0 - 127 |
| 29 | MIXER DCO-2 | 0 - 127 |
| 30 | MIXER ENV MOD DEPTH | 0 - 127 |
| 31 | MIXER DYNAMICS | 0 - 31 = OFF 32 - 63 = 1 64 - 95 = 2 96 - 127 = 3 |
| 32 | MIXER ENV MODE | 0 - 31 = ENV-2 Inverted 32 - 63 = ENV-2 Normal 64 - 95 = ENV-1 Inverted 96 - 127 = ENV-1 Normal |
| 33 | HFP CUTOFF FREQ | 0 - 31 = 0 32 - 63 = 1 64 - 95 = 2 96 - 127 = 3 |
| 34 | VCF CUTOFF FREQ | 0 - 127 |
| 35 | VCF RESONANCE | 0 - 127 |
| 36 | VCF LFO MOD DEPTH | 0 - 127 |
| 37 | VCF ENV MOD DEPTH | 0 - 127 |
| 38 | VCF KEY FOLLOW | 0 - 127 |
| 39 | VCF DYNAMICS | 0 - 31 = OFF 32 - 63 = 1 64 - 95 = 2 96 - 127 = 3 |
| 40 | VCF ENV MODE | 0 - 31 = ENV-2 Inverted 32 - 63 = ENV-2 Normal 64 - 95 = ENV-1 Inverted 96 - 127 = ENV-1 Normal |
| 41 | VCA LEVEL | 0 - 127 |
| 42 | VCA DYNAMICS | 0 - 31 = OFF 32 - 63 = 1 64 - 95 = 2 96 - 127 = 3 |
| 43 | CHORUS | 0 - 31 = OFF 32 - 63 = 1 64 - 127 = 2 |
| 44 | LFO WAVEFORM | 0 - 31 = Random 32 - 63 = Square Wave 64 - 127 = Triangle Wave |
| 45 | LFO DELAY TIME | 0 - 127 |
| 46 | LFO RATE | 0 - 127 |
| 47 | ENV-1 ATTACK TIME | 0 - 127 |
| 48 | ENV-1 DECAY TIME | 0 - 127 |
| 49 | ENV-1 SUSTAIN LEVEL | 0 - 127 |
| 50 | ENV-1 RELEASE TIME | 0 - 127 |
| 51 | ENV-1 KEY FOLLOW | 0 - 31 = OFF 32 - 63 = 1 64 - 95 = 2 96 - 127 = 3 |
| 52 | ENV-2 ATTACK TIME | 0 - 127 |
| 53 | ENV-2 DECAY TIME | 0 - 127 |
| 54 | ENV-2 SUSTAIN LEVEL | 0 - 127 |
| 55 | ENV-2 RELEASE TIME | 0 - 127 |
| 56 | ENV-2 KEY FOLLOW | 0 - 31 = OFF 32 - 63 = 1 64 - 95 = 2 96 - 127 = 3 |
| 57 | Undefined | |
| 58 | VCA ENV MODE | 0 - 63 = Gate 64 - 127 = ENV-2 Normal |

3.5 Bulk Dump (BLD)

- How to enter to 'BULK DUMP' mode :
1. Press both MIDI and WRITE button.
 2. Select BULK DUMP by ALPHA-DIAL, then press ENTER.

3.5.1 Bulk Dump (PATCH)

| Byte | Description |
|-------------|---|
| a 1111 0000 | Exclusive status |
| b 0100 0001 | Roland ID # |
| c 0011 0111 | Operation code = BLD (bulk dump) |
| d 0000 nnnn | Unit # = control channel, nnnn = 0 - 15 where nnnn + 1 = channel # |
| e 0010 0100 | Format type (JX-10) |
| f 0011 0000 | Level # = 2 Patch |
| g 0000 0001 | Group # |
| h 0000 0000 | PG# indicates the Patch number |
| i 00pp pppp | Patch number (0 - 63) |
| j 0000 vvvv | Value (0 - 15) |
| : | In sequence (96 bytes total) |
| k 1111 0111 | End of System Exclusive |

Notes :

Bulk Dump (PATCH) is available the Internal Memory PATCH A1 - H8(pppppp = 0 - 63) only.

3.5.2 Bulk Dump [TONE]

| Byte | Description |
|-------------|---|
| a 1111 0000 | Exclusive status |
| b 0100 0001 | Roland ID # |
| c 0011 0111 | Operation code = BLD (bulk dump) |
| d 0000 nnnn | Unit # = control channel, nnnn = 0 - 15 where nnnn + 1 = channel # |
| e 0010 0100 | Format type (JX-10) |
| f 0010 0000 | Level # = 1 Tone |
| g 0000 0001 | Group # |
| h 0000 0000 | PG# indicates the Tone |
| i 00tt tttt | Tone number (0 - 49) |
| j 0vvv vvvv | Value (0 - 127) |
| : | in sequence (59 bytes total) |
| k 1111 0111 | End of System Exclusive |

Notes :

Bulk Dump [TONE] is available the Internal Memory TONE = 1 - 50
(tttttt = 0 -49) only.

3.5.3 Sequence of Bulk Dump

- 1: Bulk Dump [PATCH] message repeats 64 times.
- 2: Bulk Dump [TONE] message repeats 50 times.

4. RECOGNIZED EXCLUSIVE MESSAGES

All Exclusive messages described in section 3.

SPECIFICATIONS

MKS-70: 12 Voices (24 DCO's) Polyphonic Synthesizer Module

Memory

- a. Patch
 - Internal Memory: 64
 - (Memory Cartridge): 64
- b. Tone
 - Preset: 50
 - Internal Memory: 50
 - (Memory Cartridge): 50

Edit

- Patch Factors
- Tone Parameter
- MIDI Functions
- Master Tune
- Name

Front Panel

- Patch Memory/Number (A – H, 1 – 8) Buttons
- Edit Buttons (PATCH, TONE, MIDI, PARAM, VALUE, NAME)

- Function Display Button
- A/B Buttons
- Chase Play Button
- Write Button
- Ten Key Pad
- Enter Button
- Master Tune Button
- Volume Knob
- Alpha Dial
- Protect Switch
- Power Switch
- Programmer Connector
- Headphones Jack
- 32 figures Fluorescent Indicator Panel Display

Rear Panel

- Mix Output Jack
- Output Level Switch
- Parallel Output Jack × 4
- MIDI Connector × 3

Dimensions: 480 (W) × 400 (D) × 88 (H) mm/
18-7/8" × 15-3/4" × 3-7/16"

Weight: 7.6 kg / 70 lb 10 oz

Power Consumption: 32 W

Accessories

- Connection Cord × 2
- MIDI Cable × 2
- Memory Cartridge M-64C × 1
- Edit Map
- Owner's Manual
- Guide Book "MIDI"

OPTIONS

- Programmer PG-800
- Memory Cartridge M-64C
- Carrying Case

 Roland®

10815

UPC

10815



10815

MKS-70

 Roland

86-10-GE1-1S