

Side Trak

TECHNICAL MANUAL

SIDETRAK

Technical Manual

December 1979

Copyright (c) EXIDY, INC.

CONTENTS

I.	NORMAL OPERATION.....	1
	A. Attract Mode.....	1
	B. Introduction.....	2
	C. Game Play.....	2
II.	SELECTABLE OPTIONS.....	3
	A. Coinage.....	4
	B. Crashes.....	4
III.	AUDIO ADJUSTMENTS.....	5
IV.	POWER SUPPLY ADJUSTMENTS.....	6
V.	MECHANICAL ASSEMBLIES.....	7
	A. Servicing the Controls.....	7
	B. Servicing the Four-way Joy Stick.....	8
	C. Removing the Monitor.....	9
	D. Removing the Logic and Audio Boards.....	9
VI.	PARTS LIST.....	10
VII.	SCHEMATICS.....	19

I. NORMAL OPERATION

A. Attract Mode

When the game is first turned on, a five lane square track is graphically displayed. Alternating with the racetrack display is TODAY'S HIGH SCORE followed by a score which changes with each new higher score attained throughout the day. During the progress of the game, Player 1's score is displayed on the upper left of the screen, Player 2's score is displayed on the upper right of the screen, and the number of crashes left is displayed in the middle of the upper screen. When the game is turned off, the high score is reset to zero.

Also displayed on screen, at the operator's selection, will be one of the following:

PLAYER 1	PLAYER 2
----------	----------

1 COIN	1 PLAY
--------------	--------

or

1 COIN	1 PLAY
2 COIN	2 PLAY

or

2 COIN	1 PLAY
4 COIN	2 PLAY

CRASH also has a coin accumulator so a player can buy a number of games in advance.

While in the attract mode (no credits, no game in progress), the game plays automatically.

B. Introduction Mode

When a player deposits a coin, the following message comes on the screen:

SWITCH TRACKS TO AVOID
CRASH WITH KILLER ENGINE

PASS STARTING POINT FOR
BONUS CARS AND SCORE

ADDED TRAIN CARS INCREASES
SCORE

CREDITS
N

TOP THIS SCORE FOR CREDIT

M

Where N is the number of games in the credit counter, and M is a random score used by the TOP THIS SCORE feature. The TOP THIS SCORE MESSAGE appears when the option switch is set accordingly. At the operator's option, SIDETRAK awards one extra game to any player who matches or exceeds the M score.

C. Game Play

When a player presses one of the two START buttons (after coinage), a fanfare tune signals the start of play. The player's train starts at the bottom center of the screen (in the outer track) and moves counter-clockwise. The killer engine starts in the center of the screen, moving in the same direction.

The killer engine tries to crash into the player's train. The player must avoid crashes by changing tracks at interchanges. The player uses the FAST button to reach an interchange before the killer engine.

At game start, each player gets one car at the beginning of his train. When passengers are picked up by the train, a bell rings and the passengers disappear. When one car is attached to the train, the player gets 10 points for picking up passengers on the outside of the track. An additional 10 points are added each time passengers are picked up from a track closer to the center. For example, picking up passengers on the outer track, which is the fourth track from the center, 10 points are scored; 20 points are given for passengers picked up on the third track from the center; the second track from the center nets 30 points; the closest track to the center brings 40 points; and passengers picked up from the center track bring the highest score of 50 points.

Each time the player passes START on the outside track, another car is added to the train. For each car that is added, points are increased as passengers are picked up. For example, passengers picked up with a one-car train in the outermost track are worth 10 points. The same passengers picked up with two cars bring 20 points. Passengers picked up by three cars in the same outermost lane are worth 30 points, etc.

Play continues until the player crashes into the killer engine. If the player succeeds in picking up all the passengers without crashing into the killer engine, the player is rewarded with a bonus round. The bonus round resets the playing field and the player is given the same number of cars and passengers that he had at the end of play. For example, if there were three cars containing passengers at the end of the successful game, then the same three cars and passengers would appear on the field to begin the bonus round.

II. SELECTABLE OPTIONS

SIDETRAK has three switch selectable options. These are controlled by a 8-position DIP switch located on the main logic board at position 16A. This switch is accessible from the front of the game though the coin door. Figure 1 shows all selectable functions controlled by the 8-position DIP switch.




Figure 1. Functions of the 8-position DIP Switch


Following are the switch settings for the selection of options:

A. COINAGE	Switch 4	Switch 3
2 Player - 1 Coin	ON	ON
1 Player - 1 Coin	ON	OFF
2 Player - 2 Coin		
1 Player - 2 Coin	OFF	ON
2 Player - 4 Coin		
B. CRASHES (Turns)	Switch 2	Switch 1
2 Crashes	ON	ON
3 Crashes	ON	OFF
4 Crashes	OFF	ON
5 Crashes	OFF	OFF
C. TOP THIS SCORE	Switch 5	
Credit awarded for topping score	OFF	
Credit <u>not</u> awarded for topping score	ON	

III. AUDIO ADJUSTMENTS

The following is a diagram of the audio board adjustments.

SIDE TRAK AUDIO PCB. POT CONFIGURATION (ADJUSTMENTS)



FRONT (COMPONENT) SIDE VIEW

Figure 2. Audio Board Adjustments

IV. POWER SUPPLY ADJUSTMENTS

1. Connect a voltmeter to the +5 and ground traces on the logic board.
2. Adjust the power supply potentiometer for $+5.0 \pm .1$ VDC, Figure 3.




Figure 3. Power Supply Adjustment

V. MECHANICAL ASSEMBLIES

A. Servicing the Controls

Do the following to service the Controls:

1. Unplug the power cord.
2. Open and remove the back door.
3. From inside the cabinet, remove the three control panel nuts.
4. Open the coin door.
5. From the front of the cabinet, pull the control panel out and down; let it rest on the open coin door as shown in figure 4.
6. Check all terminal connections to the pushbuttons and the four-way control.




Figure 4. Control Panel


- | | |
|-----------------|--------------------|
| 1 Carriage bolt | 4 Control panel |
| 2 Start buttons | 5 Four-way control |
| 3 FAST button | 6 Control harness |

B. Servicing the Four-way Joy Stick

The four-way joy stick is mounted on the control panel with four long screws and standoff spacers. Four pairs of spring steel cup washers surround the control stick, between the control panel and the top plate (see Figure 5). These cup washers bear against a disk welded to the control stick, and push the stick towards its center (rest) position. Four leaf switches on the bottom plate (activated by the control stick) signal lane changes to the logic board.

Figure 5. Four-way Joy Stick

- | | |
|-----------------|-------------------|
| 1 Carriage bolt | 8 Kep nut |
| 2 Control stick | 9 Switch plate |
| 3 Control panel | (bottom plate) |
| 4 Flat washer | 10 Kep nut (small |
| 5 Cup washer | pattern) |
| 6 Spacer | 11 Leaf switch |
| 7 Lower disc | 12 Phillips screw |
| (top plate) | |



Do the following to service the Four-way Joy Stick:

1. Unplug the power cord.
2. Open the control panel.
3. Check the harness connectors to each leaf switch.
4. Check the throw of each microswitch; the control stick should activate, but not bottom-out against, each switch.
5. If necessary, adjust leaf switch throw by carefully bending the switch actuator with a long-nose pliers.

C. Removing the Monitor

To remove the monitor do the following:

1. Unplug the power cord.
2. Open and remove the back door or monitor access panel.
3. Unplug the harness connector from the monitor.
4. Remove the four bolts from the monitor chassis flange mounts.
5. Lift the monitor up and slide it out of the cabinet.

D. Removing the Logic and Audio Boards

To the following to remove the Logic and Audio Boards:

1. Unplug the power cord.
2. Open and remove the back door.
3. Disconnect the edge connector from the logic board.
4. Slide the boards out of their rack.

VI. PARTS LIST

Universal Power Supply PCB

PART #	QTY	DESCRIPTION
77-3190	1	printed circuit board
20-4000	4	4000 uf 50V axial lead cap
21-4010	2	33 uf 35V dip tantalum cap
21-4015	5	6.8 uf 35V dip tantalum cap
46-3016	2	60SI diode
47-3004	1	MDA 970-1 bridge rectifier
47-3041	1	2N3055 transistor
47-3011	1	2N6246 transistor
48-2337	1	7905T negative 5V LM320T-5 regulator
48-2217	1	7912T negative 12V LM320T-5 regulator
48-2338	1	7812T positive 12V LM340T-5 regulator
68-3041	2	thermalloy 6072 heat sink
68-2038	2	thermalloy 6015 heat sink
61-8010	1	12 pin male molex
74-2514	8	4-40 x 3/8 phillips pan head machine screw
74-5216	8	#4 flat metal washer
74-5191	8	#4-40 kep nut

Power Supply Assembly

PART #	QTY	DESCRIPTION
78-3001	1	+5VDC power supply 6 amp
63-4028	1	auxiliary transformer T911
77-3365-15	1	power supply PCB assy.
71-2389	1	power supply harness
76-1211-10	1	power supply mounting board (plywood baseplate)
74-3503	4	#6 x 1/2" L. phillips pan head self tap screw
74-5196	8	6-32 x 1/2" phillips pan head machine screw
74-3502	8	6-32 kep nut
74-3500	8	#6 American Standard plain washer

Speaker Assembly

PART #	QTY	DESCRIPTION	REFERENCE LOCATION
62-7061	1	6" x 9" oval speaker	cabinet
	2	3" brown 18 AWG insulated wire	speaker
61-8056	1	2 pin male molex connector	P14
61-8054	2	male molex pins	P14

Final Assembly

PART #	QTY	DESCRIPTION	REFERENCE LOCATION
76-1212-10	1	cabinet	
76-1212-20	1	cabinet door	
38-5054-10	1	control assy.	cabinet
38-5055-10	1	monitor assy.	cabinet
77-3361-15	1	universal game black and white logic PCB assy.	cabinet
77-3363-15	1	audio PCB assy.	logic PCB
38-5059	1	power supply assy.	cabinet
38-5057	1	make-from coin door assy.	cabinet
67-5000	1	lock and key assy.	back door
	2	coin door keys (w/Vendall coin door)	back door
	1	back door key (w/lock and key assy.)	back door
87-9003-00	1	packing list envelope (for keys)	back door
87-1062		plastic bag (for manual)	back door
35-3079	1	black paper bezel	cabinet cutout
35-3105-11	1	side artwork--left side	
35-3105-12	1	side artwork--right side	
12-3000	1	interlock switch	interior cabinet
74-0105	a/r	5/8 staples (chisel point)	harness
74-4601	6	#8 x 3/4 selftap phil. screw	PCB to cab. power to cab. monitor; spkr
74-5160	12	#10 American plain washer	
74-5165	14	1/4 I.D. x 1 1/4 D.D. fender washer	coindoor; monitor; control panel
74-6503	3	#10 external tooth lock washer	controls
74-6508	3	10/24 wing nut	controls, upper
74-6524	10	10/24 x 1 1/2 carriage bolt black full thread	speaker grill; control panel PCB; coin box lid
74-7001	3	6" tie wrap	
74-8501	3	#8 x 5/8 self tap phillips pan head	interlock, coin box
74-8502	3	#8 x 5/8 self tap phillips flat head	coinbox hasp
74-9301	4	10/32 kep nut	coin door
74-9302	15	10/24 kep nut	monitor, spkr, lower controls

Final Assembly (continued)

PART #	QTY	DESCRIPTION	REFERENCE LOCATION
74-9405	4	10/24 x 1 1/2 hex bolt	monitor
74-5148-12	1	display acrylic panel	cabinet front
68-0035-12	1	black oblong speaker grille 6" x 9"	front cabinet
68-6050-10	1	universal coin box	coinbox shelf
68-6050-20	1	universal coin box lid	coinbox shelf
68-7001	1	coinbox hasp	coinbox shelf
68-7010	1	interlock switch bracket	
83-0009	1	3 amp fuse label	inside cabinet
71-2392-10	1	main harness assy.	inside cabinet
71-2391-10	1	control harness assy.	inside cabinet
71-2390-10	1	coin harness assy.	inside cabinet
71-2389-10	1	power supply harness assy.	inside cabinet
38-5034-10	1	(make from) AC line cord harness assy.	inside cabinet

Control Panel Assembly

PART #	QTY	DESCRIPTION
68-2033-23	1	control panel
72-3022	2	push button switch
38-5068-10	1	control handle assembly
38-5044-10	1	Midway white pushbutton switch assy.
74-9411	4	10/24 x 1 1/2 carriage bolt
74-9302	4	10/24 kep nut

Monitor Assembly

PART #	QTY	DESCRIPTION
79-2304	1	19" monitor black and white w/o power supply

Universal Game Logic Black and White Assembly

PART #	QTY	DESCRIPTION	REFERENCE LOCATION
48-2000	2	IC 7400	3D, 15H
48-2005	2	IC 7402	1H, 6H
48-2010	5	IC 7404	1D, 3F, 4D, 10F, 11F
48-2015	1	IC 7407	2C

Universal Game Logic Black and White Assembly (continued)

PART #	QTY	DESCRIPTION	REFERENCE LOCATION
48-2020	1	IC 7408	5E
48-2332	1	IC 74LS11	3H
48-2035	1	IC 7420	2F
48-2316	2	IC 74LS21	12F, 15E
48-2045	1	IC 7427	7F
48-2055	1	IC 7432	6F
48-2067	2	IC 7474	1C, 5H
48-2071	2	IC 74LS112	2E, 6E
48-2307	2	IC 74LS138	5B, 5D
48-2321	2	IC 74LS139	7E, 16H
48-2090	2	IC 74157	14A, 14E
48-2095	4	IC 74161	1E, 2D, 4F, 5F
48-2100	3	IC 74166	12B, 12D, 13D
48-2115	4	IC 74193	10E, 12E, 13F, 15F
48-2328	9	IC 74LS241	1A, 3A, 3B, 4H, 6B, 7D, 9B, 9E, 15A
48-2350	4	IC 74LS245	3C, 4C, 6C, 15B
48-2314	3	IC 74LS374	1F, 14B, 7C
48-6502	1	6502 microprocessor	2A
48-2334	4	2114 (1K x 4) RAM	4A, 5A, 7B, 8B
	1	2716 EPROM (T.I.) (2K x 8)	9C
	3	2716 EPROM (T.I.) (2K x 8)	6A, 7A, 8A
	1	6341 PROM (512 x 8) (use w. hdwe. moving objects)	11D
	1	6331 PROM (32 x 8)	6C
	1	6331 PROM (32 x 8) (use w. hdwe. moving objects)	14H
	1	6301 PROM (256 x 4)	5C
46-3025	2	IN 4002 diodes	8F, 9E

1/4 w. 5% resistors:

59-5135	2	470 ohm	1D
59-5120	2	1.2K ohm	2C, 7H
59-5115	4	1.8K ohm	1C, 2C
59-5110	3	2.2K ohm	2A
59-5105	4	2.7K ohm	1C, 2C, 5H
59-5095	1	4.7K ohm	5H
59-5080	1	10K ohm	7H

1/4 w. 5% 8 pin resistors:

51-0003	1	220 ohm	9E
51-0002	1	2.2K ohm	16A
51-0001	1	4.7K ohm	15A

1/4 w. 5% 8 pin resistors: (continued)

51-0004	1	6.8K ohm	14A
23-4033	1	.01 uf ceramic capacitor	1D
23-4035	48	.1 uf ceramic capacitor	a/r
20-4011	4	6.8 uf 25 volt dip tant	1C,6E,15D,6H
20-4014	2	33 uf 25 volt dip tant	1C,2C
20-4005	1	470 uf 10 volt electrolytic	10H
72-3025	4	dip shunt jumpers 16 pin	4B,10B,10D,11B
72-3042	1	8 position dip switch	16A
45-3036	1	11.289 Mhz crystal	1D
61-8041	2	10 pin male molex	16C,16E
61-8062	5	16 pin low profile sockets	3E,4E,5C,6C, 14H
77-3361-14	1	printed circuit board	
61-8045	11	24 pin low profile sockets	5A-12A,9C,10C, 11D
61-8035	1	40 pin low profile socket	2A

Universal Make-From Coin Door Assembly

PART #	QTY	DESCRIPTION
66-4003-10	1	Vendall standard double coin door (use with all
	or	acceptors except British and Australian)
66-4003-20	1	Vendall large (British, Australian) double coin
		door (use with British and Australian only)
66-4005-10	2	twenty-five-cent American Vendall coin acceptor
	or	
66-4005-20	2	one hundred Japanese yen Vendall coin acceptor
	or	
66-4005-30	2	one Deutschmark German Vendall coin acceptor
	or	
66-4005-40	2	one franc French Vendall coin acceptor
	or	
66-4005-50	2	five francs Belgian Vendall coin acceptor
	or	
66-4005-60	2	twenty-five-cent Canadian Vendall coin acceptor
	or	
66-4004-10	2	ten pence British Vendall coin acceptor
		(use with large door only)
	or	
66-4004-20	2	twenty-cent Australian Vendall coin acceptor
		(use with large door only)

Audio Assembly

PART #	QTY	DESCRIPTION	REFERENCE LOCATION
48-2321	1	74LS139	1D
48-2314	2	74LS374	2C, 2D
48-2071	1	74LS112	3D
48-2308	5	74LS161	1A, 2A, 3A, 1B, 3B
48-2210	1	72748 (T.I.)	6D
48-2342	1	LM324	5B
48-2215	1	NE566	4B
48-2212	1	NE556	5A
48-2221	1	MC3340	4A
48-2211	1	LM379 (Dual 6W audio amp)	6A
48-2015	2	7407	4C, 4D
48-2302	2	74-LS04	1C, 3C
47-3005	5	2N3904	Q1-Q5
46-3030	4	1N4454	CR1-CR4
54-5021	1	100K pot	R35
54-5019	6	10K pot	R1, R10, R22, R23, R29, R38

1/4 w. resistors:

59-5070	8	22K	R6, R20, R30, R19, R31, R32, R36, R37
59-5125	4	1K	R7, R33, R40, R45
59-5163	1	820K	R41
59-5025	5	1 Meg	R9, R16, R17, R42, R47
59-5055	1	47K	R43
59-5080	5	10K	R8, R12, R36, R46, R48
59-5140	1	100 ohm	R44
59-5086	2	6.8K	R11, R134
59-5069	2	120K	R4, R24
59-5115	1	1.8K	R5
59-5050	1	68K	R3
59-5120	2	1.2K	R2, R25
59-5095	2	4.7K	R21, R49
59-5045	2	100K	R28, R15
59-5040	1	150K	R26
59-5030	1	560K	R27
59-5065	2	33K	R18, R39
59-5102	1	3.9K	R14

ceramic disk capacitors

23-4030	2	.22 uf	C41,C44
23-4035	9	.1 uf	C9,C12,C17, C31,C32,C34, C37,C42,C43
23-4070	1	22 pf	C45
23-4060	2	.001 uf	C11,C13
23-4045	2	.02 uf	C26,C28
23-4050	18	.01 uf	C1-4,C6-8,C16, C18,C23-25, C27,C29,C30, C33,C38,C39

dipped tantalum capacitors:

21-4015	8	6.8 uf	C14,C21,C22, C36,C40,C46, C47,C50
21-4020	2	2.2 uf	C48,C49
21-4010	2	33 uf 25V	C19,C20
22-4025	4	.47 uf 25V	C5,C10,C35,C15
61-8042	2	10 pin female connector	J2,J3
68-3041	1	thermalloy 6072 heat sink (for use <u>only</u> with LM379)	6A
74-2506	2	4-40 x 1/4" machine screw	6A (heat sink)
72-3025	1	DIP package shunt (16 pin) (AMP p/n 435704-8)	6B
48-9111-01	1	6331 PROM (program # STA 2B-1)	2B
74-5075	4	6-32 x 1/2" nylon standoff	between logic and audio bds.
77-3363-14A1	1	SIDE TRAK (bare) PCB	
74-3505	8	6-32 x 1/4" machine screw	in standoffs

Universal All-Postion Joystick Control

PART #	QTY	DESCRIPTION
68-9027-10	1	upper mounting plate
92-1013-10	1	control handle
68-2031-10	1	lower disc
68-2030-10	1	switch plate
72-3023	4	microswitch
73-9081	8	Belleville spring washer
74-5189	8	#4-40 x 2 1/2 lg. phillips pan head screw
74-6525	4	#10-24 x 2 1/2 lg. flat head screw
74-6510	4	#10-3/8 lg. spacer
74-5212	4	#10-1 1/2 lg. spacer
74-6520	4	#10-24 kep nut (small pattern)
74-5160	8	#10 flat washer

Push Button Assembly

PART #	QTY	DESCRIPTION
68-0008-11	1	push button bracket
68-0008-21	1	push button bracket
72-3040	1	push button switch--white
72-3053	1	leaf switch
72-3033	1	leaf switch
72-2815	2	#2-56 UNC-2B threaded pan head screw x .25 lg.
72-2816	2	#4-40 UNC-2B threaded pan head screw x .375 lg.







AC Line Cord Harness Assembly

PART #	QTY	DESCRIPTION	REFERENCE LOCATION
71-2070	1	AC line cord	PL1
60-6020	1	fuse holder	F1
60-6001	1	fuse 3 amp slow blow	F1
61-8048	1	3 pin molex receptacle	J1
61-8055	3	individual female pins	J1
88-4002	1	small tie wrap	
61-8051	2	fast-on push on terminals .1875"	E1-E2
61-8072	1	TFB butt splice	E3

Universal Power Supply PCB

PART #	QTY	DESCRIPTION
77-3190	1	printed circuit board
20-4000	4	4000 uf 50V axial lead capacitor
21-4010	2	33 uf 35V dipped tantalum capacitor
21-4015	5	6.8 uf 35V dipped tantalum capacitor
46-3016	2	60S1 diode
47-3004	1	MDA 970-1 bridge rectifier
47-3041	1	2N3055 transistor
47-3011	1	2N6246 transistor
48-2337	1	7905T negative 5V LM320T-5 regulator
48-2217	1	7912T negative 12V LM320T-12 regulator
48-2338	1	7812T positive 12V LM340T-12 regulator
68-3041	2	thermalloy 6072 heat sink
68-2038	2	thermalloy 6015 heat sink
61-8010	1	12 pin male molex
74-2514	8	4-40 x 3/k phillips pan head machine screw
74-5216	8	#4 flat metal washer
74-5191	8	#4-40 kep nut

REVISIONS			
ZONE	LTR	DESCRIPTION	DATE
1	1		12-1-77



QTY	CODE	PART OR IDENTIFYING NO	NOMENCLATURE OR DESCRIPTION
REQD	IDENT		
PARTS LIST			
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE FRACTIONS DECIMALS ANGLES XXX .			
MATERIAL		CONTRACT NO	APPROVALS DATE
FINISH		DRAWN E JV	3/07/77
NEXT ASSY USED ON		CHECKED E JV	3/13/77
APPLICATION		DO NOT SCALE DRAWING	
SIZE		CODE IDENT NO	DRAWING NO
D			77-3361-11
SCALE			SHEET OF 8


VA9	15	11	VD7
VA8	16	12	VD6
VA7	17	13	VD5
VA6	1	14	VD4
VA5	2		
VA4	3	2114	
VA3	4	13C	
VA2	5		
VA1	6		
VA0	7		
CSCG1	8		
GSWR	11		












VA9	15	11	VD7
VA8	16	12	VD6
VA7	17	13	VD5
VA6	1	14	VD4
VA5	2		
VA4	3	2114	
VA3	4	14C	
VA2	5		
VA1	6		
VA0	7		
CSCG2	8		
GSWR	11		

VA9	15	11	VD3
VA8	16	12	VD2
VA7	17	13	VD1
VA6	1	14	VDO
VA5	2		
VA4	3	2114	
VA3	4	11C	
VA2	5		
VA1	6		
VA0	7		
CSCG1	8		
GSWR	11		





VA9	15	11	VD3
VA8	16	12	VD2
VA7	17	13	VD1
VA6	1	14	VDO
VA5	2		
VA4	3	2114	
VA3	4	12C	
VA2	5		
VA1	6		
VA0	7		
CSCG2	8		
GSWR	11		

UNIVERSAL GAME BOARD V2.0			
SCALE:	APPROVED BY:	DESIGNED BY:	
DATE: 12-4-79	AKS	REVIEWED:	
3 OF 8		77-3361-11	










EXIDY INC.		
SCALE	APPROVED BY	DRAWN BY
DATE 12-14-79	REVISED	
UNIVERSAL GAME BOARD V2.0		
CPU ROM		
50F8	DRAWING NUMBER 77-3361-11-A2	



SCALE:	APPROVED BY:	DESIGNED BY:
DATE: 12-20-79	ORR	REVIEWED:
UNIVERSAL GAME BOARD V2.0		
MOVING OBJECT POSITION COUNTERS		
6 OF 8	DESIGNED BY:	77-3361-11-A




EXIDY INC.	
SCALE	APPROVED BY <i>AKG</i>
DATE: 12-11-77	DRAWN BY: <i>h/alt</i> REVISED
SIDE TRACK AUDIO	
1 OF 2	DRAWING NUMBER 77-5363-11-A



SIDE TRAK MAIN HARNESS
SCHEMATIC
(UNIVERSAL MAIN HARNESS)

LOGIC BD.

J1 (NOTE 4)




1. All under 18 may, considered
as the minimum specified
2. 18-24 1/2 years, 25-34 3 years
35-44 4 years, 45-54 5 years
55-64 6 years, 65-74 7 years
75-84 8 years, 85-94 9 years
95-104 10 years, 105-114 11 years
115-124 12 years, 125-134 13 years
135-144 14 years, 145-154 15 years
155-164 16 years, 165-174 17 years
175-184 18 years, 185-194 19 years
195-204 20 years, 205-214 21 years
215-224 22 years, 225-234 23 years
235-244 24 years, 245-254 25 years
255-264 26 years, 265-274 27 years
275-284 28 years, 285-294 29 years
295-304 30 years, 305-314 31 years
315-324 32 years, 325-334 33 years
335-344 34 years, 345-354 35 years
355-364 36 years, 365-374 37 years
375-384 38 years, 385-394 39 years
395-404 40 years, 405-414 41 years
415-424 42 years, 425-434 43 years
435-444 44 years, 445-454 45 years
455-464 46 years, 465-474 47 years
475-484 48 years, 485-494 49 years
495-504 50 years, 505-514 51 years
515-524 52 years, 525-534 53 years
535-544 54 years, 545-554 55 years
555-564 56 years, 565-574 57 years
575-584 58 years, 585-594 59 years
595-604 60 years, 605-614 61 years
615-624 62 years, 625-634 63 years
635-644 64 years, 645-654 65 years
655-664 66 years, 665-674 67 years
675-684 68 years, 685-694 69 years
695-704 70 years, 705-714 71 years
715-724 72 years, 725-734 73 years
735-744 74 years, 745-754 75 years
755-764 76 years, 765-774 77 years
775-784 78 years, 785-794 79 years
795-804 80 years, 805-814 81 years
815-824 82 years, 825-834 83 years
835-844 84 years, 845-854 85 years
855-864 86 years, 865-874 87 years
875-884 88 years, 885-894 89 years
895-904 90 years, 905-914 91 years
915-924 92 years, 925-934 93 years
935-944 94 years, 945-954 95 years
955-964 96 years, 965-974 97 years
975-984 98 years, 985-994 99 years
995-1004 100 years, 1005-1014 101 years
1015-1024 102 years, 1025-1034 103 years
1035-1044 104 years, 1045-1054 105 years
1055-1064 106 years, 1065-1074 107 years
1075-1084 108 years, 1085-1094 109 years
1095-1104 110 years, 1105-1114 111 years
1115-1124 112 years, 1125-1134 113 years
1135-1144 114 years, 1145-1154 115 years
1155-1164 116 years, 1165-1174 117 years
1175-1184 118 years, 1185-1194 119 years
1195-1204 120 years, 1205-1214 121 years
1215-1224 122 years, 1225-1234 123 years
1235-1244 124 years, 1245-1254 125 years
1255-1264 126 years, 1265-1274 127 years
1275-1284 128 years, 1285-1294 129 years
1295-1304 130 years, 1305-1314 131 years
1315-1324 132 years, 1325-1334 133 years
1335-1344 134 years, 1345-1354 135 years
1355-1364 136 years, 1365-1374 137 years
1375-1384 138 years, 1385-1394 139 years
1395-1404 140 years, 1405-1414 141 years
1415-1424 142 years, 1425-1434 143 years
1435-1444 144 years, 1445-1454 145 years
1455-1464 146 years, 1465-1474 147 years
1475-1484 148 years, 1485-1494 149 years
1495-1504 150 years, 1505-1514 151 years
1515-1524 152 years, 1525-1534 153 years
1535-1544 154 years, 1545-1554 155 years
1555-1564 156 years, 1565-1574 157 years
1575-1584 158 years, 1585-1594 159 years
1595-1604 160 years, 1605-1614 161 years
1615-1624 162 years, 1625-1634 163 years
1635-1644 164 years, 1645-1654 165 years
1655-1664 166 years, 1665-1674 167 years
1675-1684 168 years, 1685-1694 169 years
1695-1704 170 years, 1705-1714 171 years
1715-1724 172 years, 1725-1734 173 years
1735-1744 174 years, 1745-1754 175 years
1755-1764 176 years, 1765-1774 177 years
1775-1784 178 years, 1785-1794 179 years
1795-1804 180 years, 1805-1814 181 years
1815-1824 182 years, 1825-1834 183 years
1835-1844 184 years, 1845-1854 185 years
1855-1864 186 years, 1865-1874 187 years
1875-1884 188 years, 1885-1894 189 years
1895-1904 190 years, 1905-1914 191 years
1915-1924 192 years, 1925-1934 193 years
1935-1944 194 years, 1945-1954 195 years
1955-1964 196 years, 1965-1974 197 years
1975-1984 198 years, 1985-1994 199 years
1995-2004 200 years, 2005-2014 201 years
2015-2024 202 years, 2025-2034 203 years
2035-2044 204 years, 2045-2054 205 years
2055-2064 206 years, 2065-2074 207 years
2075-2084 208 years, 2085-2094 209 years
2095-2104 210 years, 2105-2114 211 years
2115-2124 212 years, 2125-2134 213 years
2135-2144 214 years, 2145-2154 215 years
2155-2164 216 years, 2165-2174 217 years
2175-2184 218 years, 2185-2194 219 years
2195-2204 220 years, 2205-2214 221 years
2215-2224 222 years, 2225-2234 223 years
2235-2244 224 years, 2245-2254 225 years
2255-2264 226 years, 2265-2274 227 years
2275-2284 228 years, 2285-2294 229 years
2295-2304 230 years, 2305-2314 231 years
2315-2324 232 years, 2325-2334 233 years
2335-2344 234 years, 2345-2354 235 years
2355-2364 236 years, 2365-2374 237 years
2375-2384 238 years, 2385-2394 239 years
2395-2404 240 years, 2405-2414 241 years
2415-2424 242 years, 2425-2434 243 years
2435-2444 244 years, 2445-2454 245 years
2455-2464 246 years, 2465-2474 247 years
2475-2484 248 years, 2485-2494 249 years
2495-2504 250 years, 2505-2514 251 years
2515-2524 252 years, 2525-2534 253 years
2535-2544 254 years, 2545-2554 255 years
2555-2564 256 years, 2565-2574 257 years
2575-2584 258 years, 2585-2594 259 years
2595-2604 260 years, 2605-2614 261 years
2615-2624 262 years, 2625-2634 263 years
2635-2644 264 years, 2645-2654 265 years
2655-2664 266 years, 2665-2674 267 years
2675-2684 268 years, 2685-2694 269 years
2695-2704 270 years, 2705-2714 271 years
2715-2724 272 years, 2725-2734 273 years
2735-2744 274 years, 2745-2754 275 years
2

ST 30 - 2157


11-6-59

SIDE TRAK
CONTROL PANEL HARNESS
SCHEMATIC



- NOTES:
1. All wires 22 awg. insulated unless otherwise specified.
 2. ABSOLUTELY NO SUBSTITUTIONS
ON SPECIFIED WIRE COLORS

SIDE TRAK
COIN HARNESS SCHEMATIC
(UNIVERSAL COIN
HARNESS)



- NOTES:
1. All wires 22 awg. insulated unless otherwise specified.
 2. ABSOLUTELY NO SUBSTITUTIONS ON SPECIFIED WIRE COLORS

ST 30-3189

11-6-79