


ATARI[®] 5200[™]

RealSports[™] TENNIS



Atari welcomes your comments.
Please address all correspondence to:

Atari Inc.
Customer Relations
1312 Crossman Avenue
Sunnyvale, California 94086

Insert your 5200™ game cartridge so the label faces you and reads right-side-up. Be sure the cartridge is firmly seated in the center of the console, but do not force it. Then press the **POWER** switch on. **See your Owner's Manual for further details.**



TABLE OF CONTENTS

1. Match Point	1
2. Game Play	2
3. Using the 5200™ Controller	3
4. Atari Trak-Ball™ Controller Option	6
5. Scoring	6
6. Game Variations	7
7. RealSports™ TENNIS Glossary	8



Serve

1. MATCH POINT

It's your serve, the score is 6-5. If you take this point, the match is yours.

It's been a long hot afternoon at center court. Your opponent's striking forehand has given you difficulty all day. To top it off, he has a thunderbolt serve and a cruel overhead smash. Maybe you can beat him on stamina by running him around the court until he drops.

Every seat in the stadium is filled with tense and anxious fans. You nervously bounce the ball two or three times to relieve the tension. You're ready for the serve...he returns it with a forehand dropshot. You can't let this point get away. Like lightening, you mentally pinpoint where your next shot will go; and then execute it by driving the ball down the sideline.



'em up!



The crowd's with you; they groan as your opponent saves the ball with a driving forehand, forcing you back to the baseline. Quickly rethinking your strategy, you hit a defensive lob. Your opponent returns it with one of his classic smashes to your backhand. But this time, you're ready! You whip

a passing shot down the sideline to his backhand. He lunges for it—but not far enough. The crowd cheers as the ball whizzes past his astonished face.

The point is yours; you take the match!

2. GAME PLAY

The object of ATARI RealSports TENNIS is to score enough points to win a match. A match is the best of three sets. (See *Section 5, SCORING for games, sets, and matches.*)

Choose from three game variations: singles against the computer, singles between two players, or doubles in which each team has one human player and one computer player.

You can also choose between two skill levels—INTERMEDIATE or ADVANCED. In advanced games, the ball travels faster than in intermediate games.

At the end of each game, the receiver becomes the server, and the server becomes the receiver. The players also change ends of the court after every odd-numbered game.



3. USING THE 5200™ CONTROLLER

Use your 5200 controllers with this ATARI game cartridge. Plug the controller into jack 1 for one-player games; plug a second controller into jack 2 for two-player games.

KEYPAD OVERLAYS

For your convenience, two keypad overlays are included with this game. Slip the tabs into the slots above and below the keypad on your controller (see *Figure 2*).

When not in use, your keypad overlays can be stored on the back of your game cartridge. Simply slip the tabs into the slots provided on the cartridge.

CONTROLLER ACTION

After inserting the cartridge and turning the console POWER on, the program displays a selection screen.

GAME SELECTION

Press the left * key to select an automated game (the square marked AUTOMATED on your overlay). An automated game allows you to play with either one or two computer players. (See Section 6, GAME VARIATIONS for automated games.)



Figure 1 - 5200 Controller



Figure 2 - Keypad Overlay

Press the right # key to choose an intermediate or advanced game (the square marked SKILL LEVEL on your overlay).

PLAYER SELECTION

Press the O key to choose the number of players (the square marked NUMBER OF PLAYERS on your overlay). Press the key until the desired number of players appears on the court. All doubles games require two human players; one for each team.

PLAYER NAMES

Personalize your tennis match by programming your name into the scoreboard at the upper left corner of the screen. First use the top fire button to place the cursor (blinking square) over the P. Then press the lower fire button to cycle through the alphabet until you reach the desired letter. When you've reached the correct letter, simply press the top fire button and the cursor will move to the next letter. When you have completed your name, cycle through the alphabet until you find the "blank space". Then program blank spaces until you've entered a total of seven characters. Each player uses his own controller to personalize the scoreboard (see *Figure 3*).



Figure 3

START

Press **START** when you're ready to begin playing. If you don't make a specific selection, the program automatically sets to an **AUTOMATED INTERMEDIATE** game for one player. When a game ends, press **START** to begin the same game variation again.

PAUSE

Press **PAUSE** to suspend the game in progress. **PAUSE MODE** will appear at the top of the screen and all action will freeze instantly. Press **PAUSE** again to continue game play.

RESET

During game play, press **PAUSE** (**PAUSE MODE** must appear on the screen) and then **RESET** to return to the selection screen. **ALL players' names will be erased** when the program is reset.

SERVING AND RETURNING THE BALL

The server has a choice of serving to the opponent's forehand or backhand. Press the upper fire button to serve to your opponent's backhand; press the lower fire button to serve to your opponent's forehand. The player using the controller plugged into jack 1 serves first. Once the ball is in play, use your joystick to maneuver your player around the court.

IMPORTANT: To stop your player, return your joystick to the up-right center position.

Choose your strategy before returning the ball by selecting your desired target area on the court. Each half of the court is divided into nine target areas (see **Figure 4**). Both the top half and the bottom half are numbered from left-to-right and correspond exactly to the numbers on your keypad. Whether you are playing the top or the bottom half of the court, you view the target areas as shown in **Figure 4**.

To program your return, press the button (numbers 1 through 9) that corresponds to the area where you want to place the ball. If you don't select a target area, a groundstroke will automatically be made to area 5.




Figure 4 – Target Areas

To select a lob shot, press **O** during game play. But watch out, the computer player can smash a lob so fast, you won't be able to return it.

Here are a few suggestions for using your joystick controllers along with your keypad:

- Place the controller on your lap; keep one hand on the joystick and the other hand on the keypad. Use either hand to press the fire buttons for serving the ball.
- Try keeping your fingers over the keypad like a 10-key adding machine, or just use your thumb or one finger to press the keys.
- If you have large hands, try to maneuver the joystick with your thumb. This will free your other hand to place your shot.

4. ATARI TRAK-BALL™ CONTROLLER OPTION

This RealSports TENNIS cartridge offers an ATARI TRAK-BALL option which may be purchased separately (available in mid-1983). The TRAK-BALL can be plugged into either jack at the front of the console. (Follow the instructions in Section 3, USING THE

5200 CONTROLLER for player and game selection, and using the keypad). Move your TRAK-BALL in the direction you want your player to move on the court. See your TRAK-BALL owner's manual for further details.

5. SCORING

You score points in ATARI RealSports TENNIS as you would in real tennis.

0 (ZERO)	= Love
Point 1	= 15
Point 2	= 30
Point 3	= 40
Point 4	= Game (not shown on screen)

The first player to win a fourth point wins the game. However, if both players score 3 points (40 each), the score is DEUCE. After deuce, the next point scored is called advantage. If that point

is scored by the server, the screen displays AD IN. If that point is scored by the receiver, the screen displays AD OUT. To win a game, you must have a two-point lead.

The first player to win six games wins a set, provided that the winner has a two-game lead. The player to win two out of three sets wins the match. If, at the end of a set, the score is 6-all, the players compete in a tie-breaker; they alternate serves until one player wins at least seven out of twelve points. The winner of the tie-breaker must have a two-point lead to win the set.



Scores are displayed at the top of the screen; player 1's score is displayed above player 2's score. The game score is displayed at the upper right; the set score is displayed at the upper left. (See *Figure 5* for scores.)

How points are scored:

- The server wins a point if, for any reason, the opponent fails to return the ball.
- The receiver scores a point when the server fails to return the ball.



Figure 5

6. GAME VARIATIONS

There are three game variations and two skill levels in this ATARI RealSports TENNIS game.

One-Player Singles (AUTOMATED)	One player challenges the computer to a tennis match.
Two-Player Singles	Two players vie for the match.
Two-Player Doubles (AUTOMATED)	Two players each team-up with a computer player for a game of doubles. You must select the desired target area for your computer teammate.

SKILL LEVELS

INTERMEDIATE

An average game of tennis, which requires a basic knowledge of tennis rules and strategy.

ADVANCED

A faster than average game of tennis in which the ball travels faster, and the emphasis is on strategy and quick moves.

7. RealSports™ TENNIS GLOSSARY

	
ACE:	A point earned by serving a ball which cannot be returned by the opponent.
AD:	Short for advantage. A point won after a score of deuce. If the same player wins the next point, he wins the game. If he loses the next point, the score returns to deuce.
BACKHAND:	A stroke made with the hitting arm and the racket across the front of the body and the back of the hand facing the direction the ball is to go.
DEUCE:	A tie after each player has a score of 40. To win a deuce game, a player must score two consecutive points.
DINK:	A soft shot that falls just over the net.
FOREHAND:	A stroke made with the palm of the hand facing the direction the ball is to travel.
GROUND STROKE:	Hitting the ball after it bounces.
LOB:	A stroke that sends the ball high in the air, over the opponent's head, and lands in the backcourt.
MATCH:	In ATARI RealSports TENNIS, the best two out of three sets.
OVERHEAD:	Hitting the ball while it is in the air, above the head.
RUSH THE NET:	Running to the net in order to volley a return.
SMASH:	A hard overhand stroke.
VOLLEY:	Hitting the ball before it bounces.


ATARI
PROOF OF PURCHASE
RealSports™ TENNIS



Call toll-free:
(800) 672-1404 (in California)
(800) 538-8543 (Continental U.S.)

RealSports™ TENNIS



 A Warner Communications Company

ATARI, INC., Consumer Division
P.O. Box 427, Sunnyvale, CA 94086