Part I
Getting Started

Part II
Learning

Macintosh User's Guide

Part III
Reference

Part IV
Index

for Macintosh PowerBook 160 and 180 computers

Includes setup instructions and important health-related information

Apple Computer, Inc.

This manual and the software described in it are copyrighted, with all rights reserved. Under the copyright laws, this manual or the software may not be copied, in whole or part, without written consent of Apple, except in the normal use of the software or to make a backup copy of the software. The same proprietary and copyright notices must be affixed to any permitted copies as were affixed to the original. This exception does not allow copies to be made for others, whether or not sold, but all of the material purchased (with all backup copies) may be sold, given, or loaned to another person. Under the law, copying includes translating into another language or format.

You may use the software on any computer owned by you, but extra copies cannot be made for this purpose.

The Apple logo is a trademark of Apple Computer, Inc., registered in the U.S. and other countries. Use of the "keyboard" Apple logo (Option-Shift-K) for commercial purposes without the prior written consent of Apple may constitute trademark infringement and unfair competition in violation of federal and state laws.

© Apple Computer, Inc., 1992
20525 Mariani Avenue
Cupertino, CA 95014-6299
(408) 996-1010

Apple, the Apple logo, APDA, AppleLink, AppleShare, AppleTalk, ImageWriter, LaserWriter, LocalTalk, Macintosh, and StyleWriter are trademarks of Apple Computer, Inc., registered in the U.S. and other countries.

AppleColor, Apple Desktop Bus, Chicago, Finder, Disk First Aid, Monaco, PowerBook, System 7, and TrueType are trademarks of Apple Computer, Inc.

AppleCare is a service mark of Apple Computer, Inc., registered in the U.S. and other countries.

Adobe, Adobe Illustrator, and PostScript are trademarks of Adobe Systems Incorporated, registered in the United States. Adobe Photoshop is a trademark of Adobe Systems Incorporated.

AGFA is a registered trademark of Agfa-Gevaert, AG.

Classic is a registered trademark licensed to Apple Computer, Inc.

Exposure is a registered trademark of Preferred Publishers, Inc.

Helvetica and Times are registered trademarks of Linotype Company.

ITC Garamond is a registered trademark of International Typeface Corporation.

QMS is a registered trademark and ColorScript is a trademark of QMS, Inc.

QuarkXPress is a registered trademark of Quark, Inc.

SelectSet is a trademark of Miles, Inc., Agfa Division.

SuperPaint is a registered trademark of Aldus Corporation.

Tektronix is a registered trademark and Phaser is a trademark of Tektronix, Inc.

Simultaneously published in the United States and Canada.

Mention of third-party products is for informational purposes only and constitutes neither an endorsement nor a recommendation. Apple assumes no responsibility with regard to the performance or use of these products.

Contents

Preface How to Use This Book xiii

Radio and television interference xv

■ Part I *Getting Started With Your Computer* 1

Chapter 1 Setting Up Your Macintosh PowerBook 1

Setting up the computer 2

Step 1: Plug in the power adapter 2

Step 2: Open the display 3

Step 3: Turn on the computer 4

Trouble? 5

Installing system software 6

Continuing your work 7

What to do next 8

Your computer at a glance 9

Learning the basics 10

Before you begin 10

Finding the tour 11

Starting the tour from the hard disk 11

Starting the tour from a floppy disk 15

Turning the Powerbook on and off 17

Off 17

Sleep 18

On 19

On/off summary 19

When you turn on your computer 20

Restarting a computer that's already on 21

Restarting a computer that can't be turned on normally 21

Important care and safety instructions 23

⚠ Warning 23

▲ Caution 24

△ Important 25

Health concerns associated with computer use 26

Repetitive stress injuries 26

Arranging your work space and equipment 27

■ Part II *Learning Macintosh* 31

Chapter 2 Working on the Desktop 31

Use the trackball 32

Point 32

Click 33

Press 34

Drag 35

Choose a command 36

Giving orders to your computer 36

Open an icon 37

Look at the contents of a window 38

Make a window the active window 38

Make a window larger or smaller 40

Move the hidden contents of a window into view 42

Close a window 44

Move a window 45

What's on the desktop? 46

Using the keyboard 49

Chapter 3 Creating and Changing a Document 51

Open a program 52

Create a document 53

Save your work 53

Switch programs 54

Close a document 56

Two types of programs 57

Open a document 57

Change a document 58

Save your work so far 61

Taking a shortcut 62

Make more changes 62

Quit a program 64

Opening and closing documents and programs 65

Make a copy of a document 65

Change the name of an icon 66

Use the Trash 67

Chapter 4 Working With Disks 69

Insert a floppy disk 70

Floppy disks and hard disks 71

Initialize a disk 72

Copy the contents of a disk 74

Taking care of floppy disks 75

Take a floppy disk out of its drive 76

Protect the contents of disk 77

On your own: Install your programs 78

Throw away extra System Folders 79

Chapter 5 Learning More About Your Computer 81

Open the Battery desk accessory 82

Open the PowerBook control panel 82

Use Balloon Help 83

To turn off Balloon Help 84

Use Part III of this book 85

What next? 85

■ Part III *Macintosh Reference* 87

Chapter 6 Setting Up Your Programs 87

Installing or updating system software 87

Before you install 88

Installing system software 88

Installing customized system software 90

Starting up with a floppy disk 91

Installing your programs 92

Installing programs without a floppy disk drive 92

Checking for computer viruses 93

Working with several programs at a time 94

Finding out what programs are open 94

Switching programs 94

Hiding and showing windows on the desktop 94

Changing the amount of memory a program uses 95

Using the Scrapbook 96

Storing items in the Scrapbook 96

Copying items from the Scrapbook 96

Deleting items from the Scrapbook 96

Using a RAM disk 97
Creating a RAM disk 97
Erasing a RAM disk 98
Resizing or removing a RAM disk 98
Making a RAM disk the startup disk 99

Chapter 7 Power Management 101
Monitoring the battery charge level 101
Using the battery desk accessory 101
Responding to low-power messages 102
Recharging the battery 103
Recharging with the power adapter 103
Recharging with a recharger 105
Removing or replacing the battery 106
Maximizing battery life 107
Maximizing work time 108
Ways to conserve battery power 108
Adjusting the battery conservation settings 109
Using the battery conservation options 110

Chapter 8 Using Disks 113
Preparing a new disk for use 113
Initializing a hard disk 113
Initializing a floppy disk 115
Erasing a floppy disk 116
Designating a startup disk 116
Scanning order for startup disks 117
Protecting the information on a disk 117
Locking a floppy disk 117
Locking a file 118
Backing up your files 119
If you can't save files on a floppy disk 119
Ejecting a disk 120
If you can't eject a floppy disk 120
Caring for disks 121
Hard disk precautions 121
Testing and repairing disks 121
If a hard disk icon doesn't appear 121
Using Disk First Aid 122
Testing a hard disk 124

Chapter 9 Organizing Your Files 125

Straightening up your files 125
Using folders to organize your files 126
Creating and naming folders 126
Filing documents when you save them 127
Making items easier to find 128
Creating an alias 128
Installing an item in the Apple menu 129
Moving an item to the desktop 129
Finding an item 130
Finding an item by name 130
Finding an item using other criteria 131
Finding items that meet two criteria 133
Ways to use the Find command 132
Creating a template or stationery 134
Getting information about your files 135
Using the Info window 135
Using the View menu 136
Assigning a label to a file 136
Tips on transferring files 137

Chapter 10 Sound, Color, and Video 139

Setting the beep sound 139
Installing a sound 140
Removing a sound 141
Recording sounds 141
Displaying colors or grays 143
Changing the highlight color or gray 144
Changing the color of window borders 145
Changing the background pattern 146
Assigning a color to an icon 147
Changing the colors in the Label menu 148
Using more than one monitor 149
Using a second monitor for presentations 150
Controlling automatic screen dimming 151
Magnifying the screen image 152

Chapter 11 Adapting Your Computer to Your Own Use 155

Specifying which items you want opened at startup 156

Installing an item in the Apple menu 156

Installing files in the System Folder 156

Removing files from the System Folder 157

Changing the items in the Label menu 158

Setting the time and date 158

Setting a time for the Alarm Clock to go off 159

Turning the alarm off 160

Changing time and date formats 160

Changing the date format 161

Changing the time format 162

Changing number and currency formats 163

Adjusting the way the trackball or mouse works 164

Adjusting the way the keyboard works 165

Making keyboard shortcuts easier to type 166

Adjusting the keyboard for very slow typing 166

Adjusting the blinking of a menu item 167

Adjusting the blinking of the insertion point 167

Changing the way the contents of windows appear 168

Changing an icon 169

Turning off the Empty Trash warning 170

Managing memory 171

Checking memory use 171

Making the most of your memory 171

Adjusting the disk cache 172

Using hard disk space as memory 173

Turning on 32-bit addressing 174

Chapter 12 Printing 175

Before you print 175

Choosing a printer 175

Selecting Page Setup options 178

Updating printer software on networked computers 179

Printing your work 180

Printing the contents of a window or the desktop 181

Solutions to common printing problems 182

Controlling background printing 183

Working with fonts 184
Outline fonts and bitmap fonts 184
Installing fonts 185
Removing fonts 186
Transferring fonts to a LaserWriter printer 186
Finding out about available fonts 188
Other ways to use the LaserWriter Font Utility 188

Chapter 13 Using Your Computer on a Network 191

What networking offers 191
Setting up your computer on a network 192
Connecting to a network 193
Turning on AppleTalk 193
Naming your computer and its owner 194
Gaining access to files on shared disks 195
Before you begin 195
Connecting to a shared disk 195
Disconnecting from a shared disk 197
Connecting quickly to a shared disk 198
Connecting automatically when you start up 198
Reconnecting a PowerBook to shared disks 199
Working with files and folders on other computers 200
Creating a new folder on another computer 200
Changing your password 200
Giving folder ownership to someone else 201
Sharing your own files 202
How file sharing works 202
Turning file sharing on 202
Turning on guest access 203
Selecting a folder or disk to share 204
Naming a registered user 205
Setting a registered user's password 206
Naming a group of users 207
Seeing who's in a group 207
Selecting a user or group to share a folder or disk 208
Preventing specific users or guests from accessing your computer 209
Removing a user from a group 211
Removing a user or group from your list of registered users 211
Giving away ownership of a folder or disk on your computer 211
Turning file sharing off 212
Monitoring file-sharing activity 213

Disconnecting someone who is connected to your computer 213
Gaining access to your computer from another computer 214
Changing your password 215
Using access privileges 216
Understanding access privileges 216
Setting access privileges to folders and disks 217
Access privilege strategies 218
Working with privileges others have set 219
Checking your access privileges 220
Linking programs 220
Linking to a program on another computer 220
Disconnecting a program link 222
Allowing other people to link to your programs 222

Chapter 14 Expanding Your Computer System 225

Using SCSI devices 225
Installing software 226
Setting SCSI ID numbers 226
Checking that the SCSI chain is properly terminated 228
Connecting cables 229
Using your PowerBook as a SCSI disk 230
Connecting your computer as a SCSI disk 230
Simplifying the SCSI disk connection process 233
Using SCSI disk mode to reinstall system software 233
Drawing battery power in SCSI disk mode 234
Quitting SCSI disk mode 235
Using an external monitor 236
Connecting an external monitor 236
Activating the external monitor 238
Making the external monitor the main monitor 239
Working with an external monitor 240
Disconnecting an external monitor 241
Connecting a modem 242
Connecting a printer 243
Connecting a mouse or other ADB device 243
Using sound input and output devices 244
Built-in microphone 244
External microphone 244
Sound output devices 245
Adding memory to your computer 245

Chapter 15 Travel, Storage, and Service 247

Traveling with the PowerBook 247

Storing the PowerBook 248

Short-term storage (up to 2 weeks) 248

Long-term storage (more than 2 weeks) 249

Using the security feature 249

Service and support 249

If the PowerBook malfunctions or is damaged 249

How to get help 250

For more information about Macintosh computers 251

Macintosh user groups 251

Technical information 251

Quick Reference 253

Summary and Shortcuts 253

Shift-click 253

Working with icons 253

Working with windows 254

Working with menus 256

Keyboard shortcuts in the Finder and in directory dialog boxes 258

Troubleshooting 259

The PowerBook 259

SCSI devices 264

External monitors 265

Disk drives and disks 266

Modems 268

Printers 269

Networks 270

Application programs 272

Appendix A Keyboard and Character Sets 275

Using Caps Lock 276

Typing special characters and symbols 276

Appendix B Exchanging Disks and Files with MS-DOS Computers 279

Initializing a disk in MS-DOS format 279

Converting files to and from MS-DOS format 281

Other file-conversion options 283

Appendix C Map 285

Setting your location 285

Comparing locations 286

Finding a location 287

Adding or removing a location 288

Adding a location 288

Changing or removing a location 288

■ Part IV *Index 291*

How to Use This Book

This book has several parts.

- Chapter 1 explains how to set up your computer and learn how to use it.
- Chapters 2–5 are a tutorial designed for people who have not used a Macintosh computer before. If you are new to the Macintosh, you should read this section of the book before you start your own work.
- Chapters 6–15 contain reference information that will help you as you become more proficient with your computer. You can turn to these chapters for information about a particular topic.
- At the back of the book you'll find a troubleshooting section and an index.

Certain kinds of information are *not* included in this book.

- Information about modems. If your computer has a built-in modem, or if you purchase one later, you receive a separate modem manual with instructions for its use.
- Information about application programs. Your best source of information about a particular program is the set of books and disks that came with that program.
- Technical specifications for your PowerBook model. These are on a separate sheet in the box with your computer.

Turn now to Chapter 1 to set up your new PowerBook computer.

Welcome to Macintosh.

Radio and television interference

The equipment described in this manual generates, uses, and can radiate radio-frequency energy. If it is not installed and used properly—that is, in strict accordance with Apple's instructions—it may cause interference with radio and television reception.

This equipment has been tested and found to comply with the limits for a Class B digital device in accordance with the specifications in Part 15 of FCC rules. These specifications are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation.

You can determine whether your computer system is causing interference by turning it off. If the interference stops, it was probably caused by the computer or one of the peripheral devices.

If your computer system does cause interference to radio or television reception, try to correct the interference by using one or more of the following measures:

- Turn the television or radio antenna until the interference stops.
- Move the computer to one side or the other of the television or radio.
- Move the computer farther away from the television or radio.
- Plug the computer into an outlet that is on a different circuit from the television or radio. (That is, make certain the computer and the television or radio are on circuits controlled by different circuit breakers or fuses.)

If necessary, consult your authorized Apple dealer or an experienced radio/television technician for additional suggestions. You may find helpful the following booklet, prepared by the Federal Communications Commission: *Interference Handbook* (stock number 004-000-00345-4). This booklet is available from the U.S. Government Printing Office, Washington, DC 20402.

△ **Important:** Changes or modifications to this product not authorized by Apple Computer, Inc., could void the FCC Certification and negate your authority to operate the product.

This product was tested for FCC compliance under conditions that included the use of shielded cables and connectors between system components. It is important that you use shielded cables and connectors to reduce the possibility of causing interference to radios, television sets, and other electronic devices. For Apple peripheral devices, you can obtain the proper shielded cables from your authorized Apple dealer. For non-Apple peripheral devices, contact the manufacturer or dealer for assistance. △

Chapter 1

Setting Up Your Macintosh PowerBook

In this chapter

- Setting up your computer
- Installing system software
- Learning how to use your computer
- Turning the computer on and off
- Important care and safety instructions
- Being comfortable while you work

- **New Macintosh users:** If you have never used a Macintosh computer before, read this entire chapter. It explains how to set up your computer, learn how to use it, and turn it on and off.
- **New PowerBook users:** If you have used other Macintosh computers but are new to the PowerBook, follow the setup instructions that begin on the next page and then go to the section on turning the PowerBook on and off.
- **Experienced PowerBook users:** Skim this chapter for information that applies to your computer.

△ **Important:** No matter what your level of experience, please read the safety information in this chapter before beginning your own work. This information can help protect you and your computer equipment from possible harm. △

Setting up the computer

Step 1: Plug in the power adapter

Plugging in the power adapter recharges the computer's battery while you work. You should plug it in now in case the battery has drained during shipping and storage.

▲ **Warning:** Use only the power adapter that came with your PowerBook computer. Adapters for other electronic devices (including other portable computers) may look similar, but they may damage your computer. ▲

- **Plug the power adapter into a standard electrical outlet or power strip. Then plug the power adapter cable into the power adapter port (⎓) on the back panel of the computer.**



Step 2: Open the display

- **Slide the latch to the right and lift up the display.**



Position the display at a comfortable viewing angle. You can adjust the angle of the display at any time.



Step 3: Turn on the computer

- **Open the door to the back panel of your computer.**



- **Press the power button (⏻) to turn the computer on.**



You hear a tone when you turn on the computer. It takes the computer a moment to start up.

- If you see a blinking question mark on your screen, you need to install system software on the computer's hard disk. System software includes the programs the computer uses to start itself up. Continue with the section "Installing System Software."

- If you see the Macintosh desktop on your screen, the computer is ready to use. You do not need to install system software. Continue with the section "What to Do Next."



Trouble?

- *The computer made a sound, but you can't see anything on the screen.*

  Adjust the brightness (☼) and contrast (◑) controls until an image appears and the screen is easy to read.



- *Nothing happened when you pressed the power button.*

  Make sure the power adapter is firmly connected to both the computer and a power source. If the power adapter is plugged into a power strip, make sure the power strip is plugged in and turned on. Then try pressing the power button again.

Installing system software

System software is a set of programs that your computer uses to start up and operate. To install system software on your hard disk, follow these steps.

You do not need to install system software if you see the Macintosh desktop on your screen when you turn on the computer.

1. **Find the *Install Me First* disk provided with your computer. Insert the disk into the floppy disk drive (metal end first, label side up).**



After a few moments, you'll see the Welcome box of the Installer, the program that installs system software on your hard disk.

2. **Press the Return key on your keyboard to continue.**

The Easy Install dialog box appears. Easy Install puts the system software that you'll need right away onto your hard disk.

3. **Press the Return key again to start installing system software.**

Messages on your screen report how installation is progressing.

4. **When the computer prompts you, remove the *Install Me First* disk and insert the next disk the computer requests.**

During installation, the computer automatically ejects a disk it has finished with and requests the next disk it needs.

5. **Insert the remaining disks as the computer prompts you.**

6. **When you see a message reporting that installation was successful, press the Return key once more to quit the Installer program.**

If you see a message saying that installation was not successful, you need to try again. Follow the instructions on the screen.

Continuing your work

Next you see a message that asks whether you want to continue using your Macintosh. To continue working or to learn how to use the computer, use the trackball to choose Restart.

1. **Place the index and middle fingers of your dominant hand on the trackball and the thumb of the same hand on the lower trackball button. Don't press either button yet.**



2. **Roll the trackball around with your fingers.**

   Notice that the arrow (↖) on the screen moves in the direction that you roll the trackball. For example, rolling the trackball to the right moves the arrow to the right.

3. **Roll the trackball so the arrow rests over the word Restart.**

   Make sure that the tip of the arrow is inside the box with the word Restart.

continues ▶

4. **Press and release one of the trackball buttons.**

   Both buttons do the same thing.

   The screen darkens, you hear a sound, and then after a moment the Macintosh desktop appears on the screen.



If nothing happens, try clicking the word Restart again. Make sure that the tip of the arrow is inside the box with the word Restart.

What to do next

- If you have never used a Macintosh computer before, continue with the section “Learning the Basics.”
- If you have never used a PowerBook computer before, continue with the section “Turning the PowerBook On and Off.” This section contains information that can help you use your computer efficiently.
- If you are an experienced PowerBook user, you are ready to start your own work.

Your computer at a glance



Learning the basics

The PowerBook comes with a tour and a tutorial to help you start using your computer as quickly as possible.

- The *Macintosh Basics* tour teaches the most basic skills you need to master before you can use your computer.
- The tutorial section of this book (Chapters 2–5) reviews the basic skills taught in the tour, and teaches a few additional skills you'll find helpful as you become more proficient.

Take the *Macintosh Basics* tour first.

Before you begin

Make sure your computer is turned on. If the screen is dark, try the following steps in order until you see the Macintosh desktop on your screen.

1. **Adjust the screen brightness and contrast controls.**

   If you see the Macintosh desktop, skip to "Finding the Tour."

2. **Press any key on the keyboard (except Caps Lock).**

   Pressing a key wakes the computer if it was in sleep (a power-conserving state described later in this chapter). If you see the Macintosh desktop, skip to "Finding the Tour."

3. **Press the power button on the computer's back panel.**

   Pressing the power button turns the computer on if it was off. Continue with "Finding the Tour."

Finding the tour

Your *Macintosh Basics* tour may be on a floppy disk, or it may be on the computer's hard disk.

- If the Macintosh desktop appeared on the screen when you first turned on your computer, then the system software and the *Macintosh Basics* tour were installed on your computer's hard disk at the factory. Continue with the section "Starting the Tour From the Hard Disk."
- If you needed to install system software when you set up your computer (as described in the previous section of this chapter), then the *Macintosh Basics* tour is on a floppy disk in the box with your computer. Locate the disk and continue with the section "Starting the Tour From a Floppy Disk."

Starting the tour from the hard disk

1. **Roll the trackball to move the arrow over the picture labeled "Macintosh HD."**

   Make sure the tip of the arrow is over the picture, not over the words "Macintosh HD."



continues ▶

2. Being careful not to roll the trackball, press the trackball button twice in quick succession.

Now your screen should look like the picture following step 3. If it doesn't, try steps 1 and 2 again, paying special attention to the following:

- Make sure the tip of the arrow is touching the picture, not the words beneath it.
- Be sure to press the trackball button twice.
- Try pressing twice more quickly and be careful not to roll the trackball while you press.

3. Roll the trackball to move the arrow over the picture of the folder labeled "Macintosh Basics."

Make sure the tip of the arrow is over the picture, not over the words "Macintosh Basics."

The items in the illustration below may not exactly match those on your screen. The only item you need right now is the Macintosh Basics folder.



4. **Being careful not to roll the trackball, press the trackball button twice in quick succession.**

   Now your screen should look like the following illustration:



5. **Roll the trackball to move the arrow over the picture of the man labeled “Macintosh Basics.”**

   Make sure the tip of the arrow is over the picture of the man, not over the words “Macintosh Basics.”

continues ▶

6. **Press the trackball button twice in quick succession.**

   Now your screen should look like the following picture:



   If you don't see this screen, try again, paying special attention to the following:

   - Make sure the tip of the arrow is touching the picture, not the words beneath it.
   - Be sure to press the trackball button twice.
   - Try pressing twice more quickly and be careful not to roll the trackball while you press.

7. **Follow the instructions on the screen and work through the tour.**

When you finish the tour, continue with "Turning the PowerBook On and Off" and read the rest of this chapter for information that can help you use your computer safely and efficiently. Then turn to Chapter 2 and begin the tutorial.

Starting the tour from a floppy disk

1. **Insert the *Macintosh Basics* disk into the floppy disk drive (metal end first, label side up).**



After a moment, your screen should look like this:



continues ▶

2. **Roll the trackball to move the arrow over the picture of the man labeled “Macintosh Basics.”**

   Make sure the tip of the arrow is over the picture of the man, not over the words “Macintosh Basics.”



3. **Press the trackball button twice in quick succession.**

   Now your screen should look like the following picture:



   If you don’t see this screen, try again, paying special attention to the following:

   - Make sure the tip of the arrow is touching the picture, not the words beneath it.
   - Be sure to press the trackball button twice.
   - Try pressing twice more quickly and be careful not to roll the trackball while you press.

4. **Follow the instructions on the screen and work through the tour.**

When you finish the tour, read the rest of this chapter for information that can help you use your computer safely and efficiently. Then turn to Chapter 2 and begin the tutorial.

Turning the PowerBook on and off

Your Macintosh PowerBook can be in one of three power states: off, sleep, or on.

Off

When the PowerBook is off, the computer is not using any power or doing any work. The terms *shut down* and *off* both refer to this state.

You should turn the computer off to

- attach other equipment to it
- replace its battery
- conserve power when you won't be using it for several hours

To turn the PowerBook off

- If the computer is on, choose the Shut Down command from the Special menu. (The *Macintosh Basics* tour teaches how to choose a menu command.)

- If the computer is in sleep, wake it by pressing any key on the keyboard (except Caps Lock), and then choose Shut Down.

△ **Important:** Don't shut down with the power button (⏻) on the back panel of the computer unless a problem prevents you from choosing Shut Down. You will lose any work you did not save, and you may experience problems with your hard disk. △

Sleep

When the PowerBook is in sleep, it draws enough power to maintain the information in its memory (including any open programs and documents). The computer is on, but almost completely inactive.

You should put the computer to sleep to conserve power when you take a work break.

To put the PowerBook to sleep

- If the computer is on, choose the Sleep command from the Special menu.

- If the computer is off, you need to turn it on before you can put it to sleep.

Automatic sleep

If you don't use the computer for several minutes, it goes to sleep automatically. This conserves battery power. You will notice that if you spend several minutes reading without using the computer, or if you take a break, the screen may be dark when you're ready to resume working.

To wake the computer, press any key on the keyboard (except Caps Lock). The desktop reappears looking just the way it did before the computer went to sleep.

On

When the PowerBook is on, you can do your work.

To turn the PowerBook on

- If the computer is off, press the power button (⏻).



- If the computer is in sleep, press any key on the keyboard (except Caps Lock).

On/off summary

If the power state is	And you want it to be		
	Off	**Sleep**	**On**
Off	—	—	Press power button
Sleep	Press any key to wake, and then choose Shut Down	—	Press any key except Caps Lock (pressing the power button also works)
On	Choose Shut Down	Choose Sleep	—

See the chapter on power management for more information about managing your computer's power consumption.

When you turn on your computer

When you turn on your PowerBook, the computer looks on the hard disk inside the computer for the system software it uses to start itself up. (A disk that contains the system software is called a startup disk.) When the computer finds the system software, it displays the icon shown and proceeds to start itself up.

When the startup process is complete, the Macintosh desktop appears on the screen. The desktop is a gray pattern with

- a menu bar across the top (containing the names and icons of menus)
- an icon near the upper-right corner representing the startup disk
- an icon near the lower-right corner representing the Trash

When you “wake” your computer from sleep, it does not go through the startup process because it is already on (at a reduced power level). The Macintosh desktop reappears on the screen immediately, looking just the way it did before the computer went to sleep.

Restarting a computer that's already on

You need to restart your computer—turn it off and back on again immediately—when you want to make certain changes to your control panels, use a newly installed system software file, or start up the computer from a different disk.

- **Choose Restart from the Special menu.**

When you choose Restart, the computer prompts you to save your work, closes all open programs, and restarts itself.

Choosing Restart does not affect your RAM disk (if you created one) or its contents.

You also need to restart if you see a "system error" message on the screen (indicating a temporary software problem). In this case, use the trackball to click the Restart button that appears.

Restarting a computer that can't be turned on normally

If your system crashes (a rare event resulting from temporary software problems), or if a computer with a properly installed and charged battery does not respond when you try to turn it on, you should be able to restart it using one of the methods described in this section. Try them in the order given. All these methods will cause you to lose any work you have not saved.

- **Press and release the reset button.**

  You can press the button with a pen, a paper clip, or a similar object.

  Restarting the computer with the reset button does not affect your RAM disk (if you created one) or its contents.



continues ▶

- **Hold down the power button for 5 seconds.**

  When you let go, the computer turns itself off. Turning the computer off with the power button erases the contents of a RAM disk.

- **Restart from a floppy disk.**

  1. Insert the *Disk Tools* disk into the floppy disk drive.
  2. Press the power button.

  If the computer turns on, there is probably a problem with your hard disk. You may be able to fix the problem yourself (using the Disk First Aid program or another disk repair program; see the chapter on disks in the reference section). Or you can take the computer to your authorized Apple service provider.

- **If you have an Apple HDI-30 SCSI Disk Adapter cable, connect your PowerBook to a desktop Macintosh and start it up as a SCSI disk.**

  Your PowerBook can be connected to a desktop Macintosh and used as an external SCSI disk drive.

  The procedure has two parts. First you need to connect your computer to a desktop Macintosh. Then you need to reinstall system software on your computer's hard disk. Chapters 14 and 6, respectively, contain specific instructions.

Important care and safety instructions

For your own safety and that of your equipment, read and follow all the instructions in this section. Keep these instructions available for reference by you and others.

⚠ Warning

- Electrical equipment may be hazardous if misused. Operation of this product, or similar products, must always be supervised by an adult. Do not allow children access to the interior of any electrical product and do not permit them to handle any cables.
- Do not use the computer in or near water.
- Do not use cables that are frayed or otherwise damaged. Hold a cable by its connector (the plug, not the cord) when connecting or disconnecting it.
- Always handle batteries carefully.
- Do not drop, puncture, disassemble, mutilate, or incinerate the battery.
- Recharge batteries only as described in this manual and only in ventilated areas.
- Transport batteries either inside the computer or in the protective case provided with each battery. Do not transport unprotected batteries.
- Do not short-circuit the battery terminals (that is, do not allow a metal object such as a paper clip or key chain to touch the terminals). Doing so may cause an explosion or a fire.

▲ Caution

- If you have a problem with your computer and nothing presented in the manuals that came with the computer solves the problem, take the computer to your authorized Apple dealer or service provider. Attempting to repair the computer yourself may void the limited warranty. Contact your authorized Apple dealer or service provider for additional information about this or any other warranty question.
- Do not attempt to open the computer's case. There are no user-serviceable parts inside. Take the computer to an authorized Apple service provider if necessary.
- Do not drop or jar the computer.
- Do not move the computer when you can hear its hard disk spinning. When you put the computer to sleep, wait until the screen is blank before moving the computer.
- Use only the power adapter supplied with your computer. Adapters designed for other electronic devices may look similar, but they may not work with your equipment and may damage the computer.
- Never force a connector into a port. Make sure that the connector matches the port and that it's right side up. If the connector and port do not join easily, they do not match.

- Do not use the computer in wet or dusty environments.
- Keep dirt and liquids away from the ports on the back panel, the keyboard, and the trackball. If you spill any food or liquid onto the computer, shut it down immediately and unplug it before cleaning up the spill. Depending on what you spilled and how much got into the computer, you may have to bring the computer to an authorized Apple service provider for cleaning.
- Do not touch the screen with any sharp or pointed objects.
- Use only the battery supplied with your computer. Batteries designed for other portable computers may look similar, but they may not work with your computer and may damage it.
- When recharging the battery, use only the power adapter supplied with your computer. Adapters designed for other electronic devices may not work with your equipment and may damage the computer or the recharger.
- Do not leave batteries in hot locations (such as the trunk of a car).

△ Important

- If the computer has been in a cold place for several hours, let it warm up to room temperature before you use it.
- Use the computer only in environments where the temperature range is between 50°F/10°C and 104°F/40°C.
- Do not expose the computer to very low (less than –13°F/–25°C) or very high (more than 140°F/60°C) temperatures.
- If necessary, clean the outside surfaces of your computer equipment with a damp (not wet) cloth or paper towel.
- Clean the screen with soft, lint-free paper or cloth and a mild glass cleaner. Do not spray the glass cleaner (or any other liquid) directly onto the screen.

Health concerns associated with computer use

Muscle soreness, eye fatigue, and other discomforts and injuries sometimes associated with computer use can result from performing any number of activities. Misuse of the same muscles during multiple activities can create a problem that might not otherwise exist. For example, if you engage in nonwork activities that involve repetitive stress on the wrist—such as bicycling—and also use your computer's keyboard improperly, you may increase your likelihood of developing wrist problems. Preventing health problems requires careful attention to the way you use your body at all times.

The most common health effects associated with using a computer are musculoskeletal discomfort and eye fatigue. Any activity that involves sitting for long periods of time, including using a computer, can make your muscles sore and stiff.

To prevent discomfort and fatigue:

- Arrange your work space so the furniture is properly adjusted for you and doesn't contribute to an awkward, inappropriate working posture.
- Take frequent short breaks to give your muscles and eyes a chance to rest and refresh.

Repetitive stress injuries

Repetitive stress injuries (RSIs) can occur when a certain muscle or tendon is repeatedly overused and forced into an unnatural position. The exact causes of RSIs are not understood, but it is thought that awkward posture, the amount of repetition, the force used in the activity, and your physiology and lifestyle may all contribute to their occurrence.

One RSI often discussed in connection with computer use is a wrist problem called carpal tunnel syndrome, which may be aggravated by improper use of computer keyboards. This nerve disorder results from excessive pressure on the median nerve as it passes through the wrist to the hand. The information on the next few pages can help you recognize hand positions that may cause discomfort.

Since the effects of repetitive movement associated with computer use can be compounded by those of other work and leisure activities to produce or aggravate physical problems, proper use of your computer system must be considered just one element of a healthy lifestyle. No one can guarantee that you won't have problems even when you follow the most expert advice on using computer equipment. You should always check with a qualified health specialist if muscle, joint, or eye problems occur.

Arranging your work space and equipment

The suggestions in this section can help you work more comfortably with your computer.

Chair

Whenever possible, use an adjustable chair that provides firm, comfortable support.

- Adjust the height of the chair so your thighs are horizontal, your feet flat on the floor, and the backs of your knees slightly higher than the seat of your chair.
- The chair should support your lower back. Follow the manufacturer's instructions for adjusting the backrest.

Keyboard and trackball

- When you use the keyboard and trackball, your shoulders should be relaxed. Your upper arm and forearm should form a right angle, with your wrist and hand in roughly a straight line.



- Use a soft touch on the keyboard and keep your hands and fingers relaxed. Avoid rolling your thumbs under your palms.



- Change hand positions often to avoid fatigue.

- If you prefer, you can adjust the angle of the keyboard by rotating the elevation feet at both ends of the back panel until they snap into position.



The back of the keyboard is slightly elevated when the feet are in use. Otherwise, the keyboard is level.

Mouse

If you use a mouse, position it at the same height as your keyboard. When you slide the mouse, move your entire arm. Avoid resting your arm on the desk and bending your wrist as you move the mouse.

Built-in display

- Adjust the angle of the display to minimize glare and reflections from lights and windows. Make sure there is enough light to read the screen easily.
- You may need to adjust the brightness and contrast of the screen when you take the computer from one work location to another, or if the lighting in your work area changes.



- Clean the screen regularly (see “Important Care and Safety Instructions”).

External monitor

If you sometimes use an external monitor, these suggestions may be helpful.

- If possible, arrange the monitor so the top of the screen is at or slightly below your eye level while you're working. The best distance from your eyes to the screen is up to you, although most people seem to prefer 18 to 28 inches (45 to 70 cm).
- Position the monitor to minimize glare and reflections from lights and windows. You may want to use a monitor stand so you can adjust the viewing angle.

General suggestions

- Wherever you're working, take a moment to think about whether you feel comfortable, and change position if necessary.
- Occasionally rest your eyes. From time to time focus your eyes on a distant object, and blink often while you work.
- Some computer users may develop discomfort in their arms, wrists, or hands if they do intensive work without breaks. If you begin to develop chronic pain or discomfort in your arms, wrists, or hands, consult your health specialist.

Chapter 2

Working on the Desktop

In this chapter

Review basic trackball skills:

- Moving the pointer
- Choosing a command
- Opening an icon
- Looking at the contents of a window

And learn:

- How to close a window
- How to move a window
- What the icons on your desktop represent

Before you begin

You should have already

- set up your computer according to the instructions in Chapter 1
- gone through the *Macintosh Basics* tour supplied with your computer

Make sure your computer is on.

Use the trackball

Your computer has a two-button trackball. You use the ball itself to control the movements of a pointer on the screen. The pointer you'll see most often is an arrow (↖).



You use the buttons to initiate actions that you want the computer to perform. Both trackball buttons do the same thing. You can always use whichever one you prefer.

Much of the work you do on the Macintosh uses four trackball actions: pointing, clicking, pressing, and dragging.

(If you want to return to the *Macintosh Basics* tour for more practice with the trackball, see Chapter 1 for instructions.)

Point

You point to an object on the screen by rolling the trackball so the pointer is positioned over that object. When the pointer is an arrow, the *tip* of the arrow must be *exactly* over the object.



Practice pointing to different objects on the Macintosh desktop, such as the startup hard disk icon near the upper-right corner, the Trash icon near the lower-right corner, and the Help menu icon near the right end of the menu bar.

Click

You click an object on the screen by pressing and quickly releasing a trackball button while the pointer is over that object.



Practice clicking different objects on the Macintosh desktop, such as the startup hard disk icon near the upper-right corner and the Trash icon near the lower-right corner.

When you click an icon, it becomes *highlighted* (the icon is darkened). A highlighted icon is said to be *selected*. A selected icon is the object of whatever action you choose next.

Press

You press by holding down a trackball button without moving the trackball.



Practice pressing the menu names and icons in the menu bar—start with the Apple (apple) menu icon at the left side, through the menu names, and across to the Help and Application menu icons at the right side. Pressing a menu name or icon “pulls down” the menu. Read the items in each menu you pull down.



Drag

You drag an object on the screen by pointing to that object and holding down a trackball button while you roll the trackball.



Practice dragging the startup hard disk icon and the Trash icon around the Macintosh desktop. When you drag an icon, an outline of the icon follows the pointer on the screen. When you release the trackball button, the icon itself moves.



When you're finished practicing, drag the icons back to their original positions. Then click once in the middle of the desktop. (Clicking anywhere outside a selected icon returns that icon to its original "unselected" state.)

Choose a command

Choosing a command involves using a combination of the trackball actions you've reviewed.

1. **Point to the Special menu title in the menu bar.**
2. **Press to pull down the Special menu.**
3. **Drag to the first item in the menu (the Clean Up Desktop command) so it becomes highlighted, and then release the trackball button.**

When you choose Clean Up Desktop, the hard disk icon and the Trash return to their original positions (as long as they're already close).

Giving orders to your computer

Telling the Macintosh to do something involves two steps:

1. **selecting an object on the screen, and**
2. **choosing the action you want to perform on that object.**

When you select an object, you're telling the Macintosh to act upon that object.

The objects you can select include an icon on the Macintosh desktop, a sentence in a word-processing program, and a picture in a graphics program—to give just three examples.

Most of the actions you can perform on the selected object are listed in the menus at the top of the screen. The items, or actions, in the menus are called commands. When you choose a command, you are telling the computer to take the action you've chosen on the selected object.

So—you tell your Macintosh what to do by using a very simple "language" with only two kinds of words:

- nouns (the objects), and
- verbs (the actions)

and with only one rule:

- First the noun, then the verb (to this object, do that action). In Macintosh terms: select an object, then choose a command.

Open an icon

Opening an icon is your first exercise in telling the computer what you want it to do.

1. **Click the startup hard disk icon to select it.**

   The icon is in the upper-right corner of the screen. Unless someone has changed its name, the icon is called "Macintosh HD." Make sure that the icon is highlighted (darkened), which means that it's selected.

2. **Point to the File menu title in the menu bar.**
3. **Press to pull down the File menu.**
4. **Drag to the Open command (the second item in the File menu) so it becomes highlighted, and then release the trackball button.**



When you choose the Open command, the selected icon opens into a window (in this case, the Macintosh HD window). The icon becomes filled in with a pattern of dots, indicating that it has been opened.

❖ *Different icons?* The Macintosh HD window on your screen may contain items not shown above. The differences are not important; you can still do the exercises in this chapter and the next. ❖

Look at the contents of a window

Every window has several features that help you view the window's contents. But before you can work with the contents of a window, you need to make that window the active window.

Make a window the active window

You can have several windows open on your screen at one time, but only one window can be the active window. An active window is one in which you can select objects and choose actions to perform on those objects.

The Macintosh HD window is currently on your Macintosh desktop. (The window appeared when you opened the Macintosh HD icon.) You're going to open another window now.

1. **Click the Trash icon near the lower-right corner of the screen to select it.**

   Make sure that the icon is highlighted, which means that it's selected to be the object you'll act upon next.

2. **Point to the File menu title in the menu bar.**
3. **Press to pull down the File menu.**

4. Drag to the Open command so it becomes highlighted, and then release the trackball button.



When you choose the Open command, the Trash icon opens into a window (the Trash window). The Trash icon becomes filled in with a pattern of dots, indicating that it has been opened.



You should now have two windows on your Macintosh desktop: the Macintosh HD window and the Trash window. The Trash window is the active window. An active window has a series of solid lines at the top of the window.

continues ▶

5. **Click anywhere in the Macintosh HD window to make it the active window.**

   Notice that the solid lines now appear at the top of the Macintosh HD window. (The area containing the window title and the solid lines is called the title bar.) When windows overlap, the active window is the one that's on top.



Make a window larger or smaller

Sometimes you want to make a window larger, so you can see more of its contents, or smaller, so it takes up less space on your screen. You can change a window's size by dragging its size box or by clicking its zoom box.

1. **Point to the size box in the lower-right corner of the (active) Macintosh HD window.**



2. **Drag the size box in any direction, and then release the trackball button.**

   While you drag, an outline follows the pointer to indicate the window's new size. The new size takes effect when you release the trackball button.



3. **Click the zoom box near the right end of the title bar.**

   The window "zooms" to a size that shows all the items in the window.

4. **Click the zoom box again.**

   The window zooms back to its previous size (the size that you chose in step 2).

Move the hidden contents of a window into view

As you work with your computer, you'll encounter windows containing more than you can view on the screen at one time. You can view contents that are out of sight, as described in the following steps.

1. **Check that the Macintosh HD window is active, then click the System Folder to select it.**

   Make sure that the icon is highlighted, which means that it's selected.

2. **Point to the File menu title in the menu bar.**
3. **Press to pull down the File menu.**
4. **Drag to the Open command so it becomes highlighted, and then release the trackball button.**

   When you choose the Open command, the System Folder icon opens into a window (the System Folder window).

   You should now have three windows on your Macintosh desktop: the Macintosh HD window, the Trash window, and the System Folder window. (One or more of these windows may be covered by the others.) The System Folder window is the active window because you opened the System Folder most recently.

5. **Point to the size box in the lower-right corner of the System Folder window.**

6. **Drag the size box diagonally (up and to the left) to make the window about half its current size, and then release the trackball button.**





The bars across the bottom and along the right side of the System Folder window should now be gray, indicating that the window has contents that are not currently visible. The gray bars are called scroll bars.

7. **Press the scroll arrow at the right end of the horizontal scroll bar.**



The contents of the window scroll past, bringing into view the icons that were out of sight on the right.

8. **Press the scroll arrow at the left end of the horizontal scroll bar.**

The contents of the window scroll past, bringing back into view the icons that were out of sight on the left.

continues ▶

9. **Drag the scroll box toward the middle of the horizontal scroll bar, and then release the trackball button.**

Now you see the icons near the middle of the window.

The vertical scroll bar, scroll box, and scroll arrows work the same way. Try them.

Close a window

When you no longer need to see the contents of a window, you can close it by clicking the *close box*.

1. **In the (active) System Folder window, point to the close box near the left end of the title bar.**



2. **Click the close box.**

   The window closes, and the System Folder icon no longer has a pattern of dots in it.

   There are now two windows on the desktop: the Macintosh HD window and the Trash window. (One may be hidden by the other.)

Move a window

You can move a window anywhere on the screen by dragging its title bar. By changing the position and size of windows, you can arrange your Macintosh desktop in whatever way is best for you.

1. **Point to the title bar of the (active) Macintosh HD window.**

   Position the pointer anywhere on the title bar except over the close box or the zoom box.



2. **Drag in any direction, and then release the trackball button.**

   When you drag, an outline of the window follows the pointer on the screen. When you release the trackball button, the window moves to the position you've chosen.

   Notice how the Macintosh HD window, because it is the active window, stays on top of the Trash window if and when the two windows overlap.



3. **Close the Macintosh HD window by clicking the close box near the left end of the window's title bar.**

   If you can't see the close box, drag the window until you can.



continues ▶

The window closes, and the Macintosh HD icon reappears in its previous form.

The Trash window (the remaining window on the Macintosh desktop) becomes the active window.

4. **Close the Trash window by choosing Close Window from the File menu.**

You choose Close Window by pointing to the File menu title, pressing to pull down the menu, dragging to the Close Window command, and, with the command highlighted, releasing the trackball button.

Of course, you can also close the window by clicking its close box.

What's on the desktop?

Just as a desk's large flat surface is its work space, the Macintosh "desktop" is the work space on your computer. The desktop metaphor gives you a familiar way of thinking about how to use the Macintosh.

Aside from the field of gray that represents the "surface" of your work space, the Macintosh desktop has icons, windows, and menus.

- Icons represent containers.
- Windows let you view what's inside the containers.
- Menus list actions that you can apply to selected containers or their contents.

Icons represent containers

Icons can contain other icons, or they can contain information.

For example, the startup hard disk icon contains the System Folder icon. The System Folder icon contains the programs (also represented by icons) that in turn contain the information the Macintosh needs to start itself up and work properly.

Different types of icons represent different types of containers.

Hard disks and floppy disks are like filing cabinets. You use disks to store files—your programs and the documents you create with them.



Shared disks are like filing cabinets containing office supplies or information that you share with others in your work group. Your Macintosh needs to be connected to a network before you can use shared disks.



Folders are like folders in a file drawer. You use folders to organize your files.



Programs are files containing instructions to the computer that let you do certain types of work.



Documents are files containing words, pictures, numbers, sounds—whatever you create with your programs.

The Trash is a container for files that you no longer want.

Windows let you see what's inside containers

Windows let you see what's inside all these containers. When you open a disk icon, the window that appears shows you what's on the disk. When you open the document icon representing a memo, the window that appears shows you the memo.

Changing the size of a window or viewing its contents does *not* change the contents. The contents remain the same; only your view changes.

Menus offer you choices

Like the menus in a restaurant, Macintosh menus let you choose. You choose among different actions that the computer can perform on containers (icons), or on their contents (such as words in a memo).

Using the keyboard

You use the keyboard to type text and numbers, just as you would on a typewriter. (For touch typists, your keyboard has raised dots in the middle of the D key and the K key to help position your fingers on the home row.)

Depending on the program you're using, you can use special keys on the keyboard to give commands to the computer and to modify certain things that you do with the trackball. Macintosh PowerBook computer keyboards have two types of special keys: modifier keys and arrow keys.

Modifier keys

All Macintosh keyboards have four modifier keys: Shift, ⌘ (Command), Option, and Control.

Pressed by itself, a modifier key does nothing. You need to press it in combination with another key (or while using the trackball). The modifier key causes the other key or trackball to give a different ("modified") result.

You type a capital letter, for example, by pressing the Shift key with a letter key. Most programs let you choose commands by pressing the ⌘ key with certain letter keys.

Arrow keys

All Macintosh keyboards have four arrow keys: Up Arrow, Down Arrow, Left Arrow, and Right Arrow.

Many programs let you use the arrow keys as well as the trackball to move the pointer on the screen.



Chapter 3

Creating and Changing a Document

In this chapter

- How to open a program
- How to use a program to create a document
- Why it's important to save your work, and how to save it
- How to switch between programs
- How programs and system software differ from each other
- How to close a document
- How to open a document
- How to change a document
- What "keyboard shortcuts" are and how to use them
- How to quit a program
- How to make a copy of a document
- How to change the name of a document
- How to use the Trash

Before you begin

Make sure that your computer is on.

Open a program

Your computer comes with a simple word-processing program called TeachText. You're going to use this program to create a document.

1. **Open the Macintosh HD icon.**

   (Click the icon to select it, and then choose Open from the File menu.)

   The Macintosh HD window appears, showing you the contents of your hard disk. The contents include the TeachText program.

2. **Open the TeachText icon.**

   If you can't find the TeachText icon, use the scroll bars to bring it into view.



   To open the icon, click the icon to select it, and then choose Open from the File menu.

When you open the TeachText program, there is one dramatic change on your desktop:

- A window called "Untitled" appears.

There are also two subtle changes:

- The menu bar shows the menu names for the TeachText program.
- The Application menu icon in the right corner of the menu bar becomes the TeachText icon.



The untitled window is empty because you haven't put anything in it. In the next few sections, you're going to write a short document, save it, and give it a name.

Create a document

The untitled window is like a blank sheet of paper. In the upper-left corner of the empty document is a blinking vertical line (I). This line is called the *insertion point*, because it marks the place where the text you type will be inserted.

As you type, use your computer keyboard as you would a typewriter keyboard, except:

- If you make a mistake, press the Delete key to backspace over it.
- Don't press the Return key when you get to the end of a line. Keep typing, and words will move to the next line automatically.

Type the following text:

```
All people are born free and equal.
Endowed with reason and conscience, they
should act towards each other in a spirit
of togetherness.
```

You will be changing this text later in this chapter.

Save your work

Work that you do in a program exists only in the computer's memory until you save it onto a disk. Since work that exists only in memory is lost when you shut down the computer, you need to save your work so you can come back to it later. If you don't save your work, it disappears—like thoughts that are lost unless you write them down.

1. Choose Save from the File menu.

The box that appears (called a dialog box) lets you name the document and save it on your hard disk.

continues ▶

2. **Type “Opening Lines”.**



Because the word “Untitled” is selected (highlighted) when the dialog box appears, all you have to do to name your document is start typing. Whatever you type replaces the selected text.

3. **Click Save.**



The window is now titled “Opening Lines” and the document has been stored on your hard disk.

Switch programs

You can have several programs open on your Macintosh desktop at one time (how many depends on how much memory your computer has and how much memory the programs use). But only one program at a time can be the active program. The active program is the one that’s “on top of” other open programs—in the same way that the active window is on top of other windows.

The Opening Lines window is now the active window, and TeachText is the active program. But TeachText is not the only program that’s open.

Since you turned on your computer, you’ve been working with the Finder program. The Finder displays the Macintosh desktop. The Finder is always open when your Macintosh is on, so right now it is open but not active.

1. **If the Opening Lines window covers most of your screen, make the window smaller by dragging its size box up and to the left, and then release the trackball button.**

   After you resize the window, you should be able to see your hard disk icon in the upper-right corner of the desktop.

2. **Make the Finder the active program by clicking the Macintosh HD icon, or clicking anywhere on the desktop outside the Opening Lines window.**

   The Finder becomes the active program. Notice:

   - The Macintosh HD window appears on top of the Opening Lines window.
   - The menu bar shows the Finder's menu titles.
   - The Application menu icon at the right end of the menu bar becomes the Finder icon.



   You may also notice the Opening Lines icon in the Macintosh HD window, representing the document you just created and saved.

3. **Make the Opening Lines window active by clicking anywhere inside it.**

   (Part of the window may be hidden by the Macintosh HD window.)

   When you click, the Opening Lines window comes back to the top. It's now the active window again, and TeachText is the active program.

   You make a window active by clicking any visible part of it. The program that "owns" the window becomes active when the window becomes active.

Here is another way to make a program active:

4. **Make the Finder the active program by choosing Finder from the Application menu at the right end of the menu bar.**

continues ▶

You choose Finder by pointing to the Application menu icon, pressing to pull down the menu, dragging to highlight the name Finder, and then releasing the trackball button.

The Finder becomes the active program, and the Macintosh HD window becomes the active window.

5. **Make TeachText the active program by choosing TeachText from the Application menu.**

TeachText becomes the active program, and the Opening Lines window becomes the active window.

All open programs are listed in the Application menu. You can use the Application menu to choose which program to make active. The icon in the menu bar is always the icon of the currently active program.

Close a document

When you close a document, you do not close the program that you used to create it. (Closing a program is called quitting.) The program remains open and active until you quit the program or make another program active.

1. **If the Opening Lines window is not the active window, click anywhere inside it to make it active.**
2. **Close the Opening Lines window.**

   You can either click the close box near the left end of the title bar, or choose Close from the File menu.

The Opening Lines window closes but TeachText is still the active program. Notice:

- The menu bar still shows the TeachText menu titles.
- The Application menu icon at the right end of the menu bar is still the TeachText icon.

Two types of programs

Programs that you use to do your work on the computer are called *application programs,* or *applications,* because they're ways of applying computer technology to the work that you do.

Word-processing programs, for example, are applications that enable you to write memos, novels, or whatever you need to write. And if your work involves creating illustrations, designing buildings, composing music, or keeping track of large amounts of data, there are application programs for those kinds of work, too.

Because most Macintosh programs work in similar ways, you can transfer much of what you learn in one application to other applications.

Programs that the computer uses to do its work (in contrast to your work) are called *system software,* or sometimes the *operating system.*

Between you and the system software is a program called the *Finder,* which displays the Macintosh desktop. It's called the Finder because, like the viewfinder in a camera, it gives you a view of all the objects— disks, programs, folders, and documents—on your desktop.

You use the Finder to tell the system software what you want it to do for you: which disks you want to use, which documents and programs you want to open, and where you want files to be stored.

Open a document

When you open a document, the program you used to create that document becomes the active program.

1. **If you closed the Macintosh HD window, open the Macintosh HD icon now.**

   (Click the icon to select it, and then choose Open from the File menu.)

   The Macintosh HD window appears, showing you the contents of your hard disk. The contents include the TeachText program and the TeachText document you created called Opening Lines.

   The next step describes a different way to open an icon.

continues ▶

2. Open the Opening Lines icon by double-clicking it.



To double-click an icon, you click it twice in rapid succession without moving the pointer. (Use the trackball to position the pointer over the icon, and then click one of the trackball buttons twice.) Double-clicking an icon has the same effect as selecting the icon and then choosing the Open command.

When you open Opening Lines, TeachText becomes the active program. Notice that:

- the Opening Lines window appears
- the menu bar shows the TeachText menu titles
- the Application icon at the right end of the menu bar is the TeachText icon



Change a document

The Opening Lines window shows you the text you typed. In this section you'll make some changes to the text using techniques that work in most Macintosh programs.

Keep two things in mind:

- The insertion point—the blinking vertical line—marks the place where text will appear.
- A pointer called an I-beam (it looks like this: I) replaces the arrow pointer (↖) when you're working with text. You control the I-beam pointer with the trackball in the same way that you control the arrow pointer.

1. Locate the insertion point. It should be in the upper-left corner of the document.

2. Locate the I-beam pointer (I). If you don't see it, roll the trackball slightly. The pointer moves as the trackball moves.

Now you're ready to change the text.

3. **Move the I-beam pointer to the immediate left of the word “people” (after “All”).**

4. **Drag horizontally, selecting the word “people”, and then release the trackball button.**



To drag, hold the trackball button down while you roll the trackball. The selected word is highlighted (surrounded by black).

If you select more or less than you intended to, go back to step 3 and try again.

5. **With “people” selected, type the words “human beings”.**

The words you type replace the word you selected. (Press the Delete key to backspace over any typing errors.)



6. **Move the I-beam pointer between the word “equal” and the period (to the immediate left of the period).**



7. **Click the trackball button once.**

Clicking moves the insertion point to the spot where you positioned the I-beam. Whatever you type next is inserted at that point.

8. **Press the space bar once, and then type the words “in dignity and rights”.**



continues ▶

Now you'll rearrange some text.

9. **Move the I-beam pointer to the immediate left of the word "they" (after "conscience,").**

10. **Drag horizontally, selecting the word "they", and then release the trackball button.**



11. **With "they" selected, choose Cut from the Edit menu.**

    Choosing Cut removes the selected material from the document and stores it in a temporary file called the Clipboard.



12. **Move the I-beam pointer to the immediate left of the word "Endowed".**



13. **Click to place the insertion point.**

14. **Choose Paste from the Edit menu.**



When you choose Paste, your computer takes whatever's in the Clipboard and puts it into the document at the location of the insertion point.

15. **Press the space bar once, type “are”, and then press the space bar once again.**



16. **Move the I-beam pointer between the letters *t* and *h* in the word “they”.**



17. **Click the trackball button to place the insertion point.**

18. **Press the Delete key once and then type a capital *T*.**

Save your work so far

The changes you’ve made so far are not part of Opening Lines until you save them. You save them by telling the computer to record them in the Opening Lines document that’s stored on your hard disk.

It’s important to remember that no change is “official” until you save it onto a disk. Your work could be lost if power to the computer were interrupted or if a problem caused the computer to stop working properly.

Choose Save from the File menu.

Save regularly, and save often.

Taking a shortcut

You can choose some menu commands by using the keyboard instead of the trackball. A *keyboard shortcut* is a combination of keys that you press at the same time to get the same result as choosing a command from a menu. One of the keys you press is always the ⌘ key or another modifier key.

For example, instead of choosing Save from the File menu, you can hold down the ⌘ (Command) key on the keyboard while you press the S key. Pressing ⌘-S is a keyboard shortcut equivalent to choosing Save from the File menu.

You can see the available keyboard shortcuts by pressing a menu title and looking at the commands in the menu. The keyboard shortcuts are listed next to the commands.

Make more changes

The changes you've made so far are now part of the document that's stored on your hard disk.

1. **Move the I-beam pointer (⌶) between the letters *E* and *n* in the word "Endowed".**



2. **Click once to place the insertion point.**
3. **Press the Delete key once and then type a lowercase *e*.**
4. **Move the I-beam pointer to the immediate right of the comma after the word "conscience".**



5. **Press the Delete key once, press the space bar once, and then type “and”.**



6. **Move the I-beam pointer to the immediate left of “each other”.**



7. **Click the trackball button once.**

   Clicking moves the insertion point to the place where you positioned the I-beam.

8. **Move the I-beam pointer to the immediate right of the “each other”. Do not drag. Do not click the trackball button yet.**

9. **Hold down the Shift key on your keyboard and click to select the words “each other”.**



   Holding down the Shift key while you click selects the text between the insertion point and wherever you click.

10. **With “each other” selected, type “one another”.**



continues ▶

11. Select the word “togetherness” by double-clicking it.



To select a word by double-clicking it, position the I-beam pointer over the word and then click twice in rapid succession, without moving the pointer.

12. With “togetherness” selected, type “brotherhood”.

You may now have extra spaces or no spaces between words. If so, position the I-beam pointer where you need to delete or add a space, click to place the insertion point, and press the Delete key or the Space bar as necessary.



13. Choose Save from the File menu.

Quit a program

Quitting a program closes the program as well as any open documents that were created using that program. (Simply closing a document leaves the program open and active.)

1. **Make sure that the Opening Lines window is active.**
2. **Quit the TeachText program.**

   You can either choose Quit from the File menu, or press the ⌘ key and the Q key together.

If a message asks whether you want to save any changes, click Save.

The Opening Lines document and the TeachText program are closed, and the Finder becomes the active program.

Opening and closing documents and programs

Doing this	Also causes this
Opening a document	Opens the program that created that document
Making a document window active	Makes the program that "owns" that document active
Closing a document	Simply closes that document; *does not* close the program that created that document (the program continues to use memory)
Quitting a program	Prompts you to save your work, then closes the program that created the active document (memory becomes available for other programs)

Make a copy of a document

You'll often want to make a copy of a document so you can preserve the original and modify the copy. To practice making a copy of a document, you'll use the "Opening Lines" document you created.

1. **If you closed the Macintosh HD window, open the Macintosh HD icon now.**

   (Click the icon to select it, and then choose Open from the File menu.)

   The Macintosh HD window appears, showing you the contents of your hard disk. The contents include the TeachText program and the TeachText document you created called Opening Lines.

2. **Click the Opening Lines icon to select it.**

continues ▶

3. **Choose Duplicate from the File menu.**



A new icon, labeled “Opening Lines copy”, appears in the hard disk window. Notice that the icon is selected.

Other ways to make a copy of a file are outlined in the summary chapter in the reference section of this book.

Change the name of an icon

You can change the name of any icon, using any characters except a colon (:). If you change an icon’s name and then open it, you’ll see that the name of its window has also changed.

1. **Drag the “Opening Lines copy” icon away from the original icon so that the two icons do not overlap.**
2. **Click the name (not the icon) “Opening Lines copy.” Do this even if the icon is already selected.**

   When the name is selected, it is highlighted and a box appears around it. Notice that when you point to the selected name, the arrow pointer becomes an I-beam.



3. **With the name selected, type “Article 1”.**

   Whatever you type replaces the selected text.

4. **Press the Return key.**

   Pressing Return saves the new name.



Now you have two identical documents with different names. You can revise one without changing the other.

Use the Trash

When you no longer need a file or a folder, you can throw it away by dragging its icon to the Trash. Practice using the Trash by throwing away the “Article 1” document, which you created when you made a copy of the “Opening Lines” document.

1. **If you closed the Macintosh HD window, open the Macintosh HD icon now.**

   (Click the icon to select it, and then choose Open from the File menu.)

   The Macintosh HD window appears, showing you the contents of your hard disk. The contents include the TeachText program and two documents, one called Opening Lines and the other called Article 1 (you may have to use the window’s scroll bars to see them).

continues ▶

2. **Drag the Article 1 icon to the Trash icon until both icons are highlighted, and then release the trackball button.**

   If the Macintosh HD window is blocking the Trash icon, move the window by dragging its title bar.

   Both icons are highlighted when the tip of the arrow pointer reaches the Trash icon.



   When you release the trackball button, the Article 1 icon "disappears" into the Trash. When you put an object in the Trash, the Trash icon bulges to indicate that it is no longer empty.

3. **Open the Trash icon.**

   (Click to select the icon, and then choose Open from the File menu, or click the Trash twice in quick succession.)

   The Trash window appears. Anything you drag to the Trash stays there until you empty the Trash.

   You can retrieve items from the Trash by clicking to select them and then choosing Put Away from the File menu. (Or you can drag the items back to where they were.)

4. **Choose Empty Trash from the Special menu.**

   A message appears asking you to confirm that you want to permanently remove the contents of the Trash.

5. **Click OK.**

   Clicking OK empties the Trash—in other words, its contents are erased from the disk.

   Notice that the Trash icon no longer bulges, indicating that it is empty.

6. **Close the Trash window by clicking its close box.**

Chapter 4

Working With Disks

In this chapter

- What hard disks and floppy disks are for, and how they differ
- How to insert and remove a floppy disk
- How to prepare a disk for use
- How to copy the contents of a disk
- How to protect a floppy disk and its contents
- How to put programs onto your computer

Before you begin

You need a new floppy disk to follow the steps in this chapter. You should be able to get floppy disks from wherever you got your computer.

Make sure that your computer is on.

Insert a floppy disk

Your computer's floppy disk drive can accommodate 3.5-inch (89-millimeter) floppy disks of two types:

- high-density disks, which can hold up to 1.4 megabytes (MB) of information
- double-sided disks, which can hold up to 800 kilobytes (K) of information

(The next page explains kilobytes and megabytes.)



Follow these steps to insert your new disk into the disk drive.

1. **Write "Practice" on a blank disk label.**
2. **Attach the label to your new floppy disk.**

   The molding of the disk's plastic case indicates where the label goes. Do not affix the label over the metal shutter.
3. **Hold the disk with your thumb on the label and the metal shutter pointing away from you.**
4. **Push the disk into the floppy disk drive, label side up and metal shutter first.**



The next section, "Initialize a Disk," explains what to do about the message that appears on your screen.

Floppy disks and hard disks

Both floppy disks and hard disks function like filing cabinets: you use them to store information. You can store much more on a hard disk than on a floppy disk, however, and the computer can retrieve information from a hard disk much faster.

Floppy disks and hard disks are represented by different icons.

The disk whose icon is closest to the upper-right corner of your desktop is the *startup disk,* which contains the information the Macintosh uses to operate.

Your hard disk is sealed into the hard disk drive inside your computer. Floppy disks, in contrast, can be taken in and out of floppy disk drives so you can easily transfer information from one computer to another.

A floppy disk is made of thin, flexible material with a magnetic coating. To protect it and make it easier to handle, the floppy disk itself is enclosed in a rigid plastic case, which gives the floppy disk its "non-floppy" character. Floppy disks are sometimes called *diskettes.*



Even the smallest hard disks can hold the equivalent of a few thousand pages of information. High-density floppy disks can hold 1.4 megabytes (MB) of information—about 300 typewritten pages. Double-sided floppy disks can hold 800 kilobytes (K) of information—about 200 typewritten pages. (A megabyte is about 1,000 kilobytes.)

Initialize a disk

Every new disk needs to be prepared for use. Preparing a new disk is called initializing it. In the same way that lines are drawn on a newly paved parking lot to mark off parking spaces, the initializing process creates organized areas on the disk where the computer can store information. Your computer's hard disk was initialized at the factory, but you need to initialize any new floppy disks you want to use.

1. **Read the message on your screen.**

   The computer requests information from you or warns you about the consequences of an action by presenting a message in the form of a dialog box.

   If you inserted a high-density disk, this dialog box appears:

   If you inserted a double-sided disk, this dialog box appears:

2. **If you inserted a high-density disk, click Initialize. If you inserted a double-sided disk, click Two-Sided.**

   Another dialog box appears:



   This dialog box appears because you can initialize old disks as well as new ones—and the computer doesn't know whether the disk in the drive is old or new. Initializing erases all information on a disk. In this case, because the floppy disk is new, there is no information on it to erase.

3. Click Erase.

A third dialog box appears:

4. Type “Practice”.

If you make any typing errors, press the Delete key to backspace over them.

5. Click OK.

The computer takes about a minute to initialize the disk. Messages appear on the screen to let you know how the process is going.

When initialization is finished, the disk’s icon appears directly below the Macintosh HD icon (the startup hard disk icon) near the upper-right corner of the desktop.



Copy the contents of a disk

Most programs you'll use with your Macintosh are supplied on floppy disks. You can use a program more efficiently if you first install it on your hard disk. You install most programs by copying them from the floppy disk to your hard disk.

To practice copying the contents of a floppy disk to your hard disk, use your practice disk (even though there's nothing on it).

1. **Drag the Practice floppy disk icon to the Macintosh HD icon until both icons are highlighted, and then release the trackball button.**

   Both icons are highlighted when the tip of the arrow pointer reaches the Macintosh HD icon.

   When you release the trackball button, the Macintosh copies the contents of the Practice disk onto Macintosh HD (your hard disk). Because there is nothing on the Practice disk, the copying happens very quickly.

   Now, find the copy of Practice you just created.

2. **Open the Macintosh HD icon.**

   To open the icon, click the icon to select it and then choose Open from the File menu. (You choose Open by pointing to the File menu title, pressing to pull down the menu, dragging to the Open command, and then releasing the trackball button.)

   The Macintosh HD window appears, showing you the contents of the hard disk. The contents should include a new folder called Practice, which the computer created when it copied the contents of the Practice disk to Macintosh HD.

   You may have to make the window larger or use the scroll bars to see the Practice folder.

3. **Open the Practice folder icon.**

   To open the icon, click the icon to select it and then choose Open from the File menu.

   The folder holds the contents of the floppy disk you've copied. In this case, the folder is empty because there's nothing on the Practice disk.

4. **Close all the windows on the Macintosh desktop.**

   You close a window (when it's the active window) by either clicking its close box or choosing Close Window from the File menu.

Taking care of floppy disks

Follow the care instructions that came with your disks, and remember three key points:

- Keep floppy disks away from magnets. Because information is stored on the disk in the form of magnetic signals, a magnetic field can destroy that information. Televisions and monitors, telephones, loudspeakers, and certain kinds of lighting fixtures all contain magnets.
- Protect disks from extremes of temperature and humidity.
- Do not open the disk's metal shutter. Touching the disk inside the shutter could damage it.



Take a floppy disk out of its drive

You take a floppy disk out of its drive when you no longer need to get information from or store information on that disk.

1. **Click the Practice floppy disk icon to select it.**

   Click the icon, not its name.



2. **Eject the floppy disk by choosing Put Away from the File menu.**

You choose Put Away by pointing to the File menu title, pressing to pull down the menu, dragging to the Put Away command, and releasing the trackball button.

Put Away returns the object you've selected to its original place. In this case, it ejects the floppy disk from the disk drive so you can put it away.

Protect the contents of a disk

You can lock a floppy disk so its contents cannot be changed in any way. When a disk is locked, you can look at the files it contains, but you cannot modify the files on it, delete them, or store any new files.

Use your practice disk to practice locking and unlocking a floppy disk.

1. **Hold the practice disk with your thumb on the label and the metal shutter pointing away from you, as though you were going to insert the disk into a drive.**
2. **Find the square hole in the near-left corner of the floppy disk.**

   A moveable tab on the back side of the disk should be blocking the hole, indicating that the disk is unlocked.

   If you're using a high-density disk, you'll notice an additional square hole, across the label from the first hole. This second hole has no tab and is always open.

3. **Turn the disk over and lock it by sliding the tab so that the square hole is open.**



   Use your thumbnail or a push pin to move the tab.

4. **Unlock the disk by sliding the tab back so that the square hole is blocked.**

   You are unlocking your practice disk now so you can use it to store files in the next chapter.

On your own: Install your programs

If you have a floppy disk drive and disks containing programs that you plan to use with your Macintosh, you can install the programs on your hard disk now (or you can wait until later and continue with the next chapter).

The general instructions in this section describe how to copy the contents of a program disk to your hard disk.

△ **Important:** Some programs need to be installed in a particular way. If your programs came with specific instructions, follow them instead of the instructions in this section. △

1. **Lock the program disk.**

   The program disk contains your master copy of the program. Locking the disk protects its contents but doesn't keep you from copying the contents onto another disk.

2. **Insert the program disk into your floppy disk drive.**

3. **Drag the program disk icon to the Macintosh HD icon (your hard disk icon) until both icons are highlighted, and then release the trackball button.**

   Both icons are highlighted when the tip of the arrow pointer reaches the Macintosh HD icon.

   When you release the trackball button, messages appear on the screen to let you know that the computer is copying the contents of the program disk onto your hard disk.

   When copying is finished, the contents of the program disk appear on your hard disk in a folder that has the same name as the program disk.

4. **Eject the program disk by selecting it and choosing Put Away from the File menu.**

5. **Open the Macintosh HD icon.**

   The Macintosh HD window shows you the contents of your hard disk. Among its contents is the program folder, which contains the same items as the original disk.

6. **Click the program folder to select it.**

7. **Choose Open from the File menu.**

   The folder window appears, showing you the contents of the program folder. The folder has the same contents as the program disk.

8. **Look for a System Folder in the program folder.**

   Some program disks contain a System Folder so they can be used as startup disks. (A startup disk, by definition, is a disk that has a System Folder on it.) If the program disk you've copied has a System Folder, you now have two System Folders on your hard disk. For the computer to work properly, you must throw away any extra System Folders.

Throw away extra System Folders

Your startup disk must have only one System Folder on it. Whenever you copy the contents of a program disk to your hard disk, make sure that you have not copied an extra System Folder. If you have, throw the extra System Folder away.

1. **Drag the extra System Folder from the program folder to the Trash.**

2. **Choose Empty Trash from the Special menu.**

   A message alerts you that you're about to throw away the contents of the Trash (in this case, the extra System Folder).

3. **Click OK to confirm that you want to throw away the contents of the Trash.**

4. **Close the window by clicking its close box.**

Chapter 5

Learning More About Your Computer

In this chapter

- How to open the Battery desk accessory
- How to open the PowerBook control panel
- How to use the Balloon Help system
- Where to look for information about your computer and its software

Before you begin

Make sure that your computer is on.

This short chapter introduces you to the Battery desk accessory and the PowerBook control panel, with which you can monitor and control your computer's power consumption.

This chapter also tells you where to find answers to other questions you may have about your computer.

4. **Click OK.**

   The Easy Install dialog box appears.



5. **Make sure that the hard disk named in the box is the one you want to install system software on.**

   If it isn't, click the Switch Disk button until the correct disk name appears.

6. **Click Install.**

7. **Follow the instructions that appear on the screen.**

   If you are installing from floppy disks, you see messages asking you to insert different disks.

8. **When you see a message reporting that the installation was successful, click Quit.**

   If a message reports that installation was not successful, try installing again. (Follow the instructions on the screen.)

9. **Restart your Macintosh.**

Make a backup copy of the System Folder on floppy disks (or on another hard disk).

Installing customized system software

Custom installation allows you to select a combination of system files for your specific needs. You can also use custom installation to install or update a single file, or to save space on your hard disk by installing only the files you want.

To install from floppy disks, begin with step 1; to install over a network, open the Installer program and begin with step 4.

Make sure the system software you're using is compatible with your computer.

1. **Shut down your Macintosh.**
2. **Insert the *Install Me First* disk into the floppy disk drive.**
3. **Turn on your Macintosh.**

   The Installer program opens automatically.
4. **Click OK.**

   The Easy Install dialog box appears.
5. **Make sure that the hard disk named in the box is the one you want to install system software on.**

   If it isn't, click the Switch Disk button until the correct disk name appears.
6. **Click the Customize button.**

   The custom installation dialog box appears. All available components of the system software are listed.
7. **Scroll through the list of items and hold down the Shift key as you click the items you want to install.**

   If you want to conserve space on your hard disk, select the "minimal software" option for your Macintosh.



△ **Important:** Be sure to install the files that your Macintosh uses to communicate with the printer, network, and other equipment it is connected to. △

8. **Click Install.**
9. **Follow the instructions that appear on the screen.**

   If you are installing from floppy disks, you may see messages asking you to insert different disks.

10. **When you see a message reporting that the installation was successful, click Quit.**

    If a message reports that installation was not successful, try installing again. (Follow the instructions on the screen.)

11. **Restart your Macintosh.**

Make a backup copy of the System Folder on floppy disks (or on another hard disk).

▲ **Warning:** Your startup disk must have only one System Folder. Multiple System Folders on a disk can cause malfunctions and data loss. You can use the Find command (in the Finder's File menu) to see if there is more than one System Folder on your hard disk. Drag any extra System Folders to the Trash. ▲

Starting up with a floppy disk

If you're unable to use your hard disk and you have a floppy disk drive, you can start up your computer by inserting the *Disk Tools* disk into the floppy disk drive and then turning on the computer. This disk contains programs you can use to initialize, test, and repair disks.

Installing your programs

Most application programs come on floppy disks, and you install them by simply copying them from the floppy disks to your hard disk. Some programs need to be installed in a particular way. If your program came with specific instructions, follow them.

To use your programs most effectively:

- Put only one copy of each program on your hard disk. Having more than one copy can lead to problems when you're using the program.
- Whenever you copy the contents of a program disk to your hard disk, be careful not to copy an extra System Folder. Always check to see what you've copied, and drag any extra System Folders to the Trash.
- Keep the original program disk in a safe place. If the program on your hard disk malfunctions, you can replace it with a fresh copy from the original disk.
- If a program malfunctions consistently, and installing a fresh copy does not correct the problem, find out from the software manufacturer whether your version of the program is compatible with the system software you're using.
- Put frequently used programs (or aliases for those programs) in the Apple menu so you can open the programs more conveniently. See the chapter on adapting your computer to your own use.
- If you want your computer to open a program automatically each time it starts up, you can put the program (or its alias) into the Startup Items folder. See the chapter on adapting your computer to your own use.

Installing programs without a floppy disk drive

There are other ways to copy programs onto your hard disk:

- If you have access to a network, you can connect your computer to the network and copy programs from a shared disk. See the chapter on networks.
- If your computer can be used in SCSI disk mode and you have access to a desktop Macintosh, you can connect the two computers and copy programs directly from the desktop Macintosh. See the chapter on building an enhanced computer system.

Remember that the software license agreement for a given program may limit the number of copies you're allowed to make.

Checking for computer viruses

Viruses—programs that damage files or erase disks—can be introduced into your computer from a floppy disk, from a shared disk on a network, or from an electronic bulletin board service.

Programs that detect and eliminate viruses are available from user groups, bulletin boards, and dealers.

You should check for viruses frequently if you exchange disks or data with other users. Some programs check for viruses automatically.

- Check all disks—even those in new, unopened commercial software packages—for viruses before using them or copying anything from them to your hard disk.
- Check your hard disk regularly with a virus-detection program and correct any problems the program finds.
- Since new viruses appear regularly, make sure you have the latest version of your virus-detection software.
- To avoid compatibility problems, be sure to use only one virus-detection program at a time.
- If your computer is on a network or if you use a modem, check for viruses each time you copy information from an outside source.
- If you give information to other computer users on disks or send information electronically, make certain that there are no viruses on your computer system before distributing the information.

Working with several programs at a time

You can open as many programs and desk accessories as your computer's memory allows.

All open programs are listed in the Application menu at the right end of the menu bar. The name of the active program (the one you're using right now) has a checkmark next to it, and its icon appears in the menu bar.



Finding out what programs are open

If you have several programs and windows open, you can find out which program is active and what other programs are open by pulling down the Application menu.

Switching programs

You can switch to another open program or desk accessory by choosing its name from the Application menu.

If a program's icon is dimmed in the menu, that means its windows are hidden. Choosing the program from the Application menu displays its windows.

You can also switch to another program by clicking in a window that belongs to an open program, or by double-clicking a program icon (or the icon of a document that was created with the program).

Hiding and showing windows on the desktop

You can hide all windows except those of the active program by choosing the Hide Others command from the Application menu.

The other programs remain open even though the windows are hidden. When you switch to another program, its windows are displayed.

If you want to see all the open windows, choose Show All from the Application menu.

Changing the amount of memory a program uses

Each program you open sets aside the amount of memory it needs. (If you don't have enough memory to open a program, you need to quit one of the programs already open to free up some memory.)

On occasion you may want to increase or decrease the amount of memory a program uses. You increase the amount so you can open more or larger documents in that program, and you decrease the amount so you can open more programs at the same time. You adjust the program's memory size in its Info window.

1. **Quit the program if it's open, and then click the program's icon to select it.**
2. **Choose Get Info from the File menu.**
3. **Drag across the box containing the number you want to change (either "Minimum size" or "Preferred size").**

   "Preferred size" must always be larger than "Minimum size."

4. **Type the number of kilobytes (K) of memory that you want the program to use.**

   If the program frequently runs out of memory, increase both the preferred size and the minimum size.

   If you want to be able to open more programs, decrease the minimum size. If you type a size smaller than "Suggested size," the program may work more slowly, show other performance problems, or not work at all.



5. **Close the Info window.**

   If you make the memory size smaller than suggested, you'll see a message asking you to confirm your decision. Click Cancel to avoid problems with the program.

Using the Scrapbook

You can use the Scrapbook to store text, graphics, sounds, and other elements that you frequently include in your documents.

Storing items in the Scrapbook:

1. **In your document, select the text or other element that you want to store in the Scrapbook.**
2. **Choose Copy from the Edit menu.**
3. **Choose Scrapbook from the Apple ( ) menu.**

   The Scrapbook opens. You can use the scroll bar to see the different text, graphic, and other elements it contains.



4. **Choose Paste from the Edit menu.**

   The new element is pasted ahead of the one previously displayed.

Copying items from the Scrapbook:

1. **Choose Scrapbook from the Apple ( ) menu.**
2. **Use the scroll bar to display the item you want to use in a document.**
3. **Choose Copy from the Edit menu.**
4. **Open the document you want to use the item in.**
5. **Decide where you want to place the element.**
6. **Choose Paste from the Edit menu.**

Deleting items from the Scrapbook:

1. **Choose Scrapbook from the Apple ( ) menu.**
2. **Use the scroll bar to display the item you want to delete.**
3. **Choose Clear from the Edit menu.**

Using a RAM disk

A *RAM disk* is a portion of your computer's memory that you set aside for use as a temporary storage device. Using a RAM disk conserves power because the computer uses less energy to access RAM than to access a hard disk or a floppy disk.

To use a RAM disk, you should have at least 4 MB of RAM in your computer because memory assigned to a RAM disk is not available for opening programs.

Choosing Sleep or restarting the computer does not affect a RAM disk—but if your computer has a built-in floppy disk drive, choosing Shut Down erases the contents of the RAM disk (but does not remove the RAM disk itself).

Remember a few precautions if you use a RAM disk:

- Before using a program on a RAM disk, test the program on your hard disk or a floppy disk to make sure that it works properly with your computer.
- Don't store your only copy of a file on a RAM disk. Keep a backup copy on your hard disk or a floppy disk.

Creating a RAM disk

1. **Choose Control Panels from the Apple (🍎) menu.**
2. **Open the Memory control panel.**

   The RAM disk portion of this control panel is at the bottom of the window. If your computer has less than 3 MB of RAM, this portion does not appear.



3. **Click the On button below the words "RAM disk."**
4. **Drag the slider to choose the percentage of available memory you want to use for your RAM disk.**

   Choose a size just large enough to accommodate the programs and documents you want to put on the RAM disk. Don't choose a larger size than you need because memory set aside for the RAM disk won't be available for opening programs.

   The size of the RAM disk you select appears in the "RAM Disk Size" box.

continues ▶

5. **Choose Restart from the Special menu.**

   A RAM disk icon appears on the desktop when the computer restarts.

6. **Drag the items you want to the RAM disk icon.**

Erasing a RAM disk

There are two ways to erase the contents of a RAM disk. They do not remove the RAM disk itself or make more memory available for opening programs.

- **Select the RAM disk icon and choose Erase Disk from the Special menu.**
- **Drag everything on the RAM disk to the Trash and choose Empty Trash from the Special menu.**

Resizing or removing a RAM disk

1. **Copy any programs or documents that you want to save onto the internal hard disk or a floppy disk.**

   If you want to resize a RAM disk, you need to remove its contents and then restore them.

2. **Drag everything in the RAM disk to the Trash.**
3. **Choose Empty Trash from the Special menu.**
4. **Choose Control Panels from the Apple (🍎) menu.**
5. **Open the Memory control panel.**
6. **Drag the slider to choose the percentage of available memory you want to use for your RAM disk.**

   Drag the slider to 0% if you want to remove the RAM disk.

7. **Choose Restart from the Special menu.**

   If you resized your RAM disk, a new RAM disk icon appears on the desktop when the computer restarts. If you removed your RAM disk, no icon appears.

8. **If you resized the RAM disk, copy any items you want back to it.**

Making a RAM disk the startup disk

If you have 6 MB or more of memory, you can make a RAM disk your startup disk.

1. **Create a RAM disk.**
2. **Locate and open the Installer program on the *Install Me First* disk.**
3. **Install a minimal System Folder on the RAM disk.**

   See the instructions on installing customized system software in this chapter.
4. **Choose Control Panels from the Apple (🍎) menu.**
5. **Open the Startup Disk control panel.**
6. **Select the RAM disk as your startup disk.**
7. **Choose Restart from the Special menu.**

The RAM disk is now your startup disk. Be sure to keep a System Folder on your hard disk as well, in case the contents of the RAM disk are erased. Also, keep a copy of the RAM disk contents on another disk. (Don't keep two System Folders on a single disk.)

△ **Important:** If your computer has a built-in floppy disk drive, the contents of the RAM disk are erased when you choose Shut Down, though the RAM disk itself is not removed. △

Chapter 7

Power Management

In this chapter

- Checking the battery level
- Responding to low-power messages
- Recharging the battery
- Removing or replacing the battery
- Maximizing battery life
- Getting the most work time out of the battery

Monitoring the battery charge level

Your computer's main power source is a nickel-cadmium battery. The battery provides power for up to 3 hours of work (the exact time depends on how often you use the hard disk, how bright the screen is, and other factors). Use the Battery desk accessory to monitor the charge level of the battery so you can recharge it when necessary.

Using the Battery desk accessory

To open the Battery desk accessory, choose Battery from the Apple ( ) menu.



The Battery desk accessory appears.

The line of rectangles is the battery gauge. Black rectangles indicate the charge level. You can see the level decrease while the battery is in use, and increase while the battery is recharging in the computer.

When you click the lever to the right of the battery gauge, a Sleep button appears.



You may sometimes find it convenient to put the computer to sleep by clicking this button, instead of choosing the Sleep command.

Responding to low-power messages

When the battery charge drops to about 15%, the computer displays a series of low-power messages. The work time remaining after you see the first message will vary depending on how you are using the computer. It's a good idea to act promptly.

What you should do

When you see a low-power message, do either of the following:

- **Plug in the power adapter,** *or*
- **Save your work and put the computer to sleep.**

What you should know

The first low-power message indicates that it's time to recharge the battery. Right after this message appears, the screen brightness dims automatically to save power.

If you continue to work without plugging in the power adapter, the computer displays a second low-power message.

The second message is followed almost immediately by a third and final message indicating that the computer is about to put itself to sleep. When time is up, the computer goes to sleep automatically to protect the contents of RAM.

If you continue working until the computer goes to sleep automatically, you may not be able to wake it again until you recharge the depleted battery in the computer for 15 minutes.

If you can't plug in the power adapter, the contents of RAM are retained in sleep for at least 2 days. If you leave the battery in the computer and recharge it within 2 days, you should be able to wake the computer and resume work where you left off.

△ **Important:** Recharge a depleted battery as soon as possible. Leaving a depleted battery in the computer for longer than 2 weeks (especially in a hot location, such as the trunk of a car) may damage the battery so that it can't be recharged. If this happens, you need to replace the battery. △

Recharging the battery

There are two ways to recharge:

- Plug in the power adapter to recharge the battery without removing it from the computer, *or*
- Remove the battery and recharge it in the (optional) recharger.

Recharging with the power adapter

Plug in the power adapter as shown.



▲ **Warning:** Use only the power adapter that came with your computer. Adapters for other electronic devices (including other portable computers) may look similar, but they may damage your computer. ▲

A lightning bolt icon appears in the Battery desk accessory when the power adapter is plugged in and the battery is recharging. The lightning bolt icon disappears when recharging is about 85% complete, though recharging continues. The icon appears even if the power adapter is plugged into the computer only, so make sure the adapter is plugged into both the computer *and* an electrical outlet.



You can continue to use the computer while the battery is recharging, but the battery will take longer to recharge if you do. Battery recharging time while the computer is in use depends on how often you use the hard disk, how bright the screen is, whether you are using an external monitor, how deeply the battery is depleted, and other factors.

If you are using several of your computer's power-consuming features (such as an external monitor and a program that requires frequent hard disk access), and you are *not* using the features designed to conserve power (such as processor cycling), the battery may not recharge until you put the computer to sleep or shut it down.

If you recharge a fully depleted battery with the computer shut down, it takes about 2–3 hours to bring the battery to 80% of its capacity. It takes several more hours to bring the battery charge to 100%.

While the computer is shut down and the power adapter is plugged in, you can remove a charged battery from the computer and replace it with a battery you want to charge. If you do this, disconnect and then reconnect the power adapter after inserting the second battery (otherwise the second battery will not recharge).

Recharging with a recharger

A battery recharger and additional batteries are available as options for your computer. If you purchase a recharger and an extra battery, you can charge one battery while you use the other, so you always have a fully charged battery on hand.

The recharger can accommodate two batteries. The battery slots work independently, so you can put batteries in or take them out at different times.

The recharger must be plugged into an electrical outlet to charge a battery. You can plug it in using the power adapter that came with your computer, or you can purchase an additional (identical) power adapter from your authorized Apple dealer.

▲ **Warning:** Do not use any other type of power adapter with the recharger. Doing so may damage the recharger, the power adapter, or both. ▲

To recharge a battery, follow these steps.

1. **Place the recharger on a level surface.**
2. **Connect the recharger and the power adapter as shown in the illustration.**



3. **Place the battery in the recharger as shown.**

   Recharging begins immediately. You can remove a battery from the recharger at any time.

△ **Important:** To preserve a battery's charge, don't leave it in the recharger if the power adapter is not plugged into an electrical outlet. △

The lights on the recharger indicate the following:

- **No light:** The recharger is not plugged in, or the battery is defective. (If the light goes off during recharging, there is a problem with the battery.)
- **Yellow:** The battery is charging.
- **Green:** The battery is charged to at least 80% of its capacity, and can be used.

The table shows approximate recharging times for fully depleted batteries.

	80% charge	100% charge
In the recharger:		
1 battery	2.5 hours	5 hours
2 batteries	5 hours	10 hours
In the computer (shut down):	2–3 hours	6–8 hours

Removing or replacing the battery

Don't attempt to use your computer without a battery (even when the power adapter is plugged in).

To remove or replace the battery, follow these steps.

1. **Save your work, and then choose Shut Down from the Special menu.**
2. **Close the display.**
3. **Open the battery door by sliding the door in the direction indicated by the arrow.**

   The door is physically attached to the battery.



4. **Carefully pull the battery out of its compartment.**
5. **If you are inserting another battery, slide it into the battery compartment.**

   Replacement batteries come with a door attached.
6. **Close the battery door by pushing it back into place.**
7. **If you just inserted a new battery, it's a good idea to plug in the power adapter in case the battery is not fully charged.**

△ **Important:** Nickel-cadmium batteries contain hazardous materials. It is inappropriate, and in some cases unlawful, to throw batteries away with your household or business trash. Return dead batteries to your authorized Apple service provider, who will make sure they are handled correctly through Apple's battery recycling and disposal network. △

▲ **Warning:** Damaged nickel-cadmium batteries may leak small amounts of potassium hydroxide. This substance can cause severe burns to the skin and eyes. If you touch a damaged battery, immediately wash your hands and any other affected areas with water for at least five minutes. *Do not use soap.* ▲

Maximizing battery life

To maximize battery life, discharge and then recharge the battery completely once every 90 days. Just use the computer as you normally would, but ignore the low-power messages that appear on the screen. (Make sure to save your work, however.) When the computer goes to sleep automatically, recharge the battery completely before using that battery again. You can do this in either of two ways:

- Leave the battery in the computer, plug in the power adapter, and let the battery recharge overnight, *or*
- Remove the battery from the computer and recharge it in a recharger for 5 hours (if you are recharging just one battery) or 10 hours (if you are recharging two).

Your battery will last longer if you recharge it at or slightly below room temperature.

With proper care you can expect your battery to last for at least a year. If you notice that the battery no longer holds a charge for as long as it should, you may need to replace it.

Maximizing work time

Your PowerBook's battery can provide up to 3 hours of work time before you need to recharge it. The actual work time available depends on what equipment you're using with your computer and what steps you take to conserve power while you work.

Ways to conserve battery power

The more of these steps you take, the longer you can use your battery before recharging it.

- Turn down the screen brightness whenever possible. At its brightest level, the screen consumes about a third of the power your computer is using.
- Keep screen dimming turned on in the PowerBook Display control panel. This setting dims your screen automatically if you haven't used the computer for a few minutes.
- Adjust the battery conservation settings in the PowerBook control panel for maximum conservation: set the battery conservation slider at Maximum Conservation; keep processor cycling turned on; and set the computer's microprocessor to run at a reduced speed. The rest of this section describes these settings in detail.
- Keep virtual memory turned off in the Memory control panel.
- If your computer has 6 MB of memory or more, you can use a RAM disk as your startup disk to minimize hard disk use.
- Quit any program that uses a modem unless you're using the program for telecommunication. As long as the program is open, your modem is consuming power.
- If you're working near an electrical outlet, plug in the power adapter.
- If you aren't using the computer, put it to sleep and plug in the power adapter.

Adjusting the battery conservation settings

The Battery Conservation section of the PowerBook control panel gives you several ways to regulate your computer's power consumption.

The easiest approach

Just use the Battery Conservation slider to choose the setting you prefer.

1. **Choose Control Panels from the Apple (🍎) menu, and open the PowerBook control panel.**
2. **In the Battery Conservation box, drag the slider to the setting you want.**



There are four settings along the scale. If you're trying to meet a deadline, Maximum Performance allows you to work with the fewest interruptions. If you don't have a power adapter with you, Maximum Conservation gives you the longest work time.

When you change the setting, the new setting takes effect immediately.

3. **Close the PowerBook control panel.**

You can think of the battery conservation setting as an automatic sleep setting. If you don't use the computer for several minutes (how many depends on which setting you choose), it goes to sleep without any action on your part. A computer in sleep has a darkened screen and appears to be off, though it is still drawing battery power at a low level.

To put the computer to sleep before the automatic sleep setting takes effect, choose Sleep from the Special menu.

To wake the computer from sleep, press any key (except Caps Lock).

Automatic sleep does *not* take effect under any of the following circumstances:

- You are using an external monitor.
- The AppleTalk software is turned on in the Chooser and the power adapter is plugged in. (Automatic sleep does take effect if the power adapter is not plugged in.)
- Your computer is connected to a shared disk on the network.
- Your computer's printer or modem port is in use.

More about automatic sleep

The Battery Conservation slider controls two different power conservation features: system sleep and hard disk sleep.

- System sleep is a state in which your computer uses only the power it needs to maintain the contents of RAM. (The contents of RAM include any open programs and documents, and various control panel settings such as the clock time.)
- Hard disk sleep stops your computer's internal hard disk from spinning when it isn't being used.

If system sleep is in effect, so is hard disk sleep.

The table indicates how the battery conservation settings correspond to sleep times.

	Minutes before sleep if you choose:			
	Performance		Conservation	
System	15	8	4	1
Hard disk	15	4	2	0.5

Using the battery conservation options

The Battery Conservation section of the PowerBook control panel includes a button labeled Options. Click this button to see more options that affect your computer's power consumption.

Don't sleep when plugged in

If the power adapter is plugged in, you can prevent automatic sleep by clicking "Don't sleep when plugged in."

Processor cycling

If the computer is not doing anything for a few seconds, it reduces the power consumption of its microprocessor. The microprocessor comes back up to speed instantaneously when you resume work. This feature is called processor cycling.

You don't need to do anything to use the processor cycling feature. But if you notice that one of your programs performs very slowly, you might want to turn off processor cycling while using that program.

To turn off processor cycling, follow these steps.

1. **Choose Control Panels from the Apple menu, and open the PowerBook control panel.**
2. **Hold down the Option key on your keyboard and click the Options button.**
3. **Click "Don't allow cycling."**



4. **Close the PowerBook control panel.**

To turn processor cycling back on, click "Allow cycling."

You may notice other effects of processor cycling. For example, if you have open programs doing something in the background, processor cycling may slow those programs down. You may also notice that the Alarm Clock is updated irregularly or that the wristwatch pointer appears more often. These changes do not indicate a problem with your computer.

When you turn processor cycling off, the computer drains the battery faster. The computer may also become very warm to the touch, especially on the side beneath the keyboard. These changes do not indicate a problem with your computer. However, you should keep processor cycling turned on whenever possible.

△ **Important:** To conserve battery power, turn processor cycling off only when using programs that it interferes with. Turn processor cycling back on again as soon as possible. △

Processor speed

The processor speed feature allows you to slow the computer's microprocessor speed (from 33 or 25 MHz to 16 MHz). Some programs may work more slowly, but you may gain up to 15–20 minutes of work time before you need to recharge the battery. (The amount of time you gain depends on how you are using the computer.)

To slow the processor speed, follow these steps.

1. **Choose Control Panels from the Apple menu, and open the PowerBook control panel.**
2. **Click the Options button.**
3. **Click "Reduced speed."**



4. **Click OK.**
5. **Choose Restart from the Special menu.**

The computer runs at the lower microprocessor speed until you click "Standard speed" and restart the computer again.

Chapter 8

Using Disks

In this chapter

- Preparing a new disk for use
- Erasing a disk
- Choosing a startup disk
- Protecting the information on a disk
- If you can't save files on a floppy disk
- Ejecting a disk
- Caring for disks
- Testing and repairing disks

Preparing a new disk for use

Before you can use a new disk, you need to prepare it so the computer knows where to store information on the disk. This preparation is called *initializing* (or *formatting*) the disk.

The hard disk inside your computer is initialized at the factory, but you need to initialize new 3.5-inch (89-millimeter) floppy disks that you want to use in a floppy disk drive.

Initializing a hard disk

Occasionally a hard disk may become damaged in such a way that you have to reinitialize it. (The key symptom of such damage is that the hard disk's icon does not appear on the desktop when you start up the computer using another disk.) You lose all the information on a damaged disk when you reinitialize it.

If your hard disk's icon does not appear on the desktop, first try to repair it as described later in this chapter. If you can't repair the disk, use the Apple HD SC Setup program to reinitialize the disk. The program is on the system software disk called *Disk Tools*.

1. **Insert *Disk Tools* and turn on your computer.**
2. **Locate the Apple HD SC Setup icon and open it.**

The name of the hard disk currently selected is shown as the "volume name." The SCSI ID number of the selected hard disk is displayed above the Drive button. (The ID number of an internal hard disk is 0.)

3. **Click Drive until the disk you want to initialize appears.**



You cannot initialize the disk that you used to start up your computer or the disk that contains the Apple HD SC Setup program.

4. **Click Initialize.**
5. **Click Init to initialize the hard disk.**
6. **If a message appears asking you to name the disk, type a name and then click OK.**
7. **Click Quit when you see a message reporting that initialization was successful.**

   If a message reports that initialization failed, try again. If initialization fails a second time, take the disk to your authorized Apple service provider for repair.

Initializing a floppy disk

Initializing a new floppy disk prepares the disk to store information.

1. **Insert a new floppy disk into your floppy disk drive.**

   If you inserted a high-density disk (1.4 MB), this message appears:

   If you inserted a double-sided (800K) disk, this message appears:

2. **If you inserted a high-density disk, click Initialize.**
   If you inserted a double-sided disk, click Two-Sided.

   A message alerts you that you're about to erase any information that may be on the floppy disk. A new floppy disk has no information on it.

3. **Click Erase.**

   A third message asks you to name the disk.

4. **Type a name for the disk.**

   If you don't name the disk, the computer gives it the name "Untitled."

5. **Click OK.**

   The computer takes about a minute to initialize the disk. When initialization is finished, the icon of the floppy disk appears on the desktop.

Erasing a floppy disk

Erasing a disk actually reinitializes it.

▲ **Warning:** When you erase a disk, you lose any information that was on the disk. ▲

1. **Click the icon of the disk you want to erase.**
2. **Choose Erase Disk from the Special menu.**

   A message appears.
3. **Depending on the type of disk you're erasing, click Initialize or Two-Sided.**

   The computer takes about a minute to erase the disk.

Designating a startup disk

If you use more than one hard disk with your computer, you can specify which hard disk you want the computer to use as the startup disk. (A startup disk must have a System Folder on it that contains the correct version of the system software.)

If you don't specify a startup disk, your computer uses its internal hard disk as the startup disk (if it has a System Folder).

1. **Choose Control Panels from the Apple ( ) menu.**
2. **Open the Startup Disk control panel.**
3. **Click the icon of the disk you want to use as the startup disk.**

4. **Close the Startup Disk control panel.**

Scanning order for startup disks

When you turn on your computer, it looks for a startup disk (a disk containing a System Folder) in the following sequence:

1. internal floppy disk drive (if any)
2. external floppy disk drive (if any)
3. disk (or RAM disk) selected in the Startup Disk control panel
4. internal hard disk
5. external hard disk (if there is more than one, it looks first at the hard disk with the highest SCSI ID number)
6. internal hard disk (the computer returns to this drive and waits another few seconds)

If the computer does not find a startup disk, it displays a blinking question mark in the middle of the screen.

To bypass the internal hard disk in the scanning sequence, press ⌘-Option-Shift-Delete while the computer starts up.

△ **Important:** If you use an external hard disk, turn it on and wait a few seconds before you turn on your Macintosh, or the computer may not recognize the disk. △

Protecting the information on a disk

The information on a locked floppy disk or in a locked file can be opened or copied but cannot be changed.

Locking a floppy disk

- Slide the tab on the back side of the disk so that the square hole is open.

  Use your thumbnail, a push pin, or a similar object to move the tab.



To unlock the disk, slide the tab back so that it covers the square hole.

Locking a file

You use the Get Info command to lock a document or a program. Locking a program may affect its operation.

1. **Click the icon of the file you want to lock.**
2. **Choose Get Info from the File menu.**
3. **In the Info window, click the Locked box in the lower-left corner.**



4. **Close the Info window.**

To unlock the file, click the Locked box again (so the X disappears).

You can't lock a folder, but you can lock items in a folder.

Locking an alias does not lock the original file. Locking an alias merely protects it from being thrown away.

Backing up your files

Making backup copies of important files is good protection against possible damage to the originals.

- You can back up files stored on your hard disk by copying them onto floppy disks.
- You can back up an entire floppy disk by copying it to another floppy disk, or to a hard disk.
- You can use a commercial backup program to copy new and changed files from a hard disk to another hard disk, to a tape drive, or to a series of floppy disks.
- If your computer is on a network, you can back up files by copying them to a shared disk on the network.
- If your computer can be used in SCSI disk mode and you have access to a desktop Macintosh, you can connect the two computers and back up files by copying them from one computer to the other. (See the chapter on expanding your computer system for more information.)

If you can't save files on a floppy disk

If you can't save files on a floppy disk, the disk may be locked, full, or damaged, or the disk drive may not be working properly. Try the following:

- Make sure the tab on the back of the disk is in the unlocked position (the square hole should be closed).
- If you see a message reporting that the disk is full, erase unneeded files from that disk, or save on another disk.
- If you see a message that the disk is not initialized, and you know that it has been initialized, eject the disk and carefully insert it again. If the same message appears, the disk is probably damaged. You may be able to recover its information with Disk First Aid or another disk-recovery program. (See the section on testing and repairing disks in this chapter.)
- Check the disk for obvious damage to the plastic case or the sliding metal shutter.
- Insert a different disk and try saving again. If you can't save on the second disk, the disk drive may be damaged. Take the disk drive to your authorized Apple service provider for repair.

Ejecting a disk

You can eject a floppy disk by doing any of the following:

- Click the disk icon to select it and choose Put Away from the File menu.

  The disk is ejected and its icon disappears from the desktop.

- Drag the disk icon to the Trash.

  The disk is ejected and its icon disappears from the desktop. (Dragging a disk to the Trash does not erase the disk's contents.)

- Click the disk icon to select it and choose Eject Disk from the Special menu.

  The disk is ejected and its dimmed icon remains on the desktop.

You can use the first two methods to remove a hard disk icon from the Macintosh desktop (provided that it's not your startup disk), or to disconnect from a shared disk on the network.

All three methods also work with CD-ROM discs.

If you can't eject a floppy disk

If you can't eject a floppy disk in the usual way, try the following in order:

1. Hold down the ⌘ and Shift keys and press the number 1 key on your keyboard to eject a disk in an internal disk drive; press ⌘-Shift-2 to eject a disk in an external disk drive.
2. Turn off the Macintosh. If the disk isn't ejected, then hold down the trackball button while you turn the computer on again.
3. Locate the small hole near the disk drive's opening, and carefully insert the end of a large straightened paper clip into it. Push gently until the disk is ejected. Do not use excessive force.



4. If nothing works, take the computer or disk drive to your authorized Apple service provider to have the disk removed.

Caring for disks

For information on floppy disk care, see the section on working with disks in Part II of this book, or consult the instructions that came with your floppy disks.

Hard disk precautions

Hard disk drives are delicate mechanisms and should be handled with care.

- Do not bump, jar, or move your computer while the hard disk is in use. If you need to move the computer, wait until the hard disk stops spinning.
- Do not spill any liquids on or near the hard disk.
- Do not expose the hard disk to hazardous vapors, such as those from cleaning solvents.

Testing and repairing disks

Both floppy disks and hard disks can become damaged by repeated use and handling. If you see a message reporting that a disk is damaged or unreadable, you can use Disk First Aid or Apple HD SC Setup to try to diagnose and correct the problem. Both programs are on the disk called *Disk Tools* that came with your computer.

If your computer can be used in SCSI disk mode, you may be able to correct a problem with your hard disk by connecting your computer to a desktop Macintosh and then reinstalling the system software on your computer from the desktop computer. (See the chapter on enhancing your computer system for more information.)

If a hard disk icon doesn't appear

If you can't start up from a hard disk or don't see its icon on the desktop, try the following:

- If the hard disk is internal, shut down your Macintosh, wait at least 10 seconds, and then turn it on again.
- If the hard disk is your startup disk, start up with a different disk. If the hard disk's icon appears on your desktop, reinstall system software on the hard disk (use your backup copy or use the Installer program and the original system software).

continues ▶

- If the hard disk is external, make sure it is turned on and its cable is connected firmly; then restart the Macintosh.
- Check the ID numbers of all SCSI equipment connected to your computer. Each device must have a unique ID number (the computer itself has the ID number 7, and the internal hard disk has the number 0). Also check that the chain of devices is terminated properly. (See the chapter on enhancing your computer system for information about setting SCSI ID numbers and checking termination.)

Using Disk First Aid

You can use the Disk First Aid program to test floppy disks and hard disks that may have been damaged. Disk First Aid also repairs some types of disk damage. Disk First Aid is on the system software disk labeled *Disk Tools*.

1. **Insert *Disk Tools* and start up your computer.**
2. **Open the Disk First Aid icon.**

3. **Click the Drive button until the name of the disk you want to test appears. Click the Eject button if you want to insert a different floppy disk.**
4. **Click Open.**
5. **Choose Repair Automatically from the Options menu.**



6. **Click the Start button to begin testing the disk.**
7. **When testing and repair are finished, choose Quit from the File menu.**

If you want to test another disk, choose Close from the File menu, then select and open another disk (repeat steps 3–7).

If Disk First Aid cannot correct the problem:

- Try repairing the disk again. Sometimes repeating the process corrects the problem.
- Use another disk repair or recovery program. Some disk repair programs let you recover information from a damaged disk.
- Consult a specialist for help.
- Once you have recovered all the information you can, erase (reinitialize) the disk. If initialization doesn't work, discard the damaged floppy disk, or take the hard disk to your authorized Apple service provider for repair.

Testing a hard disk

You can test a hard disk with the Apple HD SC Setup program, which is on the system software disk labeled *Disk Tools.*

1. **Insert *Disk Tools* and start up your computer.**
2. **Open the Apple HD SC Setup icon.**

3. **Click the Drive button until the disk you want appears.**



4. **Click Test.**
5. **When a message tells you that testing is complete, click Quit.**

   If the test reveals a problem, you may be able to correct it by using Disk First Aid or another disk repair program, or you may have to reinitialize the disk. Consult a specialist for assistance if necessary.

Chapter 9

Organizing Your Files

In this chapter

- Straightening up your files
- Using folders to organize your files
- Filing documents when you save them
- Making items easier to find
- Finding an item
- Creating a template or stationery
- Getting information about your files
- Assigning a label to a file
- Tips on transferring files

Straightening up your files

To accomplish this . . .	Do this . . .
Straighten up all icons in the active window	Choose the Clean Up command from the Special menu
Straighten up selected icons only	Hold down the Shift key while choosing Clean Up
Arrange icons alphabetically by name, or by the list view displayed most recently in that window	Hold down the Option key while choosing Clean Up
Line up icons near the right edge of the desktop	Click the desktop, then hold down the Option key while choosing Clean Up

You can also have icons arrange themselves in a staggered grid when you choose Clean Up. See the chapter on adapting your computer to your own use.

Using folders to organize your files

Macintosh folders, like the paper folders in a file cabinet, can be used to store and organize your work. You can place one folder inside another to create a hierarchy of files.



Creating and naming folders

You can create a new folder whenever the Finder is the active program.

1. **Choose New Folder from the File menu.**

   A new folder appears in the active window (or on the desktop if no window is active). The name is already selected.



2. **Type a name for the folder and press Return.**

   If this doesn't work, click the folder's name to select it, and try again.

You move, copy, and remove folders in the same way that you do other icons.

Many programs also let you create and name a new folder in the dialog box that appears when you save a document.

Filing documents when you save them

The first time you save a document (or whenever you choose Save As to create another version of that document), a directory dialog box appears. A directory is the list of files and folders contained in a folder or on a disk.

You use this box to name your document and indicate where to store it. Directory dialog boxes vary slightly from program to program, but all share certain features.



Making items easier to find

Your Macintosh provides several ways to make a file, folder, or other item easy to find and open. You can

- create aliases for the item and put the aliases in convenient locations
- install the item (or its alias) in the Apple (🍎) menu
- move the item (or its alias) to the desktop

Creating an alias

An alias represents and points to a file, folder, disk, or other item (even a shared item on a network). You can make as many aliases for an item as you want.

1. **Click to select the item you want to make an alias for.**
2. **Choose Make Alias from the File menu.**

   The name of the alias appears in italics and ends with "alias."
3. **If you wish, type a new name for the alias (the name is already selected), and then move it to a new location.**

Uses for aliases

Alias for	Location	Purpose
Any item that could be stored in several places	Everywhere the item belongs	You can get access to an item from several places.
Apple Menu Items folder	On the desktop	You can easily add or remove Apple menu items.
A program that must stay with certain files	On the desktop; in the Apple menu	You can start the program without opening the folder or disk where it is stored.
A document or folder stored on a separate disk	Anywhere on your work disk	When opened, the alias asks for the disk by name, then opens the original when the disk is inserted.
An item on a shared disk	Anywhere on your work disk	When opened, the alias automatically connects to the shared disk and opens the item.

❖ *Trouble?* If you open an alias and nothing happens, or if you see a message that the original file isn't available, then the original has been deleted or the alias is damaged. You can open the alias's Info window to find out where the original is. ❖

Locating the original of an alias

An alias's Info window shows the location of the original.

1. **Select the alias whose original you want to find.**
2. **Choose Get Info from the File menu.**



3. **Click the Find Original button.**

   The window containing the original item opens. The icon is selected. (If the original is on another disk, you're asked to insert the disk.)

   If you deleted the original, or if it is on a shared disk that's not available, you'll see a message that the original can't be found. Aliases are not deleted when the original is deleted (and vice versa).

Installing an item in the Apple menu

You can install any item in the Apple menu, and then open the item by choosing it from the menu.

1. **Open the System Folder icon and locate the Apple Menu Items folder.**
2. **Drag the item you want to install (or its alias) into the Apple Menu Items folder.**

   The item appears immediately in the Apple menu.

You remove an item from the Apple menu by opening the Apple Menu Items folder and dragging its icon out of the folder.

❖ *Trouble?* If the Apple menu does not contain the items it should, make sure that the Apple Menu Items folder is in the System Folder of your startup disk. If it is, open the folder to check that all the items you want in the menu appear there. ❖

Moving an item to the desktop

You can make an item easy to find by dragging its icon to the desktop. The icon stays there until you remove the disk on which the item is stored.

If you've placed an icon on the desktop, you can put it back in its original location by selecting the item and choosing Put Away from the File menu.

Finding an item

When the Finder is the active program, you can use the Find command in the File menu to find any item on any disk connected to your computer. (The Find command cannot locate items inside the System file. You need to open the System file to see its contents.)

Finding an item by name

1. **Choose Find from the File menu.**

   The dialog box that appears lets you find an item by name.



   If the dialog box you see has more items than shown here, click the Fewer Choices button in the lower-left corner.

2. **Type the name (or part of the name) of the item you want to find.**

   Capitalization does not have to match.

3. **Click the Find button.**

   The first item that matches the name you typed is shown highlighted in a Finder window. If an item is found on the desktop, you see a message. If no item matches, you hear an alert sound.

4. **To see the next matching item, choose Find Again from the File menu.**

   If no more items are found, you hear an alert sound.

Finding an item using other criteria

You can use the Find command to find items by size, label, date, or other characteristics.

1. **Choose Find from the File menu.**
2. **If you see a button labeled More Choices, click the button.**

   The dialog box that appears lets you select search characteristics using pop-up menus.



   The content of the middle pop-up menu and the text area vary according to the item selected in the left pop-up menu.

3. **Choose an item from the left pop-up menu.**
4. **Choose an item from the middle pop-up menu.**
5. **Adjust the date, choose an item, or type text in the upper-right area of the dialog box.**



continues ▶

6. **Choose a search location from the pop-up menu labeled Search.**



Location for the search

7. **If you want all items displayed at once, click the checkbox labeled "all at once."**

8. **Click the Find button when you've finished selecting options.**

   The first matching item is shown highlighted in a Finder window. To see the next matching item, choose Find Again from the File menu. If the item is found on the desktop, a message appears. If no item is found, you hear an alert sound.

   When you display items all at once, they are shown highlighted in an outline view.



A list view, in outline form, shows the contents of folders.

Indentation means that an item is located inside a folder.

Finding items that meet two criteria

You can locate items that meet two sets of criteria, such as all items created before a certain date and larger than a certain size.

1. **Choose the first criterion.**
2. **Click the "all at once" box so that an X appears.**
3. **Click the Find button.**

   The items found are shown highlighted in an outline view.

4. **Choose the Find command again, before you click or take any other action.**

   You choose Find immediately so that the items located in the first stage of the search remain highlighted.

5. **Choose the second criterion.**
6. **Choose "the selected items" in the pop-up menu labeled Search.**
7. **Click Find to begin the second stage of your search.**

   The items meeting both criteria are highlighted.

Ways to use the Find command

The Find command can help you locate files quickly, organize documents, and develop an efficient system for backing up and archiving your work.

This characteristic	Can be used to locate
Name	1. Files whose names you can't recall exactly 2. All items for which you use a standard name, such as status reports or expense reports
Kind	1. All application programs 2. All aliases
Size	Large files, to make space available on a disk
Label	All the files to which you added the same label (such as "top secret")
Lock	Locked files, to unlock them for editing
Modification date	All files changed since a certain date, to back up new and changed files
Creation date	All files created before a certain date, to archive or erase outdated material

Creating a template or stationery

Most documents can be saved as or converted into a stationery pad, which is a template form of the document. The template retains its format and content, and you can use it repeatedly as a master for similar documents with different content.

Many programs let you save a document as a stationery pad when you choose Save or Save As. Click the stationery pad option to save your document as a template.



If the program you're using does not offer a stationery pad option, you can use a document's Info window to create a stationery pad.

1. **Click the document icon to select it.**
2. **Choose Get Info from the File menu.**
3. **Click "Stationery pad" near the lower-right corner so that an X appears in the checkbox.**



4. **Close the Info window.**

   The document icon now appears as a stationery pad icon.

When you open a stationery pad, an untitled window appears showing the contents of the stationery, or a dialog box appears asking you to name the new document.

If you want to change the stationery pad itself you must first turn it back into a regular document. You can do this by opening the stationery pad's Info window and clicking "Stationery pad" to remove the X.

Getting information about your files

When the Finder is the active program, you can obtain information about your files in two places:

- in the file's Info window
- in the View menu

Using the Info window

The Get Info command displays information about a selected item.

1. **Click to select the item you want information about.**
2. **Choose Get Info from the File menu.**



   You can type comments in the Info window and use the Find command to search for them later.

3. **Close the window.**

Using the View menu

You can use the View menu to display the contents of a window by icon or small icon, or you can list items according to various characteristics such as name, size, or kind. (You can use the Views control panel to change how files are listed and what information is included in the list. See the chapter on adapting your computer to your own use.)

Windows are preset to show icons. You can also display items in a list by choosing a command from the View menu. For example, listing items by the date and time of their most recent modification makes it easy to back up files you have changed recently.



When the contents of a window are displayed as a list, you can click any column heading (such as Size or Last Modified) to rearrange the list according to that characteristic.

Assigning a label to a file

You can add a label and its associated color (or shade of gray) to a file. Labels provide a way to group related files (choose By Label from the View menu). If you have a color or gray-scale monitor, you can identify related icons by assigning a label and color to each group.

The label is visible only when the contents of a window are displayed as a list. The color is visible whenever your computer is set to display colors or grays.

To assign a label and color to an icon, click the icon to select it and then choose the label and color that you want from the Label menu. If your monitor is not set to display colors or grays, no colors appear in the Label menu.

Tips on transferring files

You can transfer files from your computer's internal hard disk in the following ways:

- Over a network

  You can connect your computer to a network and transfer files over the network. For information, see the networking chapter.

- Over telephone lines

  If your computer is connected to a modem or has a modem installed, you can transfer files over telephone lines using an appropriate communications program. For more information, see the chapter on expanding your computer system.

- On floppy disks

  If your computer has a built-in floppy disk drive or is connected to an external floppy disk drive, you can transfer files from your computer's internal hard disk to a floppy disk. (If your computer does not have a built-in floppy disk drive, see the chapter on expanding your computer system for instructions on connecting a disk drive.)

- On another hard disk

  If your computer is connected to another hard disk, you can transfer files from your computer's internal hard disk to another hard disk. For instructions on connecting a hard disk, see the chapter on expanding your computer system.

Chapter 10

Sound, Color, and Video

In this chapter

- Setting the beep sound
- Installing a sound
- Removing a sound
- Recording sounds
- Displaying colors or grays
- Changing the highlight color
- Changing the color of window borders
- Changing the background pattern
- Assigning a color to an icon
- Changing the colors or grays in the Labels menu
- Using more than one monitor
- Controlling automatic screen dimming
- Magnifying the screen image

Setting the beep sound

Many programs have the computer make a sound when your attention is required or when you're attempting an action that the computer cannot perform at that time.

You can choose the type of beep sound that you want your computer to make. You can also set the sound's volume.

1. **Choose Control Panels from the Apple ( ) menu.**
2. **Open the Sound control panel.**

The Sound control panel appears. The beep that your computer is currently using is already selected.

continues ▶

3. **Click the beep sound that you want your computer to use.**



When you click a sound to select it, it's played at the current volume setting.

4. **Drag the slider up or down to set the volume.**

If you set the volume to zero, instead of hearing a beep, you'll see the menu bar flash.

5. **Close the Sound control panel.**

Installing a sound

Your computer comes with several beep sounds. You can get additional sounds from various sources.

- **To install a sound, you drag its icon to the System Folder icon (not the System Folder window). The sound is automatically installed in the System file, where it belongs.**

Once you add a sound to the System file, it is listed in the Sound control panel.

Removing a sound

You can remove sounds in the Sound control panel. Make sure you have a backup copy of the sounds on floppy disk. (To copy a sound, you can open the System file to see its icon.)

1. **Choose Control Panels from the Apple (🍎) menu.**
2. **Open the Sound control panel.**
3. **Click to select the sound you want to remove.**
4. **Choose Cut from the Edit menu.**

   If you selected the wrong sound, you can choose Paste to restore the sound.
5. **Close the Sound control panel.**

You can also remove a sound by opening the System file and dragging the sound's icon out of the System file and out of the System Folder.

Recording sounds

If your computer has a built-in microphone, or a sound input port (🎙), you can record a sound and add it to the Sound control panel. (See the chapter on expanding your computer system for information on connecting a microphone or other audio source.)

1. **If your computer does not have a built-in microphone, connect a microphone or another audio source to your computer.**
2. **Choose Control Panels from the Apple (🍎) menu.**
3. **Open the Sound control panel.**

   The Sound control panel appears. The icons of the available sound input devices appear near the bottom of the window.
4. **Click the icon of the sound input device you want to use.**

continues ▶

5. **Click the Add button.**
6. **Get ready to record, then click the Record button.**

   Recording begins immediately. You have ten seconds to record your sound. There is no volume control.



7. **Click Stop to stop recording.**
8. **To listen to the sound you recorded, click Play.**
9. **To save the sound you recorded, click Save.**
10. **Type a name for the sound, and click OK.**



The new sound appears in the Sound control panel. Its icon also appears in the System file.

Displaying colors or grays

You can designate how many colors or shades of gray you want your monitor to display. (How many colors or grays your computer can display depends on the video capability it has. See the technical specifications of your computer for more information.)

You set the number of colors or grays in the Monitors control panel.

1. **Choose Control Panels from the Apple ( ) menu.**
2. **Open the Monitors control panel.**



3. **If you have more than one monitor, click the icon of the monitor you are adjusting.**

   A dark border appears around the icon to show that it is selected.

4. **Click the Grays or the Colors button.**
5. **Click the number of colors or grays you want displayed on the selected monitor (or click Black & White).**

Changing the highlight color or gray

You can change the color or shade of gray your computer uses to highlight selected text on the screen. You make this adjustment in the Color control panel.



You can also use the Color control panel to change the color of window borders.

1. **Choose Control Panels from the Apple (apple) menu and open the Color control panel.**
2. **Press the "Highlight color" pop-up menu to open it and drag to choose a color or choose Other.**

   The selected color appears in the "Sample text" box.

   If you choose Other, a dialog box appears.



3. **To change the brightness of the color wheel, drag the scroll box up or down.**

4. **Click a color on the color wheel to select it.**

   The new color is displayed in the top half of the square. The current color remains in the bottom half of the square for comparison; you can click there to go back to it.

5. **To experiment with other colors, drag the pointer around the wheel or click at another point on the wheel.**

6. **Click OK when you have selected the color or shade of gray you want.**

   The new highlight color is displayed in the “Sample text” box in the Color control panel.

Changing the color of window borders

You can change the color of window borders. You make this adjustment in the Color control panel.

1. **Choose Control Panels from the Apple ( ) menu and open the Color control panel.**



2. **Press the “Window color” pop-up menu and drag to choose a new color.**

Changing the background pattern

You can change the background pattern that appears on your computer screen in the General Controls panel.

1. **Choose Control Panels from the Apple ( ) menu and open the General Controls panel.**



You can choose from a variety of patterns provided, or you can create your own design by editing one of the patterns supplied. You can also use the colors or grays you want in the pattern.



3. **To see the patterns available, click either of the small triangles above the sample pattern.**
4. **Click the sample pattern to see the new pattern on your desktop.**

5. **To edit a pattern, click in the pattern editing area to the left of the sample pattern.**

   Each dot in the square changes color when you click it. Your changes are displayed in the sample pattern.



6. **To use another color, click it in the color bar, then click the dots you want to change.**

   The color bar appears if your monitor is set to display colors or grays. You can choose a new color by double-clicking a color in the color bar and using the color wheel that appears.

7. **When you've finished creating your new pattern, click the sample pattern to display it on your desktop.**

8. **To save the new pattern, double-click the sample pattern.**

   If you don't save the pattern, you lose it when you click one of the small triangles to display another pattern.

9. **Close the control panel.**

Assigning a color to an icon

You can assign a color (or shade of gray) and its associated label to an icon. Labels and colors are a way to group related files (choose By Label from the View menu). On a monitor set to display colors or grays, you can identify groups of icons by assigning a color and its label to each group.

To assign a color and its label to an icon, click the icon to select it and then choose the color and the label from the Label menu.

Instructions on changing the colors in the Label menu are in this chapter.

Changing the colors in the Label menu

You can change the colors or shades of gray (as well as the labels) in the Label menu. You make these changes in the Labels control panel.

1. **Choose Control Panels from the Apple menu (🍎) and open the Labels control panel.**

To change a color, click it.

2. **Click the color you want to change.**

A dialog box appears.



3. **Click a color on the color wheel to select it.**

   The new color is displayed in the top half of the square. The current color remains in the bottom half of the square for comparison; you can click there to go back to it.

4. **To experiment with other colors, drag the pointer around the wheel or click at another point on the wheel.**

5. **Click OK when you have selected the color or shade of gray you want.**

6. **Close the Labels control panel.**

Using more than one monitor

If you use more than one monitor with your computer, you need to set the monitors' positions and designate one as the main monitor (the one that displays the menu bar). For instructions on connecting an additional monitor to your computer, see the chapter on expanding your computer system.

You make these adjustments in the Monitors control panel.

1. **Choose Control Panels from the Apple (🍎) menu and open the Monitors control panel.**



continues ▶

2. **Check the ID numbers of your monitors by clicking the Identify button.**

   A large number appears in the center of each monitor's screen; it corresponds to the number of the icon in the control panel. The ID numbers help you identify which icon represents which monitor.

3. **Decide which monitor is your main monitor and drag the menu bar to the top of that monitor icon.**

   You may want to make the largest one the main monitor because some programs limit their window size to the size of the main monitor, or you may want to make your color monitor the main monitor.

4. **Drag the icons to approximate the positions of your monitors.**

   The pointer can move from one screen to another where the monitors' icons touch in the control panel.

5. **Choose Restart from the Special menu.**

Using a second monitor for presentations

You can use a second monitor connected to your computer to show whatever is displayed on your built-in monitor. This capability is useful when you're making a presentation to a group. You turn this capability on or off in the PowerBook Display control panel.

1. **Choose Control Panels from the Apple (🍎) menu and open the PowerBook Display control panel.**

2. **Click the On or Off button under Video Mirroring.**



3. **Restart your computer.**

Controlling automatic screen dimming

Your computer screen dims automatically when the computer is left idle. It does so in order to avoid “burn-in,” which occurs when the same image is on the screen for too long, and to conserve power consumption (the screen’s backlight is the single biggest consumer of your computer’s battery power).

You can specify the delay before the screen is dimmed. You set this option in the PowerBook Display control panel.

1. **Choose Control Panels from the Apple ( ) menu and open the PowerBook Display control panel.**

2. **Click the On button under Screen Dimming.**
3. **Drag the slider to set the delay.**



If you want to keep the screen from dimming when the power adapter is plugged in, click the box labeled “Don’t dim when plugged in.”

4. **Close the PowerBook Display control panel.**

Magnifying the screen image

The CloseView control panel lets you magnify the image on your computer screen up to sixteen times. It is supplied as part of your system software.

CloseView is not automatically installed by the Installer program when you install system software.

To install CloseView:

1. **Locate the CloseView control panel.**

2. **Drag the CloseView icon to the System Folder icon (not the System Folder window) on your startup disk.**
3. **Choose Restart from the Special menu.**

To turn CloseView on or off, press ⌘-Option-O.

To turn the magnification on or off, press ⌘–Option–X. (When CloseView is on and the magnification is off, a rectangle on the screen indicates which area will be magnified. You can move the rectangle by moving the pointer.)

To increase or decrease magnification, press ⌘–Option–Up Arrow or ⌘–Option–Down Arrow.

You can set additional options in the CloseView control panel. Choose Control Panels from the Apple (🍎) menu and open the CloseView control panel.



Chapter 11

Adapting Your Computer to Your Own Use

In this chapter

- Specifying which items you want opened at startup
- Installing an item in the Apple menu
- Installing files in the System Folder
- Changing the labels in the Label menu
- Setting the time and date
- Setting a time for the Alarm Clock to go off
- Turning the alarm off
- Changing time and date formats
- Changing number and currency formats
- Adjusting the way the trackball or mouse works
- Adjusting the way the keyboard works
- Making keyboard shortcuts easier to type
- Adjusting the keyboard for very slow typing
- Adjusting the blinking of a menu item
- Adjusting the blinking of the insertion point
- Changing the way the contents of windows appear
- Changing an icon
- Turning off the Empty Trash warning
- Managing memory

Specifying which items you want opened at startup

To have a program or a document open automatically when you start up your computer, drag its icon or its alias to the Startup Items folder, which is inside the System Folder. Programs or documents that you put in the Startup Items folder are opened when you start up your computer. You can open as many files as your computer's memory allows.

If you no longer want a file to open automatically when you start up your computer, remove the icon or alias from the Startup Items folder.

Installing an item in the Apple menu

To have an item's name appear in the Apple (apple) menu, drag its icon or its alias to the Apple Menu Items folder, which is inside the System Folder.

You remove an item from the Apple menu by opening the Apple Menu Items folder and dragging the item out of the folder.

Installing files in the System Folder

Certain files need to be installed in the System Folder so your computer can use them as part of the system software. These files include

- system extensions and control panels
- preferences for application programs
- software that controls printers, scanners, and other equipment
- sounds
- fonts

Usually, you install these files by dragging their icons to the System Folder icon (not the System Folder window). Sometimes these files need to be installed by a program that comes with the files. Check the instructions that came with the files for any specific installation procedure.

Most special files are stored in folders inside the System Folder. When you drag a file's icon to the System Folder icon, your computer recognizes which type of file it is and stores the file in the appropriate folder.



If you drag an item to the System Folder window instead of the System Folder icon, the file is not stored in the appropriate folder automatically, and it may not work properly.

Items you want in the Apple Menu Items folder or the Startup Items folder need to be dragged to either folder directly. (This chapter has instructions for installing Apple menu items and specifying the items you want opened at startup.)

Removing files from the System Folder

You remove a file from the System Folder by dragging its icon out of the System Folder.

Depending on the equipment you use, whether or not you're on a network, and how you use your computer, you can remove the following items from your System Folder if you want to conserve space on your startup disk:

- software for printers or other devices you don't use (for example, the AppleTalk ImageWriter driver)
- networking software, if you are not on a network (and don't plan to be) and don't use AppleTalk Remote Access
- Apple menu items you don't use (you need the control panels, but you may not need the Calculator or the Puzzle, for example)
- fonts, sounds, or keyboard files you don't use

Be sure you have backup copies of the files on floppy disks before you remove them from your System Folder.

Changing the items in the Label menu

You can change the labels (as well as the colors) in the Label menu. You make these changes in the Labels control panel.

1. **Choose Control Panels from the Apple ( ) menu and open the Labels control panel.**



2. **To change a label, drag across it to select it and then type your new label.**

   To change a color, double-click it and choose a new color. For more instructions, see the chapter on sound and color.

Setting the time and date

Your computer has a clock that keeps track of the time and date (a battery keeps it running when the computer is turned off).

Many programs rely on the clock to automatically enter times and dates in documents you create or print, and the Finder uses it to keep track of when files are created or changed.

1. **Choose Control Panels from the Apple ( ) menu and open the Date & Time control panel.**



To set the date, click the month, date, or year to select it, then click the up or down arrow (or type the new number).



To set the time, click the hours, minutes, or seconds to select them, then click the up or down arrow (or type the number).

You can also set the time and date using the General Controls panel or the Alarm Clock.

Setting a time for the Alarm Clock to go off

You can set the Alarm Clock to alert you when it's time for an appointment or a meeting.

1. **Choose Alarm Clock from the Apple ( ) menu.**
2. **Click the upward-pointing lever near the upper-right corner to expand the Alarm Clock.**



The lever points downward, and the Alarm Clock expands to its full size.



continues ▶

3. **Click the alarm clock icon in the lower-right corner to select it.**

   The alarm clock icon becomes highlighted when you select it. The time that appears in the middle section is the current alarm clock setting.



4. **Click the hours, minutes, or seconds in the alarm clock setting to select them.**

   Up and down arrows appear to the right of the time display.

5. **Click the up or down arrows repeatedly until the number you want appears.**

6. **Repeat steps 4 and 5 as necessary.**

7. **Click the button to the left of the alarm clock setting to turn the alarm on.**

   The button and the alarm clock icon change to indicate that the alarm is turned on. (Clicking again turns the alarm off.)



8. **Click the close box to close the Alarm Clock.**

   The alarm will not go off unless you close the Alarm Clock, click the lever to make the Alarm Clock smaller, or make another window active.

Turning the alarm off

When the system clock reaches the time set for the alarm, the alert sound plays twice and an alarm clock icon blinks over the Apple icon at the left end of the menu bar.

To turn off the alarm, choose Alarm Clock from the Apple ( ) menu and click the button to the left of the alarm clock setting.

Changing time and date formats

You can change how times and dates appear based on personal preference or local custom.

Changing the date format

1. **Choose Control Panels from the Apple (🍎) menu and open the Date & Time control panel.**
2. **In the Date & Time control panel, click Date Formats.**
3. **In the dialog box that appears, make the changes you want.**

   A sample of the format you choose appears at the bottom of the dialog box.
4. **Click OK to close the control panel.**



Changing the time format

1. **Choose Control Panels from the Apple (🍎) menu and open the Date & Time control panel.**
2. **In the Date & Time control panel, click Time Formats.**
3. **Make the changes you want.**

   A sample of the format you choose appears at the bottom of the dialog box.
4. **Click OK to close the control panel.**



Changing number and currency formats

You can choose among several formats for displaying numbers and currency.

1. **Choose Control Panels from the Apple (🍎) menu and open the Numbers control panel.**

2. **Make the changes that you want.**
3. **Close the control panel.**



Adjusting the way the trackball or mouse works

You can adjust two aspects of trackball or mouse operation in the Mouse control panel: tracking, which is the relation between trackball or mouse movement and pointer movement on the screen, and double-clicking speed.

1. **Choose Control Panels from the Apple (🍎) menu and open the Mouse control panel.**





2. **Click the tracking speed you want.**

   The Very Slow option is useful for drawing or for a graphics tablet because the pointer moves at a constant speed relative to trackball or mouse movement.

3. **Click the double-clicking speed you want.**

   Adjust the double-clicking speed if your computer often interprets two clicks as a double click, or a double click as two single clicks.



The space between arrows corresponds to the time between clicks.

Mouse button highlights twice at the interval selected.

4. **Close the control panel.**

Adjusting the way the keyboard works

You can adjust the rate at which a character repeats when its key is held down as well as the delay before the character begins repeating. You can also change the keyboard layout if you have additional keyboard layouts installed.

1. **Choose Control Panels from the Apple ( ) menu and open the Keyboard control panel.**



2. **To adjust the rate at which a key repeats when it is held down, click the button for the rate you want.**
3. **To adjust the delay before keys repeat, click the button for the delay you want.**

   If the keys repeat when you don't want them to, set a longer delay before a character begins repeating. (If you click the Off button, the keys don't repeat at all.)

4. **To change the keyboard layout, click the name of the keyboard layout you want to use.**

   You may have a choice of more than one keyboard layout. (Additional keyboard layouts are available from various sources. You install them by dragging them to the System Folder icon.)

5. **Close the Keyboard control panel.**

Making keyboard shortcuts easier to type

With the system software feature called Sticky Keys, you can type keyboard shortcuts (such as ⌘-S for the Save command) without actually pressing the keys simultaneously.

- **To turn Sticky Keys on or off, press the Shift key five times without moving the mouse.**

With Sticky Keys on, you can type a keyboard shortcut by first pressing the modifier key (⌘, Option, Control, or Shift) and then pressing the character key. An icon in the right end of the menu bar (to the right of the Application menu icon) changes to indicate whether Sticky Keys is on and whether a modifier key has been pressed or locked.



You can have Sticky Keys beep when a modifier key is pressed. You set this option in the Easy Access control panel. Choose Control Panels from the Apple (🍎) menu and open Easy Access.

Adjusting the keyboard for very slow typing

The system software feature called Slow Keys lets you type very slowly and ignores accidental keystrokes by delaying the acceptance of the next keystroke.

- **To turn Slow Keys on or off, hold down the Return key for about four seconds. A beep signals when the feature has been turned on or off.**

You can adjust how long you want Slow Keys to delay acceptance of the next keystroke. You can also set Slow Keys to make an audible click each time a keystroke is accepted. You make these adjustments in the Easy Access control panel. Choose Control Panels from the Apple (🍎) menu and open Easy Access.

Adjusting the blinking of a menu item

You can change the number of times a menu item blinks when it's chosen. You make this adjustment in the General Controls panel.

1. **Choose Control Panels from the Apple (🍎) menu and open the General Controls panel.**
2. **Click the button for the number of times you want the menu item to blink.**

   Clicking the Off button prevents a menu item from blinking.

3. **Close the control panel.**

Adjusting the blinking of the insertion point

You can adjust how quickly the insertion point blinks (the insertion point indicates where any text you type will appear). You make this adjustment in the General Controls panel.

1. **Choose Control Panels from the Apple (🍎) menu and open the General Controls panel.**
2. **Click the button for the blinking rate you want.**



The insertion point in the control panel blinks at the rate you selected.

Changing the way the contents of windows appear

You can change the way the contents of Finder windows are displayed, and you can change the items in the View menu. You make these changes in the Views control panel. Choose Control Panels from the Apple (🍎) menu and open the Views control panel.

Use the Views control panel to change

- the font and font size used in all views (press to open the pop-up menu, then drag to choose a font or a size)
- the arrangement of icons or small icons
- the size of icons used in list views
- what information is included in list views, including folder sizes and the amount of available space on disk



See the summary and shortcuts section near the end of this book for more information about using windows and list views.

Changing an icon

You can change an icon by creating or copying a picture you want and then pasting it into an icon's Info window.

Some icons can't be changed, including those for control panels and other parts of the system software. Every icon fits inside a small square.

1. **Select the picture you want to use for the icon.**

2. **Copy the picture by choosing Copy from the Edit menu.**
3. **Switch to the Finder, then click to select an icon you want to change.**
4. **Choose Get Info from the File menu.**
5. **Click the icon at the upper-left corner of the Info window to select it.**

   A box appears around the icon when it's selected. If no box appears when you click, the icon can't be changed.

continues ▶

6. **Choose Paste from the Edit menu.**

   The picture you copied replaces the selected icon in the Info window. If the picture is bigger than the icon, it automatically shrinks to fit.

7. **Close the Info window.**

You can restore the original icon by clicking the picture in the upper-left corner of the Info window and choosing Cut from the Edit menu.

Turning off the Empty Trash warning

When you choose Empty Trash from the Special menu, a message warns you that you will not be able to recover the contents of the Trash once it's emptied. (The warning helps you avoid throwing away items unintentionally.)

You can turn off this warning in the Trash's Info box.

1. **Click the Trash icon to select it.**
2. **Choose Get Info from the File menu.**
3. **Click the checkbox labeled "Warn before emptying" to remove the X.**

To turn the warning back on, click the checkbox so that an X appears.

You can also override the warning by holding down the Option key when you choose the Empty Trash command.

Until you choose Empty Trash, items in the Trash continue to occupy space on your disk.

Managing memory

Occasionally you may need to make adjustments in how your Macintosh uses its random-access memory (RAM) in order to work efficiently with large programs or with several programs at once.

Checking memory use

You can find out how much memory your computer has, how much of it is available, and how much memory is being used by each program you have open. You find this information by making the Finder the active program and choosing About This Macintosh from the Apple menu.



Making the most of your memory

Remember the following tips on memory management:

- Closing a document window does not quit the program. The program remains open and uses memory until you choose Quit from the File menu. (The Application menu, at the right end of the menu bar, shows which programs are open.)
- If you have opened and quit several programs, your computer's memory may be fragmented and you may not be able to open a program that requires a lot of memory. To solve this problem, you can restart your computer.
- If you're not using network services (such as electronic mail or a shared printer), you can make more memory available by turning off AppleTalk in the Chooser and restarting your computer.
- If you're not sharing files over a network, you can make more memory available by turning off file sharing. (See the chapter on networking for more information.)
- Removing system extensions you don't need makes memory available (for example, you don't need the AppleShare extension if your computer will never be on a network and you don't use AppleTalk Remote Access).

continues ▶

- Reducing the size of the disk cache makes more memory available. (See the disk cache section in this chapter.)
- Reducing the amount of memory a program uses may allow you to open more programs at once (see the chapter on setting up your programs).

Adjusting the disk cache

The disk cache is memory set aside to help programs work more quickly and efficiently. But the memory in the disk cache is not available for opening programs or documents. If you often want to open more programs than memory allows, you can set the disk cache to a smaller size.

You set the size of the disk cache in the Memory control panel.

1. **Choose Control Panels from the Apple ( ) menu and open the Memory control panel.**

2. **Click the up or down arrows next to the Cache Size box.**



3. **Choose Restart from the Special menu.**

Using hard disk space as memory

Your computer can use space on a hard disk to increase the memory available for opening programs. The disk space, called virtual memory, is not available for storing files.

Your computer should contain enough built-in memory for your regular needs—that is, for the programs you frequently have open simultaneously. You can use virtual memory when you want to open additional programs or work with extremely large documents.

Virtual memory is most effective when you are using several small programs simultaneously. It slows the computer's performance if you're using one very large program.

You adjust the use of virtual memory in the Memory control panel.

1. **Choose Control Panels from the Apple (🍎) menu and open the Memory control panel.**

2. **Click the On button to turn on virtual memory.**
3. **Press the pop-up menu and drag to choose a hard disk to use for virtual memory.**
4. **Click the up and down arrows to set the amount of disk space to be used as virtual memory.**



The preset amount is equal to the amount of RAM installed in your computer. Choosing a larger amount of virtual memory is likely to slow the computer's performance, so it is recommended that you accept the preset size.

continues ▶

5. **Choose Restart from the Special menu.**

After you restart, your computer's total memory includes the virtual memory you set aside on the hard disk. Choose About This Macintosh from the Apple (🍎) menu to see memory use information.

△ **Important:** When you turn on virtual memory, the system software creates a file named VM Storage in your System Folder (if the startup disk is used for virtual memory) or on the desktop (if another hard disk is used for virtual memory). This file is large—the size of the computer's RAM and the selected amount of virtual memory combined. For example, if your computer has 4 MB of RAM and you add 2 MB of virtual memory, the VM Storage file will occupy 6 MB of space on your startup disk. △

Turning on 32-bit addressing

Your computer can use very large amounts of memory (more than 8 megabytes) by taking advantage of a feature called 32-bit addressing—the use of very long (32-digit) binary numbers to control the way data is manipulated.

You can turn 32-bit addressing on or off in the Memory control panel.

1. **Choose Control Panels from the Apple (🍎) menu and open the Memory control panel.**

2. **Click the appropriate buttons in the control panel.**



3. **Choose Restart from the Special menu.**

Chapter 12

Printing

In this chapter

- Before you print
- Printing your work
- Controlling background printing
- Working with fonts

Before you print

Before you can print, your computer must be connected to a printer, either directly or over a network. See the information that came with your printer for instructions on how to connect it, or check with your network adminstrator.

Choosing a printer

Once your printer is connected, you must tell your computer which printer to use by choosing that printer. You need to do this even if only one printer is connected to your computer. You choose a printer when you're using it for the first time and whenever you change printers.

You choose the printer in a program called the Chooser. How you use the Chooser depends on whether your printer is connected directly or over a network.

If your printer is connected directly to your computer

Make sure you've connected the printer according to the instructions that came with it.

1. **Choose Chooser from the Apple ( ) menu.**
2. **Click the icon of your printer to select it.**



❖ *If your printer's icon does not appear in the Chooser:* The printer software is not in your System Folder. Close the Chooser and install the software you need. If you have an Apple printer, you can use the Installer to add the printer software. If your printer is not an Apple printer, see the information that came with it for instructions on installing its software. ❖

If you have a Personal LaserWriter SC, you're finished. Close the Chooser now.

3. **Click the icon of the port to which your printer is connected.**

   If your printer is connected to the computer's modem port (marked with the icon), you're finished. Close the Chooser now.

   If your printer is connected to the computer's printer port (marked with the icon), continue with step 4.

4. **Click the Inactive button next to the word "AppleTalk."**

   If Inactive wasn't already selected, a message appears. Click OK.

5. **Close the Chooser window.**

If your printer is connected over a network

Ask your network administrator or the person who set up your computer to tell you

- which printer you can use
- which zone it's in (if the network has zones)
- what its name is (every printer on a network has its own name)

1. **Choose Chooser from the Apple ( ) menu.**
2. **Click the Active button next to the word "AppleTalk."**

   If Active wasn't already selected, a message appears. Click OK.



3. **Click the icon of the printer you want to use.**

❖ *If your printer's icon does not appear in the Chooser:* The printer software is not in your System Folder. Close the Chooser and install the software you need. If you have an Apple printer, you can use the Installer to add the printer software. If your printer is not an Apple printer, see the information that came with it for instructions on installing its software, or check with the network adminstrator. ❖

4. **If the Chooser lists AppleTalk zones, click the zone where the printer is located.**

   Zones are listed alphabetically. You can also type to select a zone.

5. **Click the name of the printer you want to use (even if only one name appears).**
6. **If you want to continue using your computer while your documents are being printed, click the On button next to Background Printing.**

   Background printing is not available with all printers. If it's not available, these buttons do not appear.

7. **Close the Chooser.**

Selecting Page Setup options

You use the Page Setup dialog box when you've selected a new printer in the Chooser, or when you want to use a different paper size or printing options.

- Choose Page Setup from the File menu and select the options you want.

When a LaserWriter printer is selected, this or a similar Page Setup dialog box appears:



When an ImageWriter printer is selected, this Page Setup dialog box appears:



Each type of printer offers different options. Some programs provide additional options. You can choose Show Balloons from the Help menu and then point to options to see descriptions, or check your printer or program manual for details.

Updating printer software on networked computers

All computers that share printers on a network must have the same version of the printer software. The printer restarts itself each time a different version is used (which takes time and clears any fonts from its temporary memory).

△ **Important:** All computers on a network must have the same printer software versions in the System Folder. △

You or your network administrator should update the printer software on all Macintosh computers on the network. You do not have to update any files other than the printer software.

To update printer software, use the Installer program and the accompanying Printer Update document (both files are on one of the system software disks that came with your computer, or they may be on a shared disk on the network).



1. **Locate the Installer and Printer Update files, and then open the Installer icon.**
2. **Click OK.**

   The Easy Install dialog box appears.
3. **Make sure that the hard disk indicated is the correct one.**

   Click the Switch Disk button until the correct disk name appears.
4. **If you want to install software for additional printers, click the Customize button, and then select the names of the printers you want to install software for.**

continues ▶

If you want to update the printer software that is already installed on your disk, go to step 5.

When you click Customize, the custom installation dialog box shows a list of printer software.



5. **Click Install.**
6. **When you see a message reporting that installation was successful, click Restart.**

   If a message reports that installation was not successful, try again.

Printing your work

You can print a document while it's open and its window is active; you can also print documents while the Finder is active.

1. **Make sure that the document you want to print is in the active window.**

   If you're printing in the Finder, select the documents you want to print.

2. **Choose Print from the File menu.**

   The printing options that appear depend on the selected printer and the program in which the document was created.



- *Printing color or gray-scale documents:* You can print color or gray-scale documents on any color printer that can use the LaserWriter printer software. If you print a color document on a black-and-white printer, the document is produced as a halftone (that is, it is composed of patterns of dots).

Some programs offer additional printing options. See the manuals that came with your programs for more information on their printing features.

3. **Click Print.**

   A status message appears. If background printing is turned on, the message disappears after a few seconds, and you can do other work while printing continues. Instructions on controlling background printing are in this chapter.

Printing the contents of a window or the desktop

You can print a list of the contents of the active window when you're working in the Finder.

1. **Make sure that the window whose contents you want to print is active.**
2. **Choose Print Window from the File menu.**
3. **Select the options you want.**
4. **Click Print.**

   The window's contents are printed, including items not visible on the screen.

When no window is active, you can print the items on the desktop by choosing Print Desktop from the File menu.

Solutions to common printing problems

If nothing happens or if you see an error message when you try to print, try the following:

- Make sure that the printer is turned on and warmed up.
- Check the cable connections to the printer.
- If your printer is an ImageWriter, make sure that the Select light is on. (If not, press the Select button.)
- Make sure that the printer has paper and that the paper is feeding properly.
- Make sure that a printer (and its name or port) is selected in the Chooser.
- If you're on a network, make sure that you are using the same version of the printer software as everyone else.
- If an error message states that the printer could not print your document, turn off the printer for at least 10 seconds. Then turn it on again, wait for the printer to warm up, and try to print again.

If fonts printed on a laser printer look jagged or if lines or letters are missing, your computer may not have enough memory available to print your document properly, the font may not be available in your printer, or the font substitution option may be turned off in the Page Setup dialog box. Try the following:

- Make sure font substitution is turned on in the Page Setup dialog box.
- With background printing turned on, quit the program you're using immediately after you choose the Print command.
- Transfer the fonts you need to your printer (see the section on transferring fonts in this chapter).
- Make use of fewer fonts and sizes in your document.

Controlling background printing

If you are using a LaserWriter or StyleWriter printer and the background printing option is turned on in the Chooser, you can continue to work while your documents are printing.

You don't need to do anything once background printing is turned on. But if you wish, you can control background printing with PrintMonitor, a program that's part of system software.

1. **After you have started printing a document, choose PrintMonitor from the Application menu.**

   A few moments after printing begins, PrintMonitor opens automatically and its name appears in the Application menu.



You can use PrintMonitor to

- check the printing of your document
- cancel a document that's printing or waiting to print
- set the date and time you want a document to print or postpone printing indefinitely
- check the paper supply

  PrintMonitor's icon blinks at the right end of the menu bar when the printer is out of paper. You can change this alert signal with the Preferences command in the File menu.

- check when to feed paper manually

  PrintMonitor's icon blinks at the right end of the menu bar to signal that you must confirm manual printing. You can change this alert signal with the Preferences command in the File menu.

2. **Select the options you want, and then close the PrintMonitor window.**

Working with fonts

A font is a collection of letters, numbers, and symbols in a distinctive typographic design.

Several fonts come with your computer's system software. They are stored in the Fonts folder (inside the System Folder on your startup disk). You can install additional fonts and remove fonts.

Additional fonts are supplied on one of the system software disks. Fonts are also available from independent manufacturers, user groups, and electronic bulletin board services.

Outline fonts and bitmap fonts

The Macintosh uses two types of fonts:

- outline fonts
- bitmap fonts

Both types of fonts are installed in your System file when you install system software.

Outline fonts (also called scalable or variable-size fonts) can appear at any size, because each character is described as a mathematical formula that adjusts according to the size you want.



Your computer needs only a single outline font in a particular typeface (such as Courier) to display or print that typeface in any size. The outline fonts supplied with Macintosh system software are called TrueType fonts.

Bitmap fonts (also called fixed-size fonts) appear only in certain sizes, because each character is a grid of black-and-white dots (called a bitmap), which is a rendering of the character's shape in a specific size.



For the best type quality when using bitmap fonts, your computer needs a separate bitmap font in each size you want to display or print, such as 12-point Times or 9-point Monaco.

Installing fonts

1. **Quit all open programs.**
2. **Locate the font you want to install, and drag it to the System Folder icon (not the System Folder window) on your startup disk.**

   Fonts are supplied either as individual files (for individual fonts) or in suitcases (for font families). To install an entire font familiy, drag its suitcase to the System Folder. If you want to install an individual font within a family, open the appropriate suitcase to see the individual font files.

   A message lets you know that the font will be stored in the Fonts folder.
3. **Click OK.**

Removing fonts

1. **Quit all open programs.**
2. **Open the System folder on your startup disk.**
3. **Locate the Fonts folder and open it.**

   The Fonts folder contains font files (for individual fonts) and font suitcases (for font families). If you want to remove an individual font within a family, open the appropriate suitcase to see the individual font files.

4. **Locate the font you want to remove, and drag it out of the Fonts folder window and out of the System Folder window.**
5. **Close the Fonts folder window and the System Folder window.**

Transferring fonts to a LaserWriter printer

If you're using a LaserWriter printer equipped with PostScript and you want to print with PostScript fonts that are not built into your printer, you can transfer, or download, those fonts from your System Folder to the printer. Downloading fonts saves printing time if you plan to print several documents that use those fonts.

When you download a font, it's stored in the printer's memory or on a hard disk attached to the printer. You can download as many fonts as the printer's memory and hard disk space allow.

You download fonts with the LaserWriter Font Utility, which is supplied on one of the system software disks.

1. **Locate and open the LaserWriter Font Utility icon.**

2. **Choose Download Fonts from the File menu.**
3. **If the font you want to download is not listed, click the Add button to add fonts to the list.**



Use the directory dialog box that appears to locate the fonts you want.

4. **In the directory dialog box, locate your font, click its name, and then click Add.**



5. **When you've added all the fonts you want to download, click Done.**

   The fonts you added are listed in the Font Utility dialog box.

6. **Click Download to send all the fonts in the list to the printer or its hard disk.**
7. **Click OK when downloading is finished.**
8. **Choose Quit from the File menu.**

Finding out about available fonts

Many programs have a Font menu that lists the fonts installed in your system, though some programs do not list them all. You can open the Fonts folder, inside the System Folder, to see all the fonts stored there. You can also see available fonts with the Key Caps desk accessory in the Apple (🍎) menu.

The LaserWriter Font Utility program (supplied with the system software disks) provides three ways to see the fonts available for printing on a LaserWriter: you can display a list of fonts on the screen, print a font catalog, or print a set of font samples.



Other ways to use the LaserWriter Font Utility

You can also use the LaserWriter Font Utility program to

- initialize a hard disk attached to a printer
- control whether a start page is printed
- restart a printer
- send PostScript files to a printer

Initializing a hard disk attached to a printer

You can attach a hard disk to some printers. A hard disk allows you to store more fonts. See the manual that came with your printer for information about connecting a hard disk.

1. **Make sure the corret printer is selected in the Chooser.**
2. **Open the LaserWriter Font Utility icon.**
3. **Choose Initialize Printer's Disk from the File menu.**
4. **Click the Drive button until you see the name of the hard disk you want to initialize.**
5. **Click Initialize.**

   Initializing erases any information that was on the hard disk.

Restarting a LaserWriter printer

Restarting the printer clears its memory, removing the fonts stored there.

1. **Open the LaserWriter Font Utility icon.**
2. **Choose Restart Printer from the Utilities menu.**
3. **Click Restart.**

Turning the printer's start page on or off

The LaserWriter can print a start page each time it is turned on or restarted.

1. **Open the LaserWriter Font Utility icon.**
2. **Choose Start Page Options from the Utilities menu.**
3. **Click the On or Off button.**



4. **Click OK.**

Transferring a PostScript file to a LaserWriter

You can use the LaserWriter Font Utility to send a file in PostScript format to a LaserWriter printer.

1. **Open the LaserWriter Font Utility icon.**
2. **Choose Download PostScript File from the Utilities menu.**
3. **Click the name of the file you want to download to the printer, and then click Open.**

   A dialog box asks you to save a file that will contain a record of the PostScript activity.



The name of a log that records PostScript activity

4. **Type a name for the log, and then click Save.**

   The file is sent to the printer and a record of the PostScript activity is saved in the log.

   You can open the log to see the sequence of PostScript commands when the file was sent.

Chapter 13

Using Your Computer on a Network

In this chapter

- What networking offers
- Setting up your Macintosh on a network
- Gaining access to files on shared disks
- Working with files and folders on other computers
- Sharing your own files
- Using access privileges
- Linking programs

What networking offers

When your computer is connected to a network, you can:

- Gain access to information on other computers.



- Allow others access to information on your own computer.



You can designate specific folders and hard disks on your computer as “shared files” that other people can gain access to.

- Print documents on network printers.



- Link your programs to programs on other computers.



You can link your programs in order to share features between those programs.

- Update files over the network automatically.



You can automatically update documents created in programs that use the Macintosh system software’s publish-and-subscribe feature. (See the instructions that came with your programs for information about publish-and-subscribe.)

Setting up your computer on a network

Before you can use your computer on a network, you need to physically connect your computer to the network and install networking software.

If a network administrator manages the network to which you’ll be connecting your computer, ask that person for advice or help.

Connecting to a network

Your computer has built-in AppleTalk networking software. This software directly supports the LocalTalk cables you need to connect your computer to the network. (If your computer has the appropriate port or expansion card, AppleTalk also supports Ethernet and TokenRing cables.)

1. **Choose Shut Down from the Special menu.**
2. **Connect the LocalTalk cable to the printer port (🖶) on the back of your computer.**

   If your computer has a combined printer/modem port, connect the LocalTalk cable to that port.

   See your network administrator or the documentation that came with your cables if you need more information.



Turning on AppleTalk

The first time you turn on your computer after you have connected it to a network, you need to make sure that AppleTalk is turned on.

1. **Choose Chooser from the Apple (🍎) menu.**
2. **Click the Active button to turn on AppleTalk.**



AppleTalk must be active before you can use a network.

continues ▶

3. **Close the Chooser.**

When AppleTalk is active, Macintosh PowerBook computers go to sleep automatically only when they run out of battery power, or when the power adapter is plugged in and the PowerBook is not connected to any shared disks on the network.

Naming your computer and its owner

Before you use the network, you should give your computer a name and name yourself as its owner.

1. **Choose Control Panels from the Apple (🍎) menu and open the Sharing Setup icon.**

❖ *If you can't find or can't open the Sharing Setup icon:* Check whether the Sharing Setup icon is in the Control Panels folder and the File Sharing and Network icons are in the Extensions folder inside the System Folder. If not, or if you still have problems, use the Installer to install the AppleTalk software. See the chapter on setting up your programs for more information. ❖

2. **Type your name in the box labeled Owner Name and press Tab.**

3. **Type your password in the box labeled Owner Password and press Tab.**

   Your password can be up to eight characters long. Remember the capitalization you use. After you press Tab, your password is replaced by bullets (•) so no one can read it.

4. **Type a name for your computer in the box labeled Macintosh Name.**

   This is the name others will see when they access your computer on the network.

5. **Close the Sharing Setup control panel.**

Gaining access to files on shared disks

You can retrieve and store information on other computers connected to your network. For example, a colleague can place some files for you on a shared disk called a file server—a computer dedicated to storing shared files. Individually owned computers on your network might also have shared disks.

Before you begin

Before you store or retrieve information on the network, do the following:

- Find out the name of the shared disk you want to access and the name of the computer that it's on.
- If your network has zones, find out the name of the zone that computer is in.
- Find out if you are registered on the computer or if it allows guest access.

  A computer owner or network administrator can limit access to files on a shared disk. Ask the owner or network administrator what type of access you have to the files.
- If you're a registered user, find out the name and password you need to use.

  Find out exactly how your name and password are spelled, including capitalization.

Connecting to a shared disk

1. **Choose Chooser from the Apple ( ) menu.**
2. **Make sure that AppleTalk is active.**
3. **Click the AppleShare icon in the upper-left section of the Chooser window.**



continues ▶

❖ *If the AppleShare icon does not appear:* Make sure that AppleTalk is active in the Chooser. Make sure that the AppleShare file is in the Extensions folder in your System Folder, and restart your computer. If that doesn't work, use the Installer to install the AppleTalk software. ❖

4. **If you see a box labeled AppleTalk Zones, click the zone the computer is in.**

   Computers with shared disks are listed as file servers on the network.

5. **Click the name of the computer you want to use.**

   If the name you want isn't listed, make sure you have selected the correct zone (if your network has zones), and make sure the other computer is turned on.

6. **Click OK.**

7. **Click Guest or Registered User.**



   If you are a guest, click Guest and go to step 10. If the Guest option is dimmed, guests do not have access to this computer.

8. **If you are a registered user, make sure the name in the box is correct.**

   Capitalization does not need to match.

9. **Type your password.**

   Capitalization does need to match.

10. Click OK.

If your password is not accepted: Make sure that Caps Lock is not on. Type your password again, taking care not to make typing errors. If it's still not accepted, ask the computer's owner for help.

11. Click the name of a shared disk to select it.



12. Click OK.

The icon of the shared disk appears on your desktop.

13. Close the Chooser.

Disconnecting from a shared disk

When you're finished using a shared disk, close any open files or programs on the shared disk and then disconnect in one of the following ways:

- Select the shared disk icon and choose Put Away from the File menu.
- Drag the shared disk icon to the Trash.
- Choose Shut Down from the Special menu. Shutting down automatically disconnects from the shared disk.

Connecting quickly to a shared disk

By making an alias for a shared disk, you can connect to that disk by simply opening the alias.

1. **Connect to a shared disk.**

   See the section on connecting to a shared disk in this chapter.

2. **Select the shared disk icon.**
3. **Choose Make Alias from the File menu.**
4. **Put the alias in a convenient location and rename it if you wish.**
5. **Next time you want to connect to the shared disk, open the alias you created in step 3.**
6. **If you originally connected to the shared disk as a registered user, a message appears. Type your password.**

   If you connected to the shared disk as a guest, this message does not appear.

   The shared disk icon appears on your desktop.

   If the shared disk is on a computer that is turned off, or if there is a problem with the network, you'll see a message.

Connecting automatically when you start up

You can connect automatically to one or more shared disks whenever you turn on your computer.

1. **Connect to the computer that has the shared disk you want to open.**

   See the section on connecting to a shared disk in this chapter.

2. **Click the checkbox next to the name of the shared disk.**



3. **If you're connecting as a registered user, click the button that indicates whether you want to save your name only, or both your name and your password.**

   For more security, click "Save My Name Only." When you start up your computer, you'll need to enter your password to connect to the shared disk.

4. **Click OK.**

5. **Close the Chooser.**

Reconnecting a PowerBook to shared disks

Your computer disconnects from any shared disks it's connected to when you turn it off or restart it. If you have a Macintosh PowerBook computer, you can reconnect to those shared disks when you turn your computer back on (or wake it from sleep) by using the AutoRemounter control panel.

1. **Choose Control Panels from the Apple (🍎) menu and open the AutoRemounter control panel.**

2. **If you want to reconnect to shared disks only when you wake the computer from sleep, click the After Sleep button.**

   If you always want to reconnect (that is, after you restart the computer as well as after sleep), click the Always button.



3. **If you do not want to enter your password when you reconnect to shared disks, click "Automatically Remounting." Otherwise, click "Always Entering Passwords."**

   Having your computer ask for your password better protects your privacy and the security of shared disks.

4. **Close the AutoRemounter control panel.**

Working with files and folders on other computers

Once you are connected to a shared disk, you can use the files and folders on it as if they were on your own computer.

You may not be able to open some items on a shared disk if the owner has restricted access to those items. For information on how to check your access privileges, see "Working With Privileges That Others Have Set" later in this chapter.

Creating a new folder on another computer

You can create a new folder on a shared disk (as long as you have the correct access privileges). If you are a registered user, you become the owner of any folder that you create. If you are connected as a guest, you share ownership of the folder with all guests and registered users.

The icons of folders that you own on another disk have a darkened tab.

When you own a folder, you can determine who can use it and in what way. See "Using Access Privileges" later in this chapter for more information.

Changing your password

If you are a registered user, you may be able to change the password you use to connect to a shared disk. (Your network administrator can restrict this capability.)

1. **Connect to the computer that has the shared disk you want.**
2. **Click the Set Password button.**



If a message tells you that you cannot change your password, your network administrator has turned off this feature.

3. **Type your current password. Then press Tab and type a new password.**

   A bullet (•) appears for each letter you type.

4. **Click OK.**
5. **Click OK in the dialog box that appears.**
6. **Retype your new password and click OK.**

   Your new password is now in effect.

Giving folder ownership to someone else

You can give away ownership of any folder you own. Once you do so, however, the new owner can restrict your access to that folder. Make sure you have copies of any files you may need before you give ownership of a folder to someone else.

1. **Connect to a shared disk.**
2. **Click a folder that you own to select it.**
3. **Choose Sharing from the File menu.**
4. **Type the name of a registered user or group in the box labeled Owner.**
5. **Close the Sharing window.**

   A message asks you to confirm that you want to change the owner of the folder.

6. **Click OK.**

   The user or group that you named assumes ownership immediately.

Sharing your own files

You can share files stored on your computer with others on the network. For example, members of your work group can connect to your computer and open a file from their own computers. (They do not have to be using System 7.) Or, if you have both a desktop Macintosh and a PowerBook computer, you can transfer files from one computer to the other without using floppy disks.

You control what you share and with whom you share it:

- You share only the items you specify.
- You share only with the people you specify—one person, a group of people, or everyone on the network.
- You can see everything on your own computer from another computer on the network.

How file sharing works

There are three steps to sharing a folder or disk:

1. turn on file sharing
2. select a folder or disk to share
3. decide whom to share it with

The folder or disk you share is not accessible to anyone but you until you choose whom to share it with.

Turning file sharing on

1. **Choose Control Panels from the Apple ( ) menu and open the Sharing Setup icon.**



Make sure the boxes in the Network Identity section of the control panel are filled in.

2. **In the section labeled File Sharing, click the Start button.**



3. **Close the Sharing Setup control panel.**

If you want to give everyone on the network access to the items you share, continue with the next section, “Turning On Guest Access.”

Turning on guest access

If you want all users connected to the network to have access to your shared folders and disks, you need to turn on guest access.

1. **Choose Control Panels from the Apple (🍎) menu and open the Users & Groups control panel.**



2. **Open the <Guest> icon.**

3. **Click the box under File Sharing labeled “Allow guests to connect” to place an X in it.**



4. **Close the window and click Save in the box that appears.**

You can still restrict access to any folder or disk you share, as described in the section “Using Access Privileges,” later in this chapter.

Continue with the next section to select a folder or disk to share.

Selecting a folder or disk to share

You can share any folder, hard disk, or CD-ROM disc connected to your computer. (You cannot share floppy disks.) You can share up to ten folders or disks at a time. (This number does not include folders within the folders or disks you share.)

1. **Make sure file sharing is turned on.**
2. **Select a folder or disk to share.**
3. **Choose Sharing from the File menu.**
4. **Click the box labeled "Share this item and its contents" to place an X in it.**



For information about the other checkboxes in this window, see "Using Access Privileges," later in this chapter.

5. **Close the window and click Save in the dialog box.**

At this point, only you have access to the item you shared and the files inside it, unless you turned on guest access and some or all of the boxes next to "Everyone" are checked.

If you haven't turned on guest access, continue with the section "Naming a Registered User" if you want to name the specific people you want to share the item with. (Even if the checkboxes next to Everyone are selected, you cannot give access to everyone unless you've turned on guest access, as described in the previous section.)

If you shared a folder, its icon appears with a darkened tab and network cables:



When people on the network are connected to your shared folder, its icon appears with faces in the center:



△ **Important:** Before you put programs inside shared folders or disks, remember that copyright laws may prevent those programs from being shared. Check the applicable licensing agreements and follow their specifications. △

Taking back a shared folder or disk

Any shared folder or disk can be made private again.

1. **Select the shared disk icon.**
2. **Choose Sharing from the File menu.**
3. **Click the box labeled "Share this item and its contents" to remove the X.**

   If people are connected to your computer, you see a message asking you to confirm your decision.

Naming a registered user

You can register as many as 100 people and groups combined, but for best network performance you should name no more than 50.

1. **Choose Control Panels from the Apple (🍎) menu and open the Users & Groups icon.**

2. **Choose New User from the File menu.**

   An icon labeled New User appears. Its name is selected for editing.

   If you can't find the New User command: Make sure the Users & Groups window is active.

continues ▶

3. **Type the name of a person you want to register.**

   Make sure you notify the person of the name you type. (Capitalization does not have to match.)



4. **To register more users, repeat steps 2 and 3.**

   To assign passwords or to name groups of users, continue with the next two sections. If you want to start sharing immediately, go to "Selecting a User or Group to Share a Folder or Disk," later in this chapter.

Setting a registered user's password

You can assign passwords for registered users to verify their identities when they want to gain access to your computer.

1. **Open a user icon in the Users & Groups control panel.**



2. **Type a password in the User Password box, then press Tab.**

   The password can be up to eight characters long. When you press Tab, the password is replaced by bullets. Make sure to inform the user of the exact password, *including capitalization.*

3. **Close the window, and then click Save in the dialog box.**

Naming a group of users

You can name several registered users as a *registered group.*

1. **Open the Users & Groups control panel and choose New Group from the File menu.**

   An icon labeled New Group appears. The name is selected for editing.



2. **Type a name for the group.**

3. **Drag user icons to the new group icon.**

   The icons are not moved inside the group icon, as they would be if it were a folder. Instead, member icons are created inside the group icon. You don't need to drag your own icon to the group icon because you (as the owner) have access to the entire contents of your computer (unless you specify otherwise).

   You don't need to include the <Guest> icon in any group.

   To allow this group access to a shared folder or disk, go to the section "Selecting a User or Group to Share a Folder or Disk."

Seeing who's in a group

- **To see the names of all group members, open the group icon.**



You can open any member icon to see or change the settings you've made for that user.

continues ▶

- **To see all the groups that a user belongs to, open the user's member icon or user icon.**



Selecting a user or group to share a folder or disk

You can give one registered user or group exclusive access to a shared folder or disk on your computer.

1. **Select a folder or disk to share.**
2. **Choose Sharing from the File menu.**
3. **Click the box labeled "Share this item and its contents" so an X appears.**
4. **Choose a user or group from the User/Group pop-up menu.**



5. **To share the item with only the user or group you've chosen, click the bottom row of checkboxes (next to Everyone) to remove the X from each box.**



6. **Close the window and click Save in the dialog box.**

Preventing specific users or guests from accessing your computer

To prevent all network access to your computer, you can turn file sharing and program linking off, as described elsewhere in this chapter.

1. **Choose Control Panels from the Apple (🍎) menu and open the Users & Groups icon.**

continues ▶

2. **To deny access to a specific user, open the user icon.**



To deny access to guests, open the <Guest> icon.



3. **If an X appears in the "Allow to connect" checkbox, click to remove the X (to deny access).**

4. **Close the window and click Save in the dialog box.**

   If you deny access to a user who is currently connected, he or she is disconnected immediately. That user is no longer a member of any group, and can connect only as a guest.

   If you deny access to guests, any guests currently connected are disconnected immediately. Only registered users and groups that you've specified will have access to your computer.

Removing a user from a group

1. **In the Users & Groups control panel, open the group icon.**
2. **Drag the member icon for that user to the Trash.**
3. **Choose Empty Trash from the Special menu.**

Removing a user or group from your list of registered users

You can remove a registered user or group at any time. When you remove a user, he or she will no longer be a member of any registered group.

1. **Open the Users & Groups control panel.**
2. **Drag the user icon or group icon to the Trash.**
3. **Choose Empty Trash from the Special menu.**

If the user is currently connected, he or she is disconnected immediately.

You cannot throw away the <Guest> icon or the owner icon.

Giving away ownership of a folder or disk on your computer

You can give away ownership of a shared folder or disk on your computer to a registered user or group.

Because you are the owner of your computer, the new owner of a folder or disk on your computer cannot restrict your access to it. However, the new owner can change the access privileges that other people have to the item. If you give away ownership of a folder or disk, make sure to remove any folders or documents that you don't want others to see or change.

1. **Select a shared folder or disk.**
2. **Choose Sharing from the File menu.**
3. **Choose a name in the Owner pop-up menu.**



continues ▶

If you select <Any User>, then anyone on the network can change the access privileges or ownership of the item.

4. **Close the window and click Save in the dialog box.**
5. **Click OK to confirm that you want to change ownership.**

Turning file sharing off

You can turn file sharing off at any time. When file sharing is off, people on the network cannot access folders or disks on your computer, and you cannot access your computer from another computer on the network.

When you turn file sharing back on, the items you shared before are available again automatically.

1. **Choose Control Panels from the Apple (🍎) menu and open the Sharing Setup icon.**



2. **In the section labeled File Sharing, click the Stop button.**

   A dialog box appears in which you can specify a delay before file sharing is turned off. If you specify a delay, users who are connected to your computer are warned to save their work and disconnect.



3. **Type the number of minutes you want to elapse before file sharing is turned off.**

   To turn file sharing off immediately, type the number 0.

4. **Click OK.**

If someone is using files on your Macintosh when file sharing is turned off, any changes he or she has not saved will be lost.

Monitoring file-sharing activity

When file sharing is on, you can see who is connected to your computer and what folders or disks you've shared.

- **Choose Control Panels from the Apple (🍎) menu and open the File Sharing Monitor icon.**



Disconnecting someone who is connected to your computer

You can disconnect users who are currently connected to your computer in the File Sharing Monitor control panel.

1. **Select the user or users you want to disconnect.**
2. **Click Disconnect.**
3. **Type the number of minutes that you want to elapse before users are disconnected.**



If you specify a delay, users are warned to save their work and disconnect. To disconnect a user immediately, type 0.

continues ▶

4. **Click OK.**

   A message remains on the screen until the time is up. You can switch to any program you already have open so you can continue working.

5. **When the designated amount of time has elapsed, close the File Sharing Monitor.**

Gaining access to your computer from another computer

You can connect to your own computer from another computer on the network and access everything on the disks attached to your computer.

1. **Make sure that file sharing is turned on.**
2. **Choose Control Panels from the Apple (🍎) menu and open the Users & Groups icon.**

3. **Open the owner icon (the one with the bold outline).**
4. **Click the boxes labeled “Allow user to connect” and “Allow user to see entire disk” to place an X in them.**



When these boxes are checked, you can see and use everything on your disks while you’re using another computer.

To restrict your access, click a checkbox to remove the X.

5. **Close the window and the Users & Groups control panel.**

6. **Leave your computer turned on.**

To gain access to your computer, connect to it as a registered user. Type your owner name and password as they appear in the Sharing Setup control panel of your computer. Then connect as you normally would.

❖ *If you are unable to connect to your computer:* Make sure that your computer is turned on, that your computer has file sharing turned on, and that you have the correct access privileges. Make sure that you type your password exactly as it is entered in the Sharing Setup control panel, including capitalization. ❖

Changing your password

You can change the password you use to gain access to your own computer from another computer.

1. **Choose Control Panels from the Apple (🍎) menu and open the Sharing Setup icon.**



2. **Type a new password in the box labeled Owner Password and press Tab.**



Remember the capitalization. Your password is replaced by bullets to keep it private.

3. **Close the Sharing Setup control panel.**

Your new password is now in effect.

Using access privileges

Access privileges let you control what other people can do with the information you share on a network. For example, you might want to let people see a file but prevent them from changing it.

Understanding access privileges

You can set access privileges for any shared folders on your own computer and any folders you create on another Macintosh. Owners of other computers can set access privileges that restrict what you can do with their shared disks.

Three categories of people can have access privileges to shared disks and folders:

- **The owner:** The owner of a folder can change the access privileges to that folder. You become the owner of a folder automatically when you create it and you are the owner of any folder on your computer. You can keep ownership or give it away.
- **A registered user or group:** A registered user has special access to shared disks over the network. A registered group is a group of registered users.
- **Everyone:** This category includes the owner, registered users, and guests.

There are three types of access to shared items:

- **See Folders:** allows people to see, open, and copy folders.
- **See Files:** allows people to see, open, and copy files.
- **Make Changes:** allows people to copy, delete, or change the contents of a folder or disk, or to add items to a folder or disk.

The table indicates which privileges you need to see folders, see files, or make changes to items in a shared folder or disk.

Action	See Folders	See Files	Make Changes
Copy or move files to a folder	☐	☐	☒
Copy a file from a folder	☐	☒	☐
Copy a folder from a folder	☒	☐	☐
Create a folder in a folder	☒	☐	☒
Delete a file from a folder	☐	☒	☒
Delete a folder from a folder	☒	☐	☒
Open and use a file in a folder	☐	☒	☐
Save changes to a file in a folder	☐	☒	☒

Setting access privileges to folders and disks

You can set access privileges for shared items on your own computer and for items that you own on other computers.

1. **Select a folder or disk.**
2. **Choose Sharing from the File menu.**

   The dialog box you see may be slightly different from the one pictured.



- If you've selected a folder inside a shared folder, the checkbox at the top is labeled "Same as enclosing folder."
- If you've selected a folder on another computer, the Owner and User/Group areas are text boxes, not pop-up menus.
- If you've selected a folder you do not own, all the checkboxes and their labels are dimmed.

3. **Choose a registered user or group to share the item with.**

   Choose from the list of users and groups in the pop-up menu, or type the name of a registered user or group in the box.

4. **To set access privileges, click the appropriate checkbox.**

   - To set the same privileges for the folders within this folder or disk, place an X in the box labeled "Make all currently enclosed folders like this one." If you're working with an item that contains a large number of folders, such as a CD-ROM disc, this action may take a few minutes to complete.
   - To prevent the folder from being changed, place an X in the box labeled "Can't be moved, renamed, or deleted." If you check this box, no one—not even you—can change the folder. (The folder can still be viewed and copied.)
   - If you want the folder to have the same privileges that the folder or disk enclosing it has, place an X in the checkbox labeled "Same as enclosing folder." This box only appears for folders inside shared folders. When you move such a folder to another folder, its access privileges change automatically to reflect those of the enclosing folder.

5. **When you're finished setting access privileges, close the Sharing dialog box and then click Save in the dialog box.**

Access privilege strategies

Access privileges can be combined in several ways. A few common and useful strategies are summarized here.

- **Allow everyone on the network all access privileges.** As long as you've turned on guest access, everyone on the network can open, read, and change the files and folders.



- **Keep a folder or disk private.** To keep a folder or disk on your own computer private, do not share it. To keep your folder on another computer private, use these settings.



- **Allow access to one other person or group.** This set of privileges allows the owner of the item and one registered user or group to use the item.



- **Keep a folder private but allow others to place files or folders into it.** People on the network can deposit files or folders into this folder but only the owner can see, remove, or change its contents. (This configuration is sometimes called a *drop box*.)

	See Folders	See Files	Make Changes
Owner	☒	☒	☒
User/Group	☐	☐	☒
Everyone	☐	☐	☒

- **Set up a folder as a bulletin board.** People can open and read the files in this folder but cannot change them. Only the owner can add files.

	See Folders	See Files	Make Changes
Owner	☒	☒	☒
User/Group	☒	☒	☐
Everyone	☒	☒	☐

Working with privileges that others have set

When you are using the By Icon or By Small Icon view, the appearance of shared folders indicates the access you have.

Icon	Meaning
	A darkened tab indicates that you own the folder and can set its access privileges.
	A plain tab indicates that you can open and use the folder.
	A strap indicates that you cannot open and use the folder.
	A strap with an arrow indicates that you can put files or folders into the folder, but you cannot open it or use any files or folders within it.

Checking your access privileges

When you open a folder on another computer, icons under the title bar indicate the privileges that you do not have.



You can't make changes to files in this folder.



You can't see files in this folder.



You can't see folders in this folder.

Linking programs

Some programs can exchange information directly with other programs. For example, one program might be able to instruct another program to add a row to a spreadsheet or change the font size of a paragraph.

Programs implement linking in various ways and not all programs have this capability. See the documentation that came with your programs for more information.

Linking to a program on another computer

You can only link to programs that are shared.

1. **Within your program, choose the menu command that allows you to link programs.**

   The menu location and command name depend on the program you're using. You use a dialog box to find the program that you want to link to.



2. **If your network has zones, select a zone in the lower-left section of the dialog box.**
3. **Select the Macintosh you want to connect to in the upper-left section of the dialog box.**
4. **Select the program you want to link to.**
5. **Click OK.**

   In most cases, you need to identify yourself as a guest or a registered user.



6. **Click Guest or Registered User.**

   If you are a guest, click Guest and go to step 9. If the Guest option is dimmed, guests do not have access to this computer.
7. **If you are a registered user, make sure that the name is correct.**
8. **Type your password.**
9. **Click OK.**

   The two programs are now linked.

Disconnecting a program link

To disconnect a link to a program on another computer, quit the program you used to create the link.

Allowing other people to link to your programs

You can allow people on the network to link to programs on your computer.

- First you turn on program linking.
- Then you make a program available for linking by sharing it.
- Then you either allow guest access or allow specific people to link.
- Finally, you open the program.

These steps are outlined in the following sections.

Turning program linking on

When you turn program linking on, your computer is visible to others on the network whenever they attempt to link a program. Before you turn program linking on, make sure that AppleTalk is active and that you have named your Macintosh in the Sharing Setup control panel.

1. **Choose Control Panels from the Apple (🍎) menu and open the Sharing Setup icon.**
2. **In the section labeled Program Linking, click the Start button.**



3. **Close the Sharing Setup control panel.**

   Once program linking is turned on, you must select programs to share before network users can link to them, as described in the next section.

Selecting a program for linking

Before a network user can link to your program, you need to share it.

1. **Quit the program if it's open, then click its icon to select it.**
2. **Choose Sharing from the File menu.**
3. **Click the box labeled "Allow remote program linking" to place an X in it.**



If the box is dimmed, the program does not support linking.

4. **Close the window.**

   At this point, no one but you can link to the program until you turn on guest access or name registered users, as described in the following sections.

5. **Open the program.**

Allowing guests to link to your programs

You can let everyone on the network link to your shared programs.

1. **Choose Control Panels from the Apple (🍎) menu and open the Users & Groups icon.**
2. **Double-click the <Guest> icon.**
3. **Click the box labeled "Allow guests to link to programs on this Macintosh" to place an X in it.**



4. **Close the window.**

   Guest users can now link to any of the programs you're sharing, as long as the programs are open.

Naming specific users to link to your programs

You can identify the registered users and groups you want to link to your programs.

1. **Choose Control Panels from the Apple (🍎) menu and open the Users & Groups icon.**
2. **Open the icon of a user.**
3. **Click the box labeled "Allow user to link to programs on this Macintosh" to place an X in it.**



4. **Close the window and click Save in the dialog box.**
5. **To give more registered users access to your programs, repeat steps 2 through 4.**

Chapter 14

Expanding Your Computer System

In this chapter

- Using SCSI devices
- Using your PowerBook as a SCSI disk
- Using an external monitor
- Connecting a modem
- Connecting a printer
- Connecting a mouse or other ADB device
- Using sound input and output devices
- Adding memory to your computer

Using SCSI devices

A SCSI device is any product—including hard disk drives, CD-ROM drives, scanners, and printers—that communicates with Macintosh computers by means of a standard electronic interface. (SCSI stands for Small Computer System Interface.) You can attach up to six SCSI devices to your computer by linking them together in a chain that starts at your computer's SCSI port.

The SCSI port on Macintosh PowerBook computers looks like this:



To connect a SCSI device to the SCSI port on your PowerBook, you need an Apple HDI-30 SCSI System Cable.

Setting up one or more SCSI devices for use with your PowerBook involves the steps listed here.

- installing software
- setting SCSI ID numbers
- checking that the SCSI chain is properly terminated
- connecting cables

These steps are described in the following sections.

Installing software

Most SCSI devices come with software that allows your computer to communicate with them. These programs are called drivers. (If no drivers come with a device, then it doesn't need any.) To install a driver, follow the instructions that came with the device.

Setting SCSI ID numbers

Each device in a SCSI chain must have a unique ID number between 1 and 6 so the computer can identify it properly. The information in this section can help you assign SCSI ID numbers to the devices you want to use with your computer.

▲ **Warning:** Using two or more devices with the same SCSI ID number can cause your equipment to malfunction. You could lose information as a result. ▲

Your computer has the SCSI ID number 7, and its internal hard disk has the number 0.

See the documentation that came with your SCSI devices for information about ID numbers and how to change them.

The ID numbers of Apple SCSI devices can be set as follows.

1. **Make sure the SCSI device is turned off.**

   If the device is already part of a SCSI chain, make sure that all devices in the chain are turned off, including the computer.

2. **Locate the ID number indicator and switch (usually on the back panel of the SCSI device).**



3. **Check the ID numbers of all the devices you want to connect.**

   If all the devices have unique ID numbers, you've finished this part of the procedure. Continue with the next section, "Checking That the SCSI Chain Is Properly Terminated."

4. **If you need to change a device's ID number, choose an available number between 1 and 6.**

5. **Insert the end of a straightened paper clip into the small hole below the ID number indicator.**

   The small hole gives you access to the ID number switch.

6. **Push the ID number switch repeatedly until the number you want appears in the ID number indicator.**

Checking that the SCSI chain is properly terminated

To ensure accurate transmission of information, a chain of SCSI devices must have a terminator at each end. Terminators are built into some SCSI devices and can also be added externally.



SCSI terminator

- Your PowerBook's internal hard disk, which is always the first device in the chain, has a small built-in terminator. However, for reliable information transfer in a chain of SCSI devices, it should be supplemented with an external terminator as described in these instructions.
- External SCSI devices from Apple do not have built-in terminators.
- External SCSI devices from other vendors may have built-in terminators; see the documentation that came with the device.

If you are attaching one SCSI device

Make sure that there is

- an external terminator between the HDI-30 system cable and the SCSI device *and*
- an internal terminator in the SCSI device, *or* an external terminator attached to the device.

If you are attaching more than one SCSI device

Make sure that there is

- an internal terminator in the first external device, *or* an external terminator between the HDI-30 system cable and the first device;
- an internal terminator in *or* an external terminator attached to the last device; *and*
- no other terminator (internal or external) in the chain.

If you have too many devices with internal terminators, your authorized Apple service provider can remove extra terminators.

Correct chain configurations are shown in the illustration on the following page.

Connecting cables

▲ **Warning:** When making SCSI connections, *always* turn off power to all devices in the chain. Failure to do so can cause the loss of information and damage to your equipment. ▲

1. **Shut down your PowerBook and all SCSI devices in the chain.**
2. **To connect the first device, use an Apple HDI-30 SCSI System Cable.**

   Attach the smaller end of the cable to your computer's SCSI port (marked with the icon ⟐) and the larger end of the cable to either SCSI port on the device.
3. **To connect the next device, use a SCSI peripheral interface cable.**

   Both cable connectors are the same. Attach one connector to the available SCSI port on the first device, and the other connector to either SCSI port on the next device.
4. **Repeat step 3 for each additional device you want to connect.**

The illustration shows where to add cable terminators.



△ **Important:** The total length of a SCSI chain should not exceed 20 feet (6 meters). Apple SCSI cables are designed to meet this restriction. If you are using SCSI cables from another vendor, check the length of the chain. △

Once your SCSI devices are connected, always turn them on before turning on your PowerBook. If you turn the computer on first, it may not be able to start up, or it may not recognize the SCSI devices.

Using your PowerBook as a SCSI disk

If you have an optional cable called the Apple HDI-30 SCSI Disk Adapter, you can connect your PowerBook to any desktop Macintosh and have the PowerBook function as though it were an external SCSI disk drive. The PowerBook appears on the screen of the desktop Macintosh as a hard disk icon, and you can transfer information between the computers by dragging files. This feature of the PowerBook is called SCSI disk mode.

SCSI disk mode is especially useful if you often need to retrieve or store information on other Macintosh computers. You can also use this feature to reinstall system software on your PowerBook, as described later in this chapter.

▲ **Warning:** Follow the steps for connecting and disconnecting SCSI devices carefully to avoid loss of information and damage to your equipment. ▲

Connecting your computer as a SCSI disk

Before making any connections, you need to assign a SCSI ID number to the PowerBook.

1. **Choose Control Panels from the Apple ( ) menu of your PowerBook computer.**
2. **Open the PowerBook control panel.**
3. **In the SCSI Disk Mode ID section of the control panel, click the ID number you want to assign.**

   If you are connecting the PowerBook to an existing SCSI chain, make sure to give it an ID number different from those of the other devices.



4. **Turn off the PowerBook by choosing Shut Down from the Special menu.**
5. **Shut down the desktop Macintosh.**
6. **Turn off any other devices in the SCSI chain.**

7. **Connect the PowerBook to either (a) the desktop Macintosh or (b) the end of the SCSI chain.**

   "Desktop Macintosh" includes all the models listed in the illustration, as well as a PowerBook Duo in a Duo Dock.

   The illustration shows which cables to use and where to add cable terminators. Remove the terminator from the last device in an existing chain before connecting the PowerBook.

▲ **Warning:** Always shut down the PowerBook before connecting or disconnecting the SCSI disk adapter cable. Connecting the adapter cable while the computer is turned on can damage the computer. ▲

8. **Turn on the PowerBook by pressing the power button.**

   After a few seconds a SCSI icon appears on the screen, showing the ID number you assigned in step 3.



▲ **Warning:** If you do not see the SCSI icon, and the computer either starts normally or displays an error message, choose Shut Down (if you can) and then immediately disconnect your computer from the SCSI chain. If you can't choose Shut Down, you should disconnect the cable anyway, or you may lose information. Then go back and repeat steps 4 through 8, making sure that you have shut down all your equipment, that you are using the correct cables, and that you have put terminators in the correct places. ▲

9. **Turn on the other SCSI devices in the chain, if any.**

10. **Turn on the desktop Macintosh.**

    The PowerBook appears as a hard disk icon on the desktop Macintosh. You can now transfer and use files as if the PowerBook were an external disk drive.

(a) Connecting to a desktop Macintosh

- Models *without* internal hard disk: Classic® Classic II LC LC II IIfx
- Models *with* internal hard disk: Classic Classic II LC LC II SE SE/30 II IIx IIcx IIci IIsi IIfx Macintosh Quadra™



- Models *without* internal hard disk: SE SE/30 II IIx IIcx IIci Macintosh Quadra



- Models *without* internal hard disk: Plus Portable
- Models *with* internal hard disk: Portable



(b) Connecting to the end of a SCSI chain

- Models *without* internal hard disk: Classic Classic II LC LC II IIfx
- Models *with* internal hard disk: Classic Classic II LC LC II SE SE/30 II IIx IIcx IIci IIsi IIfx Macintosh Quadra



- Models *without* internal hard disk: Plus Portable SE SE/30 II IIx IIcx IIci Macintosh Quadra
- Models *with* internal hard disk: Portable



*Do not use *any* terminators, non-Apple cables, or extension cables in this configuration, or it will not work.

Simplifying the SCSI disk connection process

If you regularly plan to use your PowerBook as a SCSI disk with the same desktop Macintosh, you can leave the cables, terminators (if any), and SCSI disk adapter cable attached to the desktop Macintosh. When you want to use your PowerBook as a SCSI disk, simply shut down all devices and connect the adapter cable to the SCSI port on your PowerBook. The desktop Macintosh and its SCSI chain (if there is one) will work correctly with or without the PowerBook attached.



▲ **Warning:** Always disconnect your PowerBook from the adapter cable when you are not using it as a SCSI disk. Your PowerBook will not work correctly if the adapter cable remains attached. ▲

Using SCSI disk mode to reinstall system software

If you're using SCSI disk mode to reinstall system software on your PowerBook's hard disk (because its System Folder was damaged, for example), you may not be able to select a SCSI ID number for the computer. If you don't know what the current ID number is, follow these steps:

1. **If there is anything visible on the screen or any other sign that the computer is on (even if it doesn't appear to be working properly), press the power button on the back of the computer to make sure that all power is off.**
2. **Connect the SCSI disk adapter cable to the SCSI port on your PowerBook.**

   Don't make any other connections yet.
3. **Press the power button again to restart the computer.**
4. **Note the ID number that appears on the screen.**

   You can't change this number now, but if you are attaching your PowerBook to an existing SCSI chain you can change the numbers of other devices if there is an ID conflict.
5. **Press the power button again to turn the PowerBook off.**

6. **Shut down the desktop Macintosh and any other SCSI devices in the chain.**
7. **Change conflicting ID numbers if necessary.**
8. **Connect the other end of the adapter cable to the desktop Macintosh, or to the end of the SCSI chain.**

   The illustrations in the section "Connecting Your Computer as a SCSI Disk" show the proper cables and terminator placement.
9. **Press the power button on the back of the PowerBook to turn it back on.**
10. **Turn on any other SCSI devices in the chain.**
11. **Turn on the desktop Macintosh.**

You can now reinstall system software on the hard disk in your PowerBook. Use the system software disks that came with your PowerBook, or with a system software upgrade kit designed to work with your PowerBook. (The disks that came with your desktop Macintosh, or any other Macintosh, may not be the correct version.)

Drawing battery power in SCSI disk mode

Your PowerBook continues to draw battery power when you use it as a SCSI disk. Low battery power is indicated by the appearance of a blinking low-power warning on the PowerBook's screen.



If you see this warning while using your computer as a SCSI disk, either plug in the power adapter or quit SCSI disk mode, as described in the next section, so you can remove the battery for recharging. If you wait until the computer goes to sleep automatically, you may lose information.

△ **Important:** Do not attempt to change batteries while your computer is in SCSI disk mode. △

Quitting SCSI disk mode

1. **Shut down the desktop Macintosh.**
2. **Press the power button on the back of the PowerBook to turn it off.**
3. **Turn off any other SCSI devices in the chain.**
4. **Disconnect the PowerBook from the adapter cable.**

   If you regularly plan to connect your PowerBook to the same desktop Macintosh, you can leave the adapter cable attached to the SCSI chain on the desktop Macintosh. See “Simplifying the SCSI Disk Connection Process,” earlier in this chapter.

△ **Important:** If you leave the adapter cable attached to the PowerBook, the computer will behave as though it is still in SCSI disk mode when you try to restart. △

5. **Disconnect the cables from the desktop Macintosh.**

Your equipment is now ready for normal use. Make sure that the SCSI devices connected to the desktop Macintosh are properly terminated.

Using an external monitor

Your PowerBook has a video port to which you can connect any of the following Apple monitors:

- Macintosh 12" Monochrome Display
- Macintosh 12" RGB Display
- AppleColor High-Resolution RGB Monitor (13")
- Macintosh Color Display (13")
- Apple Macintosh Portrait Display (15")
- Macintosh 16" Color Display

To connect one of these external monitors, you need the PowerBook video adapter cable that is provided in the box with your computer.

Your PowerBook also supports any VGA monitor in VGA mode. To connect a VGA monitor, you need an adapter cable, which should come from the same source as your monitor.

An external monitor connected to your computer functions as an extension of your PowerBook's built-in screen—that is, you can drag objects from one screen to another and do your work on either one. Or you can show the same image on both screens.

Connecting an external monitor

To connect any of the Apple monitors listed, follow these steps. (If you are connecting a different monitor, see the instructions in its manual.)

1. **Choose Shut Down or Sleep from the Special menu.**

   If you attempt to connect a monitor with your computer turned on, the computer will not be able to tell that the monitor is there.

2. **Plug in the power adapter.**

   You must use the power adapter with your computer whenever you are using an external monitor.

3. **Place the monitor where you will be using it.**

   Keep the computer and the monitor at least 8 inches apart to avoid electronic interference between the monitor and your computer's floppy disk drive, which can cause errors on your floppy disks.



Arrange the monitor so the top of the screen is slightly below eye level while you work. Position the monitor to minimize glare and reflections on the screen from lights and windows.

4. **Attach the monitor's power cord to the monitor.**

   (If your monitor has an attached power cord, skip this step.)

5. **Plug the other end of the monitor's power cord into a grounded outlet or power strip.**

   If your monitor's power cord is designed to plug into the power receptacle on the back of a computer, rather than into an electrical outlet, you can obtain a cable with the correct plug from your authorized Apple dealer.

   If you are using a power strip, make sure it is turned on.

6. **Attach one end of the monitor's video cable to the monitor and tighten the thumbscrews.**

   (If your monitor has an attached video cable, skip this step.)

7. **Attach the other end of the monitor's video cable to the video adapter and tighten the thumbscrews.**



8. **Attach the other end of the video adapter to the video port (▭) on the computer's back panel.**



9. **Turn on the external monitor.**

10. **Press the power button to turn on your computer.**

Trouble?

- Nothing happened when you tried to turn on the PowerBook.

  Make sure that all your equipment is connected properly, and try pressing the power button again.

  Make sure that the power adapter is plugged into both the computer and an electrical outlet. If you are using a power strip, make sure it is turned on.

- The computer is on, but the external monitor is dark.

  Make sure that the monitor's power cord is connected, and that its power switch is on. Also try adjusting the monitor's brightness and contrast settings.

Activating the external monitor

You must activate the external monitor each time you connect it to your computer.

1. **Choose Control Panels from the Apple (🍎) menu, and open the Monitors control panel.**

   You'll see two rectangles representing your two monitors.



2. **Click the large rectangle (representing your external monitor).**

Making the external monitor the main monitor

The main monitor is the one that displays the menu bar. The PowerBook's screen is the main monitor whenever an external monitor is not connected to your computer.

To make your external monitor the main monitor, follow these steps.

1. **Choose Control Panels from the Apple (🍎) menu, and open the Monitors control panel.**

   You'll see two rectangles representing your two monitors.



2. **Drag the menu bar from the small rectangle (representing your PowerBook screen) to the large rectangle (representing your external monitor).**



3. **Choose Restart from the Special menu.**

Trouble?

- The computer is on, and the external monitor looks like it's on, but the screen is blank.

  You must activate the external monitor each time you connect it to your computer. See "Activating the External Monitor" and "Making the External Monitor the Main Monitor."

Working with an external monitor

This section summarizes how your computer and external monitor behave when you use them together.

Sleep

The PowerBook will not sleep as long as you are using an external monitor. The automatic sleep settings will not take effect, and the Sleep command will not work.

Processor cycling

Whenever you use a Macintosh 16" Color Display with your PowerBook, processor cycling must be turned on. This keeps the computer from overheating and allows the battery to recharge.

You will not be able to turn processor cycling off if it is already on. If you had processor cycling turned off before you connected the monitor, the computer turns it back on automatically.

If you are using any external monitor, it's a good idea to leave processor cycling turned on.

Backlight dimming

The dimming feature in the PowerBook Display control panel turns the screen brightness down to its lowest level when you haven't used the computer for a certain time interval. (You can think of dimming as "screen sleep.")

When dimming is turned on, the screen on the external monitor also becomes dark. When you move the trackball or press a key, the brightness is restored on both screens.

Video mirroring

A feature called video mirroring allows you to display the same image on two screens at the same time. This feature is useful when you want to do a presentation: you can use the PowerBook screen to see and control what your audience views on a larger screen. Use the PowerBook Display control panel to turn video mirroring on or off.

Disconnecting an external monitor

1. **Make sure your computer is shut down.**

   If you disconnect the monitor while your computer is on, the computer will turn itself off, and you will lose any information you did not save.

   (The computer will not sleep as long as you are using an external monitor.)

2. **Disconnect the video adapter from the video port on the computer's back panel. The video port is marked with this icon:** |▭|

   Press the small buttons on both sides of the connector to remove the video adapter from the port.



Connecting a modem

Apple offers an optional, low-power, internal fax/data modem for your computer. See the modem manual for information about this modem and how to use it.

You can also connect an external modem to the modem port (✆) on the back panel of the computer.

To connect an external modem, follow these steps.

1. **Make sure the computer is in sleep or shut down.**
2. **Connect the modem to a power source and to the phone line.**

   See the documentation that came with the modem.
3. **Make sure the modem is turned off.**
4. **Connect the modem cable to the modem port marked with this icon: ✆.**
5. **Turn on the modem.**
6. **Wake or restart the computer.**

If your computer does not have an internal modem, the external modem is ready to use.

If your computer does have an internal modem, continue with step 7.

7. **Choose Control Panels from the Apple (🍎) menu.**
8. **Open the PowerBook control panel.**
9. **Click the External Modem button.**



10. **Close the control panel.**

The external modem is ready to use.

If you have both an internal and an external modem, remember to select the modem you want to use in the PowerBook control panel before opening your telecommunications program.

Connecting a printer

The printer port on your computer can accept either a direct cable connection (to a printer such as the StyleWriter) or a network cable connection (to a printer such as the LaserWriter IINTX). The printer port is marked with this icon: .

Some printers, including the Personal LaserWriter SC, are connected through the SCSI port (marked with the icon).

Follow the instructions that came with your printer to connect it to your computer.

▲ **Warning:** The StyleWriter printer comes with its own power adapter. This power adapter is not interchangeable with your computer's power adapter. Connecting the computer's power adapter to the printer will not damage your equipment, but the printer will not work properly. *Connecting the printer's power adapter to your computer will damage the adapter.* Use each power adapter only with the equipment for which it was intended. (You may want to label the adapters.) ▲

Connecting a mouse or other ADB device

Your computer has one Apple Desktop Bus (ADB) port, to which you can connect optional low-power input devices (such as a mouse) provided by Apple and other vendors. The ADB port has this icon: .

Make sure that any such devices you connect are designed for portable computers. Standard ADB devices designed for desktop Macintosh computers may drain your battery very quickly, in some cases even if the power adapter is plugged in. Low-power devices are marked with this icon: .

By connecting devices in a chain, you can attach up to three devices to the ADB port. See the instructions that came with your ADB device(s) for information about their power consumption, and make sure that the total power drawn by all devices you're connecting does not exceed 200 mA.

Using sound input and output devices

Built-in microphone

Your computer has a built-in microphone centered just below the display. The microphone has no on/off switch; it is controlled by the program you use to record sounds. (Sound recording is described in the chapter on sound and color.)



External microphone

In addition to its internal microphone, your PowerBook has a sound input port (marked with this icon:) to which you can connect an external microphone.

You cannot use both internal and external microphones at the same time. If an external microphone is connected, the internal microphone does not work.

▲ **Warning:** Do not plug a sound output device (such as a pair of headphones) into the sound input port. Doing so may damage your audio equipment. ▲

Sound output devices

The PowerBook also has a sound output port (marked with the icon ◂)) to which you can connect speakers, an amplifier, headphones, or other audio output devices. The sound output port accepts a standard stereo miniplug, like that used to attach headphones to a portable tape player.

Adding memory to your computer

Your PowerBook computer comes with at least 4 MB of RAM. By adding memory upgrade cards you can increase your computer's memory. You can find out how much memory your computer has by choosing About This Macintosh from the Finder's Apple menu.

Apple provides memory upgrades through its authorized dealers. Memory upgrades are also available from other vendors; ask your dealer for more information.

Apple recommends that memory upgrades be installed by an authorized Apple dealer.

Your PowerBook computer also supports virtual memory, a feature that makes use of hard disk space to provide additional RAM.

Chapter 15

Travel, Storage, and Service

In this chapter

- Traveling with the computer
- Storing the computer
- Getting service and support
- Getting more information about Macintosh computers

Traveling with the PowerBook

The safety instructions in the first part of this book also apply when you are traveling. In addition, note these precautions:

- Do not transport your PowerBook while it is turned on. Choose Sleep or Shut Down from the Special menu, and wait until the hard disk stops spinning, before you move the computer.
- Transport batteries either inside the computer or in the protective case provided with each battery. Do not transport unprotected batteries.
- Bring backup copies of your system software and other important files on floppy disks, in case you need to reinstall them.
- Do not check your computer as baggage. Carry it with you.
- Do not allow your computer or any hard disks or floppy disks to pass through X-ray machines. Have security officials manually inspect your computer and disks.
- Be prepared to show security officials that your computer is working. Have a charged battery or a power adapter ready to use.

- Some airlines may restrict or prohibit the use of computers in flight. Check ahead to find out what restrictions, if any, apply.
- Take the necessary plug adapters if you're traveling overseas. (You may need to use them with the power adapter.) You do not need a voltage transformer. The power adapter can handle 90 volts to 260 volts AC (48 to 62 Hz).

Check the diagrams below to determine which plug adapters you'll need, or ask your travel agent.

Outlet Type	Locations
	United States, Canada, parts of Latin America, Japan, Korea, the Philippines, Taiwan
	Former Soviet Union, most of Europe, parts of Latin America, the Middle East, parts of Africa, Hong Kong, India, most of South Asia
	Mexico, United Kingdom, Ireland, Malaysia, Singapore, parts of Africa
	China, Australia, New Zealand

Storing the PowerBook

Short-term storage (up to 2 weeks)

1. **Save your work on a hard disk or floppy disks.**
2. **Choose Battery from the Apple ( ) menu and note the charge level of the battery.**
3. **Choose Shut Down from the Special menu.**
4. **Close the display.**
5. **If the battery is not fully charged, or if you plan to leave the computer in storage for more than a week, plug in the power adapter.**

   If the battery is fully charged, you can store the computer *without* its power adapter plugged in for up to a week.
6. **Store the computer in a cool, dry place.**

   Storage temperatures should remain between 50°F/10°C and 104°F/40°C. Avoid leaving the computer where temperatures may be extreme or unpredictable—in the trunk of a car, for example.

Long-term storage (more than 2 weeks)

1. **Save your work on a hard disk or floppy disks.**
2. **Choose Shut Down from the Special menu.**
3. **Close the display.**
4. **Recharge the battery.**

   Plug in the power adapter or use the recharger.
5. **If you recharged the battery in a recharger, put the battery back into the computer.**
6. **Store the computer in a cool, dry place.**

   Storage temperatures should remain between 50°F/10°C and 104°F/40°C. Avoid leaving the computer where temperatures may be extreme or unpredictable—in the trunk of a car, for example.

   If you leave the battery in storage for more than 6 months, you may not be able to recharge it.

Using the security feature

Your PowerBook has a security slot to which you can connect a locking device and security cable. See your authorized Apple reseller for more information about this security system.

Service and support

If the PowerBook malfunctions or is damaged

If your computer is malfunctioning but does not appear to be physically damaged, shut it down (and leave the power adapter plugged in, if possible) until you can get help.

If you know or suspect that your computer is physically damaged, disconnect the power adapter, remove the battery, and do not use the computer until it can be repaired.

How to get help

To obtain service in the United States, you can contact either your nearest authorized Apple dealer or Apple Computer directly. If you are in North America, call 800-538-9696 to request the name of an authorized dealer near you. If you are anywhere else, check the local telephone directory.

To contact Apple directly, call 800-SOS-APPL (800-767-2775), Monday through Friday, 8 A.M. to 5 P.M. (Pacific time) to speak to a Technical Support Engineer. If your PowerBook requires service, the Technical Suppport Engineer will arrange for your computer to be picked up at your location, sent to Apple's centralized repair facility for repair, and returned to you at any location you specify in the United States. Apple has established a centralized repair facility to help you get the best performance from your system.

If you need answers to product questions or information about product updates, your authorized Apple dealer can help you. Apple's technical support organization backs each dealer and international technical support group with an AppleLink network, a state-of-the-art on-line information service, to ensure prompt and reliable assistance. Apple guarantees parts and warranty labor. (Regulations in each country determine the length of warranty. Some restrictions may apply, depending on the country of original purchase.)

If you cannot return to the authorized Apple dealer from whom you purchased your system, go to the nearest service location. For the location nearest you, write or call one of the following:

Apple Computer, Inc.
Customer Relations
20525 Mariani Avenue
Cupertino, CA 95014-6299
USA
(800) 538-9696

Apple Canada, Inc.
7495 Birchmount Road
Markham, Ontario, L3R 5G2
Canada
(800) 268-7796/7637

For locations in other countries, either call the Apple headquarters in your country or write to the United States address on this page.

Apple also offers service plans. One is the AppleCare Service Agreement (available in the United States, Canada, and Australia only), which extends full warranty coverage up to three years. Your AppleCare contract will be honored at any participating authorized Apple dealer within the country of purchase—an added benefit if you relocate.

You can purchase AppleCare at any time, but you may want to purchase it with your system, or at least before your warranty expires, to avoid an inspection at your own expense.

For more information about Macintosh computers

Macintosh user groups

Whatever your level of computer experience, you may be interested in joining a Macintosh user group. Group activities may include new product demonstrations, question-and-answer sessions, and classes on using programs or writing your own programs.

Ask your authorized Apple dealer for the name of the Macintosh user group nearest you, or call 800-538-9696. For names of user groups outside the United States, or if you're interested in starting your own group, contact:

Berkeley Macintosh User's Group
1442-A Walnut Street, #62
Berkeley, CA 94709
USA
510-549-BMUG (510-549-2684)

or

Boston Computer Society
One Center Plaza
Boston, MA 02108
USA
617-367-8080

Technical information

Apple makes technical information for Macintosh computers available through the Apple Technical Library and the Apple Communications Library, both published by Addison-Wesley Publishing Company and available at bookstores.

Apple Technical Library

The Apple Technical Library includes comprehensive technical documentation for all Macintosh computer models as well as the multivolume guide to the Macintosh operating system, *Inside Macintosh.*

Apple Communications Library

The Apple Communications Library offers complete technical information about Macintosh communications products and the Macintosh in a network environment.

APDA

APDA (Apple Programmers and Developers Association) offers access to a broad range of programming products, resources, and information for anyone developing hardware or software for Apple computers. These resources include the most current versions of Apple and third-party development tools, debuggers, compilers, languages, and technical references.

To establish an APDA account, obtain ordering information, or find out about site licensing and developer training programs, contact:

APDA
Apple Computer, Inc.
20525 Mariani Avenue, M/S 33-G
Cupertino, CA 95014-6299

800-282-2732 (USA)
800-637-0029 (Canada)
408-562-3910 (International)
Fax: 408-562-3971
Telex: 171576
AppleLink address: APDA

If you provide commercial products and services, call 408-974-4897 for information about the developer support programs available from Apple.

Assistance for hardware and software developers

If you plan to develop hardware or software products for sale through retail channels, you can get valuable support from Apple Developer Programs. Write to:

Apple Developer Programs
Apple Computer, Inc.
20525 Mariani Avenue, M/S 51-W
Cupertino, CA 95014-6299

Summary and Shortcuts

- **Double-click an object on screen by pointing to the object and clicking twice in rapid succession, without moving the mouse.**

  Double-clicking is a common shortcut for opening an icon or the selected item in a directory dialog box.

Shift-click

- **Hold down the Shift key while clicking.**

  Shift-clicking is a way to select more than one icon or item in a list.

Working with icons

Selecting icons

To do this	Take these steps
Select an icon	Click the icon.
Deselect an icon	Click anywhere except the selected icon.
Select multiple icons	While holding down the Shift key, click each icon.
Deselect an icon in a group of selected icons	While holding down the Shift key, click the icon.
Select multiple icons that are near each other	1. Place the pointer at one corner of the group of icons. 2. Drag diagonally to select the icons, then release the mouse or trackball button.
Select contiguous icons in a list	1. Place the pointer to the left of the top icon or the bottom icon. 2. Drag up or down the list, releasing the mouse or trackball button when the pointer is left of the last icon.
Select text in an icon's name	Click the icon's name (not the icon itself).

Opening an icon

You open an icon by selecting it and choosing Open from the File menu or using the keyboard shortcut ⌘-O or ⌘–Down Arrow. Or you can double-click the icon.

Moving, copying, and renaming an icon

To do this	Take these steps
Move an icon	Drag the icon to where you want it.
Copy an icon onto another disk	Drag the icon to the icon of the other disk (or to an icon or window that belongs to that disk).
Copy an icon on the same disk	1. Click the icon to select it. 2. Choose Duplicate from the File menu, or press ⌘-D. 3. If you wish, rename the icon and drag it to a new location. You can also make a copy by holding down the Option key while you drag the icon to another folder or window.
Rename an icon	1. Select the icon's name by clicking the name (not the icon). 2. Type a new name and press the Return key.

Working with windows

Making a window the active window

You make a window active by clicking inside it. You can also make a window active by clicking its icon (even though it's dimmed) and choosing Open from the File menu, or by double-clicking the dimmed icon.

Moving a window and changing its size

To do this	Take these steps	
Move a window		Drag the window's title bar (at the top of the window) to the new location.
Resize a window		Drag the size box (in the lower-right corner).
		Or click the zoom box (in the upper-right corner).
Close a window		Click the close box (in the upper-left corner). Or choose Close from the File menu. Or press ⌘-W.

Scrolling through the contents of a window



- **Click the up, down, left, or right scroll arrow.**
- **Click the vertical or horizontal scroll bar (when it's gray).**
- **Drag the vertical or horizontal scroll box along its scroll bar.**

Opening higher-level folder windows

You can open a higher-level folder window (whose contents include the active window) from a pop-up menu in the active window's title.

1. **Hold down the ⌘ key as you press the active window's title.**

   A pop-up menu of the higher-level folders (and the disk) appears.

2. **Drag to choose a higher-level folder (or the disk), and then release the mouse or trackball button.**

   The folder (or disk) window you chose appears as the active window.



If you hold down the Option key as well as the ⌘ key, the old window closes when the new window appears.

Using the outline form in list views

Any list view you choose from the View menu (that is, any view except the icon and small icon views) shows the contents of the active window in outline form. You can see the contents of a folder without opening the folder in its own window.



Click the triangle next to a folder name to display or hide the folder's contents in the active window. If you double-click a folder, it opens in its own window, and its outline view closes.

- *Shortcuts:* When a folder is selected in an outline view, pressing ⌘–Right Arrow displays its contents and ⌘–Left Arrow hides its contents. ❖

Working with menus

Macintosh menus come in two types: pull-down menus and pop-up menus. The menus in the menu bar are pull-down menus.



Pop-up menus often appear in dialog boxes that you use to set options or preferences. You can recognize a pop-up menu by a small solid triangle, pointing down, next to its name. The name shows the current option or preference.



Choosing an item from a menu

To choose a command from a menu, point to the menu name, press to “pull down” or “pop up” the menu, drag to the item you want to choose so that it’s highlighted, and then release the mouse or trackball button.

Choosing an item from a submenu

Some menu items are submenus. A submenu name has a small solid triangle next to it, pointing to the right. The submenu opens when the submenu name is highlighted.

To choose an item in a submenu:

1. **Point to the menu name and press to open the menu.**
2. **Drag to the menu item so that the submenu appears.**



3. **Drag sideways to the submenu, drag to the submenu item you want to choose so that it's highlighted, and then release the mouse or trackball button.**



Keyboard shortcuts in the Finder and in directory dialog boxes

Key	Action
Up, Down, Left, or Right Arrow key	Selects the next item in the direction of the arrow
Tab key	Selects the next item alphabetically (except in a directory dialog box and the Chooser)
Character key (a, b, c . . .)	Selects the first item whose name begins with that character (or the character following closest to it in the alphabet)
⌘–Down Arrow	Opens the selected icon
⌘–Option–Down Arrow	Opens the selected icon and closes the current folder
⌘–Up Arrow	Opens the folder that contains the current folder
⌘–Option–Up Arrow	Opens the folder that contains the current folder and closes the current folder
Return or Enter	In the Finder: Selects the selected icon's name for editing or saves the edited name In a dialog box: the same as clicking the button with the bold outline around it

Troubleshooting

This section describes possible causes and solutions for some common problems you may have with your Macintosh PowerBook or associated equipment provided by Apple.

This section is not comprehensive. Check the appropriate reference section for additional help on specific topics.

▲ **Warning:** If you have a problem with your Apple computer equipment and nothing presented in the manuals that came with the equipment solves the problem, call Apple Computer directly at 800-SOS-APPL (800-767-2775), or take the computer or accessory to your authorized Apple dealer or service provider. Attempting to repair the equipment yourself may void the Limited Warranty. Contact your authorized Apple dealer or service provider for additional information about this or any other warranty question. ▲

The PowerBook

The computer won't start.

- The computer may be on, but the screen brightness or contrast may be turned down. Adjust the brightness and contrast controls to see whether an image appears on the screen.
- The battery may be drained. Plug in the power adapter, wait 15 minutes, and then try to turn on the computer.
- There may be a temporary problem with the computer's power system. Use a paper clip or similar object to press the reset button on the computer's back panel, and then try to turn the computer on again.

The computer just stopped.

- The computer may have gone to sleep. Press any key on the keyboard (except Caps Lock) to wake it again.
- The battery may have drained so far that the computer has put itself to sleep to protect the contents of RAM. Plug in the power adapter, wait 15 minutes, and then turn the computer on again.
- The computer may have "crashed" due to temporary software problems. Click the Restart button on the screen (if you see one), or use a paper clip or similar object to press the reset button on the computer's back panel. If you use these methods, you will lose any work you have not saved.

The computer is very hot.

- It is normal for the computer to be warm to the touch while you are using it, especially on the side beneath the keyboard. If the computer seems unusually hot, try the following:
  - plug in the power adapter
  - turn down the screen brightness (☼)
  - turn on backlight dimming
  - use the Maximum Conservation setting in the PowerBook control panel
  - make sure processor cycling is on in the PowerBook control panel
  - select "Reduced processor speed" in the PowerBook control panel
  - disconnect the external monitor
  - put the computer to sleep or shut it down

  See Chapter 7 for more information on reducing your computer's power consumption.

The computer exhibits odd behavior, such as many unexplained system failures.

- A common cause of unexplained problems is multiple System Folders on your computer's startup disk. The System Folder that the PowerBook is using to operate is marked with an icon. Use the Find command in the Finder's File menu to locate any other System Folders, and throw them in the Trash.
- You may have a virus on your hard disk. Obtain a virus-detection program, use it to check all your disks, and eliminate any viruses the program finds.
- You may be using a program that's not compatible with your computer's system software. Check the information that came with the program or contact the manufacturer.
- You may have added a control panel or system extension that is incompatible with other programs you use. Restart the computer with the Shift key held down until you see the message "Extensions off." If the problem does not recur, remove any such items you recently installed.

Power

The battery is draining too fast.

- Turn down the screen brightness, turn off virtual memory, move the Battery Conservation slider in the PowerBook control panel to Maximum Conservation, or work with the power adapter plugged in.
- You may be using an input device (such as the mouse intended for desktop Macintosh systems) not designed for PowerBook computers. Make sure to use only low-power input devices.
- Your computer supplies power to the modem whenever a communications program is open. Quit your communications program if you aren't using it.
- If you aren't using network services, you can also save power by turning off AppleTalk in the Chooser.
- Your battery may need to be discharged and recharged completely. See Chapter 7.
- Older PowerBook batteries do not hold a charge as well as new ones. You may need to replace the battery.

The battery can't be recharged.

- There may be a loose connection. Make sure all plugs are securely attached.
- If all connections are OK, then the battery is probably damaged or dead. Obtain a replacement battery from your authorized Apple dealer.

The computer goes to sleep too often.

- Open the PowerBook control panel and move the Battery Conservation slider toward Maximum Performance.

The computer doesn't go to sleep automatically.

- You may have selected "Don't sleep when plugged in" in the Options section of the PowerBook control panel. Click the box to remove the X.
- You may be connected to a shared disk on the network. If you are not using the information on the shared disk, disconnect from it.
- The printer or modem port may be in use. Quit your telecommunications program or turn off background printing in the Chooser (if the documents you're printing can wait until later).
- One or more applications may be doing work in the background. You can choose Sleep from the Special menu to override them.

See Chapter 7 for more information about batteries and power consumption.

The screen

The screen looks blurred or out of focus.

- The viewing angle may not be optimal. Tilt the display on its hinge until the screen looks better.

The screen is too dark.

- When you first turn on your computer, it may take several minutes for the screen brightness to "warm up," especially if you've chosen a high setting.
- The screen brightness (☼) or contrast (◑) may not be optimal for the surrounding lighting. Adjust the brightness or contrast setting.
- The screen dims automatically when the battery starts to run low. You may need to recharge or replace the battery before you can turn up the brightness.

The screen is flickering.

- This problem sometimes occurs when your screen is set to display the maximum number of grays. Try adjusting the contrast control, or select fewer grays in the Monitors control panel.

There are ghost images or black dots on the screen.

- When the computer is left on for many hours, temporary defects may appear on the screen. Put the computer to sleep. The longer the computer was left on, the longer it will take for the images to fade, but they will eventually disappear.

The pointer moves too fast/too slowly.

- You need to adjust the pointer's tracking speed. Open the Mouse control panel and choose a more comfortable setting.

The pointer won't move at all.

- A software problem may have caused the computer to "freeze." Restart the computer by using a paper clip or similar object to press the reset button on the computer's back panel. You will lose any work you have not saved.

A window has disappeared.

- Another open window on the desktop may have covered the window you're looking for. Move, resize, close, or hide windows you aren't using until you see the one you want.
- Windows belonging to open but inactive programs may be hidden. Choose Show All from the Application menu to show hidden windows.

An icon is blinking in the menu bar.

- One of your programs needs your attention. For example, you may have set the Alarm Clock to go off at a particular time, or PrintMonitor may be alerting you to a printing problem. Make the program active and take the necessary action.

Memory

A "not enough memory" message appears when you try to open a program.

- Quit any programs you aren't using, then try again to open the program you want. If that doesn't work, restart the computer. Sometimes restarting makes additional memory available.
- If you are using a RAM disk or a disk cache, reduce its size and then restart the computer.
- Use extra space on your hard disk as virtual memory to increase the amount of memory available for opening programs. (Use virtual memory only when the power adapter is plugged in.)
- If you consistently want to open more programs than memory allows, you can purchase a memory expansion card from your authorized Apple dealer.

SCSI devices

You can't turn on the computer after connecting a SCSI device.

- SCSI devices connected to your computer must be turned on before the computer itself. Turn on the SCSI device(s) first, and then turn on the computer.

The computer doesn't recognize your SCSI devices.

- The devices may be off. Check to make sure that they are plugged in and turned on.
- If the device is a disk drive, it may need to be initialized before you can use it. See the instructions that came with the device.
- The software (driver) needed to communicate with the device may not be installed in your System Folder. See the instructions that came with the device.
- Two or more devices in the SCSI chain may have the same ID number. Check the ID number of each device to make sure each one has its own number between 1 and 6, and change any numbers that are not unique.
- When connecting SCSI equipment, it is important to use the right cables and the correct number and placement of cable terminators. Check the cables and terminators in the SCSI chain and make sure that all cables are firmly attached.

See Chapter 14 for more information about working with SCSI devices.

External monitors

The external monitor is dark.

- There may be no power to the monitor. Make sure that the monitor's power cord is connected, and that its power switch is on.
- Try adjusting the monitor's brightness and contrast controls.

The external monitor looks like it's on, but the screen is blank.

- The computer's power adapter must be plugged in when you use an external monitor. With the computer in sleep or shut down, plug in the power adapter and then wake or start up the PowerBook.
- You must activate the external monitor in the Monitors control panel each time you connect it to your computer. See Chapter 14.

Disk drives and disks

The computer won't start up from its hard disk, or the hard disk icon doesn't appear on the desktop.

- There may have been a temporary software problem. Shut down the computer, wait at least 10 seconds, and then turn it on again.
- There may be a problem with the system software on the hard disk. Start up the computer with the *Disk Tools* disk. If the hard disk's icon appears, reinstall system software as described in Chapter 6. Disk repair programs can sometimes fix problems of this kind.
- The information on the disk drive may be damaged. Try using a disk repair program to repair or recover the information. If this doesn't work, you'll need to reinitialize the hard disk. See Chapter 8.
- There may be a mechanical problem with the disk drive. If none of the above suggestions works, take the computer to an authorized Apple service provider.

The hard disk keeps stopping and starting again.

- The hard disk may be going to sleep to conserve power. Open the PowerBook control panel and move the Battery Conservation slider toward Maximum Performance.

The hard disk is full.

- You can reclaim space on your hard disk by removing unneeded files; installing a smaller, customized System Folder; turning off virtual memory; or purchasing a disk optimization program to reorganize the information on the hard disk.

The icon of a floppy disk doesn't appear on the screen.

- There may be a problem with the disk or disk drive. Try inserting a different disk. If its icon does appear, the original disk is probably damaged. You may be able to repair the disk or recover some of the information on it. See Chapter 8. If the icon of the second disk does not appear either, take the computer or disk drive to an authorized Apple service provider for repair.

A high-density (1.4 MB) disk you use with your PowerBook computer is not recognized by another Macintosh.

- Some disk drives cannot recognize high-density disks. Try inserting an 800K or 400K disk in the disk drive of the other Macintosh. If that works, copy your files to an 800K disk or a 400K disk. If you regularly plan to use floppy disk drives of different types, use the lower-capacity disks in all drives.

You can't eject a disk from a floppy disk drive.

- There may be a temporary mechanical problem with the disk drive. Restart the computer and hold down one of the trackball buttons while the computer starts up. If that doesn't work, carefully insert the end of a straightened paper clip into the small hole near the disk drive's opening, and push gently until the disk is ejected.

A message says that a disk is not initialized—but you know that it is.

- The disk may not be seated properly in the disk drive. Eject it and try inserting it again.
- The disk may be damaged. If you insert another disk in the drive and the message does not appear, you can assume that the original disk needs repair. See Chapter 8 for information about recovering information from a damaged disk. If the second disk is also not recognized, take the computer or disk drive to an authorized Apple service provider.

You can't delete a file on a floppy disk.

- The disk may be locked. Unlock it by sliding the tab so that it covers the hole at the corner of the disk.
- The file may be locked. You can unlock it in its Info window (choose Get Info from the File menu). Or you can hold down the Option key while you choose Empty Trash from the Special menu.
- An application program may be using the file. You'll need to quit the program.

You can't save or copy files onto a floppy disk.

- The disk may be locked. Unlock it by sliding the tab so that it covers the hole at the corner of the disk.
- The disk may be full. Delete files you no longer need or use a different disk.

See Chapter 8 for more information about working with disk drives and disks.

Modems

The external modem doesn't work.

- The modem may be turned off or improperly connected. Make sure it is turned on and that all connections are correct.
- The modem port may not be activated. Open the PowerBook control panel and make sure that External Modem is selected.

The internal modem doesn't work.

- The modem port may not be activated. Open the PowerBook control panel and make sure that Internal Modem is selected.

See the modem manual for more information about using and solving problems with your modem.

Printers

Your computer can't find the printer.

- The printer may be turned off. Turn it on.
- The printer may not be selected in the Chooser. Open the Chooser and select the printer you want to use.

Your printer does not appear in the Chooser window.

- The printer may not be connected properly. Check the connections between your computer and the printer, including relevant sections of the network if appropriate.
- The printer software may not be in your System Folder. Close the Chooser and install the software you need.
- AppleTalk must be active before you can use a network printer. Make sure that AppleTalk is active in the Chooser.
- If your network has zones, the printer you want may not be in the currently selected zone. Make sure the correct zone is selected.

The network printer keeps restarting.

- Someone on the network may be using a different version of the printer software. Everyone connected to a network should use the same printer software version. Consult the network administrator for more information.

Nothing happens, or you see an error message, when you try to print.

- The printer may not be turned on. Make sure it is turned on and warmed up.
- The printer may be out of paper or have some other problem. Check the printer status lights and any messages on your screen.
- If an error message states that the printer could not print your document, turn the printer off for at least 10 seconds. Then turn it on again, wait for it to warm up, and try to print again.

Your documents are printed with the wrong fonts.

- The printer may not have your fonts in its memory and is substituting other fonts. You may be able to add the necessary fonts to your printer (see Chapter 12), or print on a different printer that has the fonts you want. If you have a LaserWriter, you can turn off Font Substitution in the Page Setup dialog box.

See Chapter 12 for general information about printing documents. See the printer manual for more information about your printer's features or problems with the printed output.

Networks

You can't find or can't open icons needed to set up file sharing.

- One or more icons may be in the wrong place. Make sure that the Sharing Setup icon is in the Control Panels folder, and that the File Sharing Extension file, the Network Extension file, and the AppleShare file are in the Extensions folder. (Both folders are inside the System Folder.)
- Some network software may not be installed. Use the Installer to install the appropriate network software.

The shared disk you want to connect to does not appear in the Chooser window.

- AppleTalk must be active before you can use a shared disk. Make sure that AppleTalk is active in the Chooser.
- If your network has zones, the shared disk you want may not be in the currently selected zone. Make sure the correct zone is selected.
- The computer that the disk is on must be turned on before the disk can be shared. Make sure that computer is on.

You can't open a shared disk or folder.

- You may not have the access privileges needed to use the disk or folder. Ask the network administrator or the owner of the shared item to grant you access.
- You may have entered your name or password incorrectly when you tried to open the shared disk or folder. Check with the owner of the item to make sure you are entering your name and password correctly, and try again.

You can't connect to your own computer from another Macintosh.

- Make sure that your computer is turned on, file sharing is turned on for both computers, you have the correct access privileges, and you entered your name and password correctly.

See Chapter 13 for more information about using your computer on a network.

Application programs

A program won't open.

- Some programs can't be opened from a locked floppy disk. Make sure the disk is unlocked.
- The program may be damaged. Recopy it from a known good source (such as the original program disk).
- There may not be enough memory available to open the program. Quit other programs or change the program's memory size in its Info window.

A program runs very slowly.

- Some programs are slowed by processor cycling. You can turn processor cycling off; see Chapter 7. Turning processor cycling off will drain your battery faster and cause the computer to become hotter.

A program doesn't work, or malfunctions consistently.

- You may have more than one copy of the program on your hard disk. Remove extra copies by dragging them to the Trash.
- The program may be damaged. Recopy it from a known good source (such as the original program disk).
- Your version of the program may be incompatible with your system software. Consult the software manufacturer to find out which version of the program you should be using.
- The program may be using less memory than it needs to work with your documents. Choose Get Info from the File menu and increase the memory size.

A message says that a program could not be found.

- You may be trying to open a document created with a program you don't have on your computer, or created with a different version of the program. Obtain the correct program and version. Or open the document with another program that can read its format. (If another program can open a document, the program icon becomes highlighted when you drag the document icon to it.)

You just did something you didn't mean to do.

- If you have not yet taken any other action, you can usually undo your most recent action (even if you aren't sure what it was). Most programs have an Undo command in the Edit menu (⌘-Z). Choose Undo to go back one step in your work. You cannot undo more than one action.

See the documentation that came with your programs for more information about their operation and features.

Appendix A

Keyboard and Character Sets

Tab key: Moves the insertion point to the next stopping place (such as a tab stop or data field).

Delete key: Deletes selected material, or the character to the left of the insertion point.

Return key: Moves the insertion point to the beginning of the next line. In a dialog box, pressing Return is the same as clicking the outlined button.

Caps Lock key: A Shift key for letters only (numbers and symbols aren't affected).

Shift key: Produces capital letters (or the upper character on the key).

Control key: In combination with other keys, provides shortcuts or modifies actions.

Option key: In combination with other keys, produces special characters or modifies actions.

⌘ **(Command) key:** Works in combination with other keys as an alternative to choosing a menu command.

Arrow keys: Move the insertion point, as an alternative to using the trackball. In some programs, the arrow keys have other functions.

Using Caps Lock

The Caps Lock key on PowerBook computers does not stay depressed even when it's locked. You can tell whether Caps Lock is on or off by looking at the menu bar. An arrow appears to the left of the Help menu icon when Caps Lock is on.

To turn Caps Lock on or off, press the Caps Lock key.

Typing special characters and symbols

You can type a variety of special characters (with diacritical marks) and symbols by pressing modifier keys in combination with certain letter and number keys.

The Key Caps program, which is installed with the system software, shows you the characters produced when you type certain keys and key combinations in the fonts available on your computer. Choose Key Caps from the Apple ( ) menu, then choose the font from the Key Caps menu.





Characters available in the Chicago font when the Option key is pressed

The highlighted key represents the key held down on the keyboard—in this case, the Option key.

To type a character with a diacritical mark (such as an acute accent or an umlaut), you press the Option key along with a specific letter key, and then type the character.

Diacritical mark	Key combination
Grave accent (`)	Option–`, then type the character
Acute accent (´)	Option–e, then type the character
Circumflex (^)	Option–i, then type the character
Tilde (~)	Option–n, then type the character
Umlaut (¨)	Option–u, then type the character
The letter “c” with a cedilla (ç)	Option–c

If the character appears *after* the diacritical mark (rather than with it), then the marked character is not available in the font you’re using.

Appendix B

Exchanging Disks and Files With MS-DOS Computers

Apple File Exchange is a file format conversion program supplied on your system software disks. The program and *translator* files are stored in the Apple File Exchange Folder.

You can use the program to initialize a disk in MS-DOS (or Apple II ProDOS) format and convert files to and from MS-DOS (or ProDOS). Apple File Exchange cannot open converted files; you need to open them with an application program that recognizes the converted files.

Initializing a disk in MS-DOS format

(You can also follow these instructions to initialize a disk in ProDOS format.)

1. **Locate the Apple File Exchange icon and open it.**

   Apple File Exchange is supplied on one of your system software disks.

   When you open the program, the contents of the active window are listed on the left side and an empty box appears on the right side.

2. **Insert a blank disk into your floppy disk drive.**

   A message reports that the program can't read the disk and asks if you want to initialize it. The message lists the formats available in Apple File Exchange, including Macintosh, MS-DOS, and ProDOS.

   (You can initialize a disk that is not blank by inserting it, clicking the Drive button until the disk's name appears, and then choosing Erase Disk from the File menu.)

3. **Click MS-DOS.**

4. **If necessary, click the capacity (in K) of the disk you inserted.**

   If you want to initialize a high-density (HD) disk in MS-DOS format, 1440K is the only option and it is already selected. If you inserted a double-sided disk, click 720K.

   Apple File Exchange cannot initialize a high-density disk in 720K format, nor can it read a double-sided disk that has been initialized in the high-density (1.4 MB) format.

Disk capacity is the same for Macintosh and MS-DOS high-density disks.

5. **Click Initialize.**

   When initialization is finished, a message asks you to name the disk.

6. **Type a name for the disk, and then click OK.**

   MS-DOS filenames can have up to eight characters, followed by an optional period and up to three characters.

   The name of the disk you initialized appears above an empty window. The disk's icon doesn't appear on your Macintosh screen because the Macintosh can't recognize a disk in MS-DOS format.

7. **Choose Quit from the File menu.**

Converting files to and from MS-DOS format

Apple File Exchange provides two methods of file conversion—text and binary. Text translation is for text files, and binary translation is for other file types.

Apple File Exchange can also use translator files designed to convert files into formats that specific programs can use. One such translator file is provided with Apple File Exchange: DCA-RFT/MacWrite, which converts documents between MacWrite format (for the Macintosh) and Document Content Architecture/ Revisable Form Text format (used by many MS-DOS word-processing programs).



Follow these steps to translate an MS-DOS (or ProDOS) file:

1. **Locate the Apple File Exchange program and open it.**

   Apple File Exchange is supplied on one of your system software disks.

   When you open the program, the contents of the active window are listed on the left side and an empty box appears on the right side.

2. **Insert the floppy disk containing the files you want to translate.**

3. **Use the Open, Drive, and Eject buttons to display the files you want to translate and the disk or folder where you want to store the translated files.**

4. **Click the names of the files or folders you want to translate.**

   The appropriate translation menus (for translating from or to Macintosh format) appear in the menu bar when you select MS-DOS files.

5. **Pull down the translation menu you want.**

6. **Make sure that the translators for the types of files you selected have checkmarks; if not, choose them so checkmarks appear next to them.**

   An active translator has a checkmark. The default translator has a diamond (indicating that it's always active). Choosing an active translator makes it inactive.

7. **Compare the size of the files or folders selected for translation with the space available on the destination disk.**

   Total space required appears between the lists; the space available on the destination disk appears below its name.

   If the size of the selected items is greater than the space available on the destination disk, deselect some of the items, remove some files on the destination disk (click Remove), or use another destination disk (click Eject).

8. **Click Translate.**

   If two or more active translators (other than Text or Default) are capable of translating a selected file, a message asks you to select the translator you want.

   If the names of files or folders on the destination disk are the same as those of files or folders being translated, a message asks you to rename the file being translated.

   If you need to select options before a file is translated, a dialog box appears in which you can select the options.

9. **Respond to any messages by selecting a translator, renaming a file, or selecting options.**

   When Macintosh files are translated into MS-DOS files, filenames may be shortened to conform to MS-DOS naming conventions.

10. **Choose Quit from the File menu.**

❖ *Converting MS-DOS files on a file server:* Some file servers can store information created by both Macintosh and MS-DOS computers. For example, the AppleShare PC program allows MS-DOS computers to store and translate files on an AppleShare file server. Consult your authorized Apple dealer or representative for more information about using a file server and MS-DOS files. ❖

Other file-conversion options

Apple File Exchange's File menu provides several other options to assist you with file conversions.



To see explanations of the translators Apple File Exchange uses, choose About Apple File Exchange from the Apple menu. Select a translator from the list, and then click the About button for more information. (Click Done to return to the program's window.)

Appendix C

Map

The Map control panel lets you set your computer's location and find out the distance and the time difference between your location and cities around the world. If you travel with your computer and use Map to reset your location accordingly, the time (in the Date & Time control panel) is automatically reset to the local time.

Certain programs (in networking and telecommunications, for example) can use your computer's location to account for time zones and distances when making calculations.

Setting your location

1. **Choose Control Panels from the Apple (apple) menu and open the Map control panel.**



To magnify the map in the control panel (showing less of the world at a larger scale), hold down the Option key while you open Map.

2. **Type the city nearest your current location and then click the Find button (or press the Return key).**

   If you aren't sure how the city is spelled, type the first few letters and press the Return key. If the city isn't found, you can add it to the list of cities stored in Map (instructions are given elsewhere in this appendix).

3. **Click the Set button.**

   Your current location is indicated by a blinking cross.

Comparing locations

After you set your computer's location, you can use Map to find out:

- the distance from your location to another location
- the time at another location
- the time difference between your location and another location

Open the Map control panel and find or add the other location (instructions are given elsewhere in this appendix). You can also choose a location by clicking anywhere on the map (the unnamed location's coordinates appear in the boxes for latitude and longitude).



The distance to and the time at the other location are shown at the bottom of the window. The distance is based on the shortest possible route (called the great circle).

To find out the time difference between your location and the other location, click the words “Time Zone.” Click again to see the other location’s time zone.

Finding a location

The Map has a list of locations, with information on the latitude, longitude, and time zone of each location.

1. **Choose Control Panels from the Apple ( ) menu.**
2. **Open the Map control panel.**

   To magnify the map in the control panel (showing less of the world at a larger scale), hold down the Option key while you open the Map control panel.

3. **Type the city you are looking for and then click the Find button (or press the Return key).**

   If you aren’t sure how the city is spelled, type the first few letters and press the Return key.

   If you don’t know the name of a city but know where it is, you can find it by clicking its location on the map. Each blinking point is a location in the list. If you click in the map and then drag to a blinking point, that location’s name, latitude, longitude, and time zone appear.

   (If you hold down the Option key while clicking the Find button, Map displays, one at a time, all the locations in its list.)

Adding or removing a location

Adding a location

1. **If the map does not show the location you want to add, scroll by dragging beyond the map in the direction of the location.**
2. **Click the location.**

   A blinking star appears at the location, and its coordinates and approximate time zone are displayed.
3. **Type the name of the new location.**
4. **If you know the coordinates, type them in the latitude and longitude boxes.**

   When the N and E boxes are checked, the boxes next to them display North latitude and East longitude, respectively. Otherwise, they display South latitude and West longitude.
5. **If the time zone is not correct, click the Time Zone boxes and type in the correct number.**

   When the box at the end of the Time Zone line is checked, the boxes show how much time the location is ahead (east) of Greenwich Mean Time. Otherwise, they display how much time the location is behind (west of) Greenwich Mean Time.

   The map estimates the time difference based solely on longitude. Since the boundaries and time of time zones are determined politically, you may need to consult a time zone chart, map, atlas, or globe for the correct time.
6. **Click the Add City button.**

   The new location is added to the list. If your computer beeps, the location is already part of the list.

   To change details about a location, you need to remove it and then add it again.

Changing or removing a location

1. **Find a location.**
2. **Click the Remove City button.**

   If you want to keep the location but change the coordinates or time zone, type the new coordinates or time zone, then click the Add City button.

Index

A

accent marks, typing 277
access privileges 216–220. *See also* file sharing; network
  checking 220
  set by others 219
  setting 217
  strategies for using 218–219
  types of 216
  turning on 203
active program 54–56, 58
  identifying 94
active window 38–40
  printing contents of 180
ADB devices. *See* Apple Desktop Bus devices
air travel tips 247–248
Alarm Clock
  setting alarm 159–160
  setting time 158–159
  turning alarm off 160
alert sound. *See* beep sound
alias
  connecting to a shared disk with 198
  creating 128
  locating original of 129
  locking 118
  searching for 133
  troubleshooting 128
  uses of 128
APDA (Apple Programmers and Developers Association) 251–252
AppleCare Service Agreement 250
Apple Desktop Bus (ADB) devices
  connecting 243
  power consumption of 243
Apple File Exchange 279
  converting files with 281–283
  initializing a disk with 279–280
Apple HDI-30 SCSI System Cable 226, 228, 229, 232
Apple HD SC Setup program 114, 124
Apple menu 34
  adding items to 129, 156
  removing items from 129, 156
Apple Menu Items folder 129, 156
AppleShare icon 196
AppleShare PC program 282
AppleTalk
  sleep and 109, 194
  turning on/off 193–194
  zones 196
Apple II ProDOS format
  converting files to and from 281–283
  initializing a disk in 279–280
Application menu
  hiding and showing windows 94
  making an open program active 56, 94
  switching programs 94
application programs 57
  installing 92
  locating 133
  making active 56
  switching 94
  troubleshooting 92, 272–273
arrow keys 49, 258, 275
arrow pointer 32
AutoRemounter control panel 199

B

background pattern, changing 146–147
background printing 177, 183
backlight dimming 240
backup copies 119
backup program 119
Balloon Help 83–84
battery
  caring for 23, 25, 247
  cautions about 107, 247
  low-power messages 102–103
  maximizing life of 107
  maximizing work time with 108–112
  monitoring charge level of 101–103
  power conservation 108–112
  processor cycling and 111
  processor speed and 112
  recharging 103–106
  removing or replacing 106–107
  safety tips for 107
  SCSI disk mode and 234
  sleep and 18, 109, 110
  troubleshooting 262
  using the computer without 102
Battery desk accessory 82, 101–102
beep sound. *See also* sounds
  choosing 139–140
  installing 140
  recording 141–142
  removing 141
Berkeley Macintosh User's Group 251
binary translation 281
bitmap 185
bitmap fonts 184, 185
blinking icons 5, 87, 264
blinking line. *See* insertion point
border color of windows 145
Boston Computer Society 251
brightness, adjusting 5, 28, 108
bulletin boards
  access privileges for 219
  viruses and 93

C

cables
  safety instructions 23
  for SCSI connections 226, 228, 229, 231, 232
Cache Size box 176
Caps Lock key 275, 276
care and maintenance 23–26
carpal tunnel syndrome 26
CD-ROM disc
  access privileges and 216–220
  connecting 225–229
  ejecting 120
  selecting for sharing 204–205
changed files, searching for 133
character repeat rate, adjusting 165
character sets 275–276
Chooser 175–177, 193–194
choosing a command 36, 257
cities, getting information about 285–288
cleaning the computer 25
Clean Up command 125
Clear command 96
clicking 33
Clipboard 60

clock, setting 158–160
close box 44–45
CloseView control panel 152–153
Close Window command 46
closing a document 56, 65
closing a window 44, 45
color
  changing in Label menu 148–149
  displaying 143
  highlight color 144–145
  icon color 136, 147
  printing 181
  window border color 145
Color control panel 144
comfort 27–29
Command key 49, 62, 275
commands
  choosing 36, 257
  keyboard shortcuts for 62, 258
computer viruses 93, 261
connecting. *See* file sharing, hardware configuration, network, *specific equipment*
contrast, adjusting 5, 28
Control key 275
control panels 82–83
  appearance of Finder windows 168
  AppleTalk 193
  AutoRemounter 199
  background pattern 146–147
  battery conservation 109–112
  beep sound 139–142
  color 144
  date and time 158–159, 161, 162
  desktop pattern 146–147
  disk cache 172
  Easy Access 166
  file sharing 202–208, 209–210, 212–215
  hard disk sleep 110
  insertion point blinking 167
  internal/external modem 242
  keyboard response 165
  labels 148, 158
  map 285–287, 286–287
  memory 172–174
  menu item blinking 158–159
  monitors 143, 149, 238, 239
  network identity 194, 215
  numbers 163
  opening 82–83
  program linking 222–224
  RAM disks 97–98
  SCSI ID number 230
control panels *(continued)*
  shared disks 199
  sleep 109–110
  sound 139–142
  startup disk 116–117
  32-bit addressing 174
  time 158–159, 161, 162
  trackball speed 164
  virtual memory 173–174
copying
  a disk 74–75, 78–79, 119
  a document 65–66, 119, 254
  files without a floppy disk drive 92
  items to and from Scrapbook 96
copyright law, program sharing and 204
creating
  alias 128
  document 52–53
  folder 126
  folder on a shared disk 200
  stationery 134–135
currency formats, changing 163
cursor. *See* pointer
customer service 250
customized system software, installing 90–91, 179–180
Cut command 60

D

damage to computer 249
date
  format, changing 160, 161
  searching for files by 133
  setting 158–159
Date & Time control panel 158–159, 161, 162
DCA-RFT/MacWrite translator 281
dealer support 250, 259
Delete key 53, 275
deleting
  a file 67–68
  Scrapbook items 96
  text 59–60
  typing errors 53
deselecting an item 35
desk accessories (DAs)
  Battery 101–102
  Chooser 175–177, 193–194
  Key Caps 276–277
  switching among 94
desktop 20
  changing background pattern 146–147
  contents of 20, 46–48
  dragging an object on 35
  hiding and showing windows on 94
  moving an item to 129
  pointing to an object on 32
  printing contents of 181
  selecting an object on 33
  straightening up 125
desktop Macintosh. *See* Macintosh desktop computer
diacritical marks, typing 277
dialog box 72
directory 127
  saving a file in 127
directory dialog box 127, 258
disk cache 176
  adjusting the size of 176
disk capacity 70, 71
disk drives 70, 71
diskettes. *See* floppy disks
Disk First Aid program, using 122–123
disk repair programs 266
disks 70. *See also* floppy disks; hard disk
  backing up 119
  caring for 75, 121
  copying the contents of 74–75
  ejecting 76, 120
  erasing 116
  formatting. *See* initializing
  initializing floppy disk 72–73, 113, 115
  initializing hard disk 113–114
  inserting 70
  installing programs on 78–79
  locking 77, 117
  removing items from 67–68
  repairing 121–123, 266
  startup 116–117
  testing 121–124
Disk Tools disk
  Apple HD SC Setup program on 114, 124
  Disk First Aid program on 122
  starting up with 22, 91
display. *See also* external monitor
  background pattern, changing 146–147
  brightness of 5
  changing attributes of 144–147
  cleaning 25
  comfort tips 28
  contrast of 5
  dimming 108, 151
  displaying colors or grays 143
  highlight color or gray 144–145
  icon colors, changing 147
  magnifying image on 152–153
  opening 3
  position of 3
  power consumption of 108
  troubleshooting 259, 264
  window border color 145
distances between locations. *See* Map control panel
Document Content Architecture (DCA) format 281

documents 48
adding to Apple menu 156
aliases for 128–129
backing up 119
changing 58–64
closing 56, 65
converting to and from stationery 134–135
copying 65–66
creating 52–53
naming 53–54, 127
opening 57–58, 65
opening automatically 156
printing 180–182
saving 53–54, 61–62, 127
saving as a template 134–135
"Don't sleep when plugged in" option 262
double-clicking 58, 253
adjusting speed of 164
downloading printer fonts 186–187
dragging 35
drivers 156, 226
drop box 219
drop folder 219
duplicating a document 65–66, 254

E

Easy Access control panel 166
Easy Install dialog box 89
ejecting a floppy disk 76, 120
electronic bulletin boards. *See* bulletin boards
emptying Trash 68
turning off warning 170
erasing
a floppy disk 116
a RAM disk 98
typing errors 53
ergonomics 27–29
error messages 21, 139. *See also* troubleshooting
in printing 182
in SCSI disk mode 231
Ethernet cables 193
extended warranty coverage 250
Extensions folder 194, 196
external microphone 244
external modem. *See* modem
external monitor 29, 149–150, 236–241
activating 238
backlight dimming 240
connecting 236–238
designating as main monitor 149
disconnecting 241
ID number of 150
multiple monitors 149–150
power adapter and 236
presentations, using for 150
processor cycling and 240
sleep and 240
troubleshooting 238, 239, 265
video mirroring 240
external recharger 105–106
external SCSI disk drive
connecting 226–229
as startup disk 117
using your computer as 22, 230–232

F

fax/data modem 242
files
  adding to System Folder 156–157
  assigning label and color to 136
  backing up 119
  closing 56, 65
  color of icons 136, 147
  converting to and from MS-DOS format 281–283
  deleting 67–68
  getting information about 135–136
  labels for 136
  locating 128–129, 130, 133
  locking 77, 118
  opening 37, 65
  organizing 126, 136
  program vs. document 47–48
  removing from System Folder 157
  shared disk access to 195–199
  sharing. *See* file sharing
  straightening up 125
  system. *See* System Folder; system software
  throwing away 67–68
  transferring 137
file server 195. *See also* shared disks
  and MS-DOS files 282
file sharing *See also* access privileges; network
  changing your password 200–201, 215
  checking access privileges 220
  connecting to a shared disk 195–197, 198–199
  creating a folder on a shared disk 200
  disconnecting from a shared disk 197
  disconnecting someone from your disk 213–214
  files that belong to others 200–201, 216–220
  files that belong to you 194–199, 200–202
  gaining access to your own computer 214–215
  giving away ownership of a folder or disk 201, 211–212
  monitoring 213
  naming users or groups for sharing 205–207
  preventing access to your disk 205
  reconnecting to shared disks 199
  restricting access to your disk 209–210
  setting access privileges 217–219
  selecting a folder or disk to share 204–205
  selecting users or groups for sharing 208–209
  troubleshooting 194, 205, 271
  turning off 212
  turning on 202–203
File Sharing Monitor 213
File translators 281–283
Find command 130
Find dialog box 130, 131
Finder 54, 57
  changing display of window contents 168
  checking memory use in 171, 245
  keyboard shortcuts in 258
  making active 55–56
finding items on a disk 130–133
fixed-size (bitmap) fonts 184, 185
floppy disk drive 69, 70
  in scanning order 117
  removing disk from 76, 120
  restarting with 22
  starting up with 91
  troubleshooting 120, 266, 267
floppy disks 47, 70, 71
  backing up contents of 119
  capacities of 70, 71
  caring for 75
  copying contents of 74–75
  ejecting 76, 120
  erasing 116
  initializing 72–73, 113, 115
  initializing in MS-DOS format 279–280
  inserting 70
  installing system software from 87–91
  locking and unlocking 77, 117
  obtaining 69
  removing from drive 76, 120

floppy disks *(continued)*
restarting from 22
starting up from 22, 91
transferring files from 137
troubleshooting 119, 120, 122–124, 266–267
folders 47
access privileges to 216
aliases for 128
changing ownership of 201, 211–212
creating and naming 126
creating on another computer 200
deleting 67–68
locking items in 118
opening higher-level folder windows 255
organizing files in 126
sharing 204–205
setting access privileges for 217
throwing away 67–68
fonts 184–188
bitmap (fixed-size) 184, 185
font families in suitcase 185, 186
installing 185
Key Caps program and 276–277
outline (scalable or variable-size) 184
removing 186
seeing which are available 188
transferring to a LaserWriter 186–187
troubleshooting 182
TrueType 184
Fonts folder 185, 186, 188
formatting. *See* initializing

G

gaining access to your computer over a network 214–215
troubleshooting 271
General Controls panel
date 158–159
desktop pattern 146–147
insertion point blinking 167
menu item blinking 167
time 158–159
Get Info command 135
gray-scale documents, printing 181
gray shades. *See also* color
assigning to icons 147
changing in Label menu 148–149
displaying 143
highlight 144
group, registered. *See* registered group
guest
access privileges of 203, 216, 218
allowing to link to your programs 223
allowing to share your files 203, 204, 216, 218
connecting to a shared disk as 195–196
creating a folder as 200
denying access to 209–210
linking programs as 220–221
removing from a group 211

H

halftone printing 181
hard disk 47, 71
backing up 119
capacity of 71
caring for 121
changing ownership of 211–212
connecting to your computer 225–229
connecting to a printer 188
damage symptoms 113
deleting items from 67–68
designating as startup disk 116
finding items on 130–133
hard disk sleep 110
initializing (formatting) 72, 113–114
installing programs on 78–79, 92
installing system software on 5, 87–91
saving space on 90
scanning order at startup 117
sharing someone else's 195–199
sharing your own 202–209
as startup disk 20, 71
testing and repairing 121–124
transferring files from 137
troubleshooting 121–124, 266
using your computer as 230–232
virtual memory and 173–174
hard disk icon 47, 71
failure to appear 121–122
removing from desktop 120

hardware configuration
ADB devices 243
external monitor 236–241
headphones or speakers 245
memory 245
microphone 244
modem 242
mouse 243
printer 243
SCSI devices 225–229
using your computer as a SCSI disk 230–232
hardware development support 252
HDI-30 SCSI System Cable 226, 228, 229, 231
headphones, connecting 245
health concerns 26
Help menu 83–84
hidden windows, viewing 94
Hide Balloons command 84
highlight color or gray, changing 144–145
highlighted (selected) icon 33

I, J

I-beam pointer 58
locating 58
using to move insertion point 59
icons 20, 46–47
alias 128
changing appearance of 169–170
changing names of 66–67, 254
clicking 33
colors, assigning 136, 147
copying 254
double-clicking 58, 253
dragging 35
highlighting 33
identifying 46–48, 71
label and color, assigning 136, 147
moving 254
opening 37, 254
organizing 125, 126
pointing to 32
pressing 34
question mark 5, 87
renaming 66–67, 254
selecting 33, 253
straightening up 125
ID numbers
for monitors 150
for SCSI devices 150, 226–227, 230, 233–234
ImageWriter
Page Setup options for 178
selecting in Chooser 176
troubleshooting 182
Info window 135
changing an icon 169–170
creating stationery 134
getting information about a file 135
locating original of an alias 129
locking a file 118
initializing 72, 113
a floppy disk 72–73, 115
a floppy disk in MS-DOS format 279–280
a hard disk 113–114
injuries 26
inserting text 53
insertion point 53, 58
adjusting blinking of 167
positioning 59
Installer program 88–89, 179–180
installing
Apple menu items 156
fonts 185
printer software 176, 179–180
programs 74–75, 78–79, 92
sounds 140
System Folder items 156–157
system software 6, 87–91
system software in SCSI disk mode 233–234
without a floppy disk drive 92
Install Me First disk 6, 88, 90, 99
internal modem. *See* modem
interrupt button 21

K

keyboard 49, 275
  adjusting response of 165–166
  comfort tips 27
  turning computer on from 18, 109
Keyboard control panel 165
keyboard shortcuts 62, 166, 258
Key Caps desk accessory 276–277
kilobyte (K) 70, 71

L

Label menu
  changing colors in 148–149
  changing labels in 158
labels
  assigning 136, 138, 158
  changing 158
  searching for 133
Labels control panel 148, 158
LaserWriter
  background printing with 177, 183
  fonts available for 188
  Page Setup options for 178
  printing on 180–181
  restarting 189
  selecting in Chooser 176
  start page, turning on or off 189
  transferring fonts to 186–187
  transferring PostScript files to 190
  troubleshooting 182
LaserWriter Font Utility program 188
  downloading fonts with 186–187
licensing agreements
  file sharing and 205
  software installation and 92
lightning bolt icon 104
linking programs 220–224
LocalTalk cable, connecting 193
locations, information about. *See* Map control panel
lock, security 249
locked box, in Info window 118
locked files, searching for 133
locking files 118
locking/unlocking a disk 77, 117
low-power messages 102–103

M

Macintosh Basics tour 11–15
Macintosh desktop computer
  backing up files 119
  connecting PowerBook to, as SCSI disk 230–232, 235
  gaining access to your computer 214, 215
  installing files 92, 121, 233–234
  reinstalling system software 233–234
  sharing files 202
  transferring files 202
Macintosh HD icon, opening 37
MacWrite format, converting to and from 281–282
magnifying the screen image 152–153
maintenance 23–25
Map control panel 285–288
  adding locations 288
  changing or removing locations 288
  comparing locations 286–287
  finding locations 286, 287
  setting location 285–286
member (of a group) 207–208
memo pad. *See* stationery

memory. *See also* disk cache; RAM disk; virtual memory
adding 245
changing a program's use of 95
checking use of 171
and disk cache 172
managing 171–174
and 32-bit addressing 174
troubleshooting 171, 174, 264
virtual 108, 173–174
Memory control panel,
adjusting disk cache size 172
creating a RAM disk 97–98
resizing or removing a RAM disk 98
turning on/off 32-bit addressing 174
turning on/off virtual memory 173–174
menu bar 20
menu item, blinking of 167
menus 20, 36, 48
choosing items from 257
commands in 36
keyboard shortcuts 62
pulling down 34
submenus 257–258
titles (names) of 20
viewing 34
microphone
built-in 249
external 244
mistakes, deleting 53
modem
external, connecting 242
power consumption of 108, 242
selecting internal/external 242
transferring files with 137
troubleshooting 268
modem port 242
modifier keys 49, 62, 275
Sticky Keys feature with 166
typing special characters with 276–277
monitor. *See* display; external monitor
monitoring file sharing 213
Monitors control panel 143, 149, 238
mouse 28. *See also* trackball
Mouse control panel 164
moving
icons 245
text 60
windows 45–46, 254
MS-DOS format
converting to and from 279, 281–283
initializing a disk in 279–280
multiple monitors 149–150
multiple programs, working with 93–94

N

naming
a document 53–54
a folder 126
an icon 66–67, 254
your Macintosh 194
a registered group 207
a registered user 205–206
network 191–192. *See also* access privileges; file sharing
accessing your own computer 214–215
assigning access privileges 203, 216–220
assigning passwords to registered users/groups 206
ceasing to share a folder/disk 205
changing folder ownership 201, 211–212
changing your password 200–201, 215
checking your access privileges 220
choosing a printer 176–177
connecting to 193
connecting to a shared disk on 195–197
disconnecting from a shared disk 120, 197
disconnecting users from your computer 213–214
guest access 203, 204, 209–210, 216, 218, 233
installing system software 88–91
linking programs 220–224
monitoring file-sharing activity 213

network *(continued)*
naming registered groups 207
naming registered users 205–206
preventing access to your computer 209–210
removing users/groups from your list of registered users 211
selecting a printer 177
selecting a zone 177, 196
selecting one user/group for sharing 208–209
setting up your computer 192–194
shared disks 47, 120, 195–199
sharing your own files 202–215
sleep and 109
starting file sharing 202–203
stopping file sharing 212
transferring files over 137
troubleshooting 194, 196, 205, 269, 270–271
updating printer software 179–180
viewing group member names 207–208
viruses and 93
working with files and folders 200–202
network administrator 177, 192, 193, 195, 200
new folder, creating 126
nickel-cadmium (NiCad) batteries. *See* battery
Number control panel 163
number formats, changing 163

O

opening
display 3
document 57, 58, 65
folder 255
icon 37, 58, 254
program 52
operating system 57, 87–91
Option key 49, 275
organizing files 125–129
in folders 126
outline fonts 184
outline form in list views 256
overwriting text 63–64

P

Page Setup options 178
password
assigning to others 206
changing your own 200–201, 215
Paste command 60, 96
pattern, background 146–147
performance
memory management and 171, 174
of programs 92, 111, 112
32-bit addressing and 174
virtual memory and 173–174
Personal LaserWriter SC. *See* LaserWriter
plug adapters 248–249
pointer
arrow 32
I-beam 58–61
pointing 32
PostScript file, transferring to LaserWriter 190
PostScript fonts, downloading 186–187
PostScript Log, creating 190
power adapter
conserving power with 108
“Don’t sleep when plugged in” option 110
external monitor and 236
for external recharger 105
long-term storage and 249
plugging in 2
preventing automatic sleep while using 110
recharging battery with 2, 103, 104
short-term storage and 248
StyleWriter printer and 243
travel tips 248
power adapter port 2
PowerBook control panel 82–83
adjusting hard disk sleep 110
adjusting system sleep 110
assigning SCSI disk mode ID 230
battery conservation 108–112
opening 82–83
processor cycling 111
processor speed 112
selecting internal/external modem 242
working with virtual memory 108, 174

power button 233
restarting the computer with 22
"Shut Down" warning 17
turning on the computer with 4, 19
power management 101–112
power problems
low battery 102–103
in SCSI disk mode 235
troubleshooting 261–262
power states 17–19
power usage
ADB devices 243
disks vs. RAM disks 97
microprocessor 111, 112
modem 108, 242
screen brightness 108
SCSI disk mode 234
virtual memory 108
presentations, using a monitor for 150
pressing 34
Print command 180–181
printer
choosing 175–177
connecting 243
downloading fonts to 186–187
installing fonts on 185
installing printer software 176–177
LaserWriter Font Utility and 188
outline vs. bitmap fonts 184–185
out of paper 183
PrintMonitor and 183
removing fonts from 186
restarting 189
selecting Page Setup options for 178
troubleshooting 182, 269–270
updating printer software on networked computers 179–180
printer port 243
printing 180–182
background 177, 183
color or gray-scale 181
desktop contents 181
fonts for 182, 184–185
LaserWriter start page 188
on network 176–177, 179–180
Page Setup options for 178
troubleshooting 176, 177, 182, 269–270
window contents 181
PrintMonitor 183
processor cycling 111
external monitor and 240
processor speed 112
ProDOS format. *See* Apple II ProDOS format
programs 47
adding to Apple menu 129, 156
aliases for 128–129
application vs. system 57
automatically starting up 156
changing memory use of 95
disk repair 266
installing 74–75, 78–79, 92
installing without a floppy disk drive 92
linking 220–224
making active 54–56
memory use of 171
multiple 93–94
opening 52, 65
performance of 92, 111, 112
quitting 56, 64, 65
RAM disks and 97–98
sharing caution 204
switching among 54–56, 94
troubleshooting 92
types of 57
protecting disk contents 77, 117–118
Put Away command 76, 120, 197

Q

question mark startup icon 5, 87, 117
question mark (Help menu) icon 83–84
Quit command 64
quitting
  a program 56, 64, 65
  SCSI disk mode 235
  turning the computer off 17

R

RAM. *See* random-access memory
RAM disk 97–98
  creating 97–98
  conserving power with 97, 108
  erasing 98
  memory recommendations for 97, 99
  resizing or removing 98
  restarting and 99
  shutting down and 97
  temporary nature of 97
  using as a startup disk 99, 108
random-access memory (RAM). *See also* RAM disk
  adding 245
  checking use of 95, 171
  disk cache and 172
  management of 171–174
  preserved in sleep 110
random-access memory *(continued)*
  preserved under low-power conditions 103
  programs' use of 95
  amount needed for RAM disk use 97, 99
  32-bit memory and 174
  virtual memory and 173–174
recharging the battery 103–106
reconnecting to shared disks 199
recording sound 141–142
registered group 207–208, 217
  access privileges of 216, 217
  exclusive access for 208–209
  linking programs 224
  naming 207
  removing a user from 211
  seeing members of 207–208
  setting access privileges for 217
registered user 195, 216
  access privileges of 216, 217
  changing password 200–201
  connecting to a shared disk as 195–197
  creating a folder as 200
  denying access to 209–210
  disconnecting 213–214
  exclusive access for 208–209
  linking programs 220–221, 224
  naming 205–206
  removing 211
  setting access privileges for 217
  setting password for 206
  sharing your files with 202
removing
  battery 106–107
  dirt 25
  extra System Folders 79, 91
  floppy disk 76, 120
  fonts 186
  RAM disk 98
  registered user or group 211
  sounds 141
  System Folder items 157
  unwanted files 67–68
repetitive stress injuries 26
replacing the battery 106–107
reset button 21
Restart command 7, 21
restarting the computer 21–22
  to solve a problem 21
Return key 258, 277
run time, maximizing 108–112

S

safety instructions 23–26, 107, 247–248
Save As command 134
Save command 53–54, 61–62, 134
saving your work 53–54, 61–62
  in a directory 127
  as a template 134–135
scalable fonts. *See* outline fonts
scanning order 117
Scrapbook 96
screen. *See also* external monitor
  background pattern, changing 146–147
  brightness of 5
  changing attributes of 144–147
  cleaning 25
  comfort tips 28
  contrast of 5
  dimming 108, 151
  displaying colors or grays 143
  highlight color or gray 144–145
  icon colors, changing 147
  magnifying image on 152–153
  opening 3
  position of 3
  power consumption of 108
  troubleshooting 259, 264
  window border color 145
scroll arrows 43–44, 255
scroll bars 43–44, 255
scroll box 44, 255
SCSI (Small Computer Systems Interface) 225
SCSI chain 225. *See also* SCSI disk mode
  configurations for 229
  ID numbers in 122, 226–227
  length of 229
  termination, rules for 228
SCSI devices 225. *See also* SCSI disk mode
  connecting 226, 228, 229
  ID numbers for 122, 150, 226–227
  installing software for 226
  terminators for 228
  troubleshooting 264–265
SCSI disk mode 230
  battery use in 234
  configurations for 232
  connecting your computer in 230–232
  quitting 235
  reinstalling system software in 233–234
  setting ID numbers for 230
  simplifying connection process 233
  terminators for 231
SCSI icon 225
SCSI peripheral interface cable 229, 232
SCSI port 225
SCSI terminator 228
searching for files 130–133
security feature 249
seeing hidden windows 94
selecting an icon 33, 36–37, 253
selecting text 59–60, 63–64
serial port 242, 243
service locations 250
setting up
  computer 1–29. *See also* hardware configuration
  computer on a network 192–194
  programs 87–99
shared disks 47, 195. *See also* file sharing
  access privileges for 217–218
  belonging to you 201–205
  ceasing to share 205, 209–210, 212, 213–214
  changing folder ownership on 201, 211–212
  connecting to 195–197
  creating new folders on 200
  disconnecting from 120, 197
  reconnecting to 199
  sleep and 109
  using files and folders on 200, 201
shared files. *See* file sharing
shared folders, access privileges for 217–218
Sharing Setup control panel
  changing your password 215
  identifying your computer on the network 194
  turning file sharing off 212
  turning file sharing on 202
  turning program linking on/off 222

shift-clicking 253
Shift key 49, 275
shortcuts. *See* keyboard shortcuts
Show Balloons command 83
Shut Down command 17, 97
size box 40–43
size of window, changing 40–41
sleep 17, 18, 109–110
  adjusting 109–110
  automatic 18, 103, 109, 110
  conserving power with 18, 109–110
  external monitor and 240
  hard disk sleep 110
  low power and 103
  network use and 109
  preventing 109
  reconnecting to shared disks after 199
  troubleshooting 262
  waking the computer from 18, 103, 109
  when to use 18, 108
Sleep command 18
Slow Keys feature 166
Small Computer Systems Interface. *See* SCSI
software. *See* programs; system software
software developer support 252
software drivers 156, 226
software licensing agreements 92, 205
Sound control panel
  choosing a sound 139–140
  recording a sound 141–142
  removing a sound 141
  setting sound volume 140
sound input port 244
sound output port 245
sounds
  choosing 139–140
  installing 140
  recording 141–142
  removing 141
  setting volume of 140
  when alarm rings 159–160
  with Slow Keys feature 166
  with Sticky Keys feature 166
speakers, connecting 245
starting up your computer 4–5, 19–22
startup disk 71, 79
  conserving space on 157
  designating 116–117
  installing system software on 87–89
  RAM disk as 99
  scanning order for 117
  System Folder on 79, 91, 157
  troubleshooting 87, 121–122, 260
  VM Storage file on 174
Startup Disk control panel 116
startup disk icon 20, 71
Startup Items folder 156
stationery, creating 134–135
Sticky Keys feature 166
storing items in Scrapbook 96
storing the computer 248–249
  battery charge and 103, 248–249
StyleWriter printer
  background printing with 183
  power adapter caution 243
submenus, choosing items from 257–258
suitcase icon 185
support services 250
System 7, networked computers and 179, 202
system error, restarting after 21, 22
System file. *See* System Folder
System Folder 47, 87. *See also* system software
  installing files in 156
  installing fonts in 184, 185
  installing sounds in 140
  listing fonts in 188
  on program disk 78–79
  putting files in 156–157
  removing extra System Folders 79
  removing files from 157
  removing fonts from 186
  removing sounds from 141
  on startup disk 88, 91
  VM Storage file in 174
system sleep. *See* sleep
system software 57. *See also* System Folder
  fonts and 184–186
  installation, custom 90–91
  installation, standard 88–89
  reinstalling in SCSI disk mode 233–234
  sounds and 141
  special files and 156–157
  troubleshooting 261, 266

T

Tab key 258, 275
TeachText program 52
technical information 251–252
technical support 250
telephone lines, transferring files over 137
templates, creating 134–135
text
  changing 58–64
  deleting 59–60
  inserting 53
  moving 60
  replacing 63–64
  selecting 59–60, 63–64
  typing 53
text translation 281
32-bit addressing 174
3.5-inch disks. *See* floppy disks
time
  automatic reset during travel 285
  format, changing 160, 162
  setting clock 158–159
  time zones, tracking 285–287
title bar 40, 45
TokenRing cables 193
trackball 32
  adjusting 164
  buttons 32
  choosing a command with 36
  clicking with 33
  comfort tips 27
  dragging with 35
  pointing with 32
  pressing with 34
  using 32–36
transferring files 137. *See also* copying
translators 281–283
Trash 67–68
  deleting files/folders with 67–68
  ejecting a disk with 120
  emptying 68
  location of 20
  purpose of 48
  turning off warning for 170
traveling, tips for 247–248
troubleshooting 259–273
  access to your computer over a network 214–215, 271
  aliases 128
  Apple menu items 129
  application programs 92, 272–273
  battery 262
  blinking icons 87, 264
troubleshooting *(continued)*
  computer is hot 260
  computer stops working 21, 260
  damage to computer 249
  external monitor 238, 239
  file sharing 194, 205, 271
  floppy disk drives 120, 266, 267
  floppy disks 119, 120, 122–124, 266–267
  fonts 182
  hard disks 121–124, 266
  heat 260
  lost windows 264
  memory 170, 264
  modems 268
  network 194, 196, 205, 214–215, 269, 270–271
  odd behavior 261
  power problems 261–262
  printers 182, 269–270
  printing 176, 177, 182, 269–270
  screen 259, 264
  SCSI devices 264–265
  sleep 262
  starting up 5, 21–22, 87 121–122, 259
  system crash 21, 260
  system software 261, 266
  32-bit addressing 174
  viruses 93, 261
  windows 264

TrueType fonts 184
  downloading 186–187
  installing 185
turning computer off 17
turning computer on 4–5, 19
  and connecting automatically to a shared disk 198–199
  from keyboard 18, 109
turning file sharing off 212
turning file sharing on 202–203

U

Undo command 273
unlocking
  disks 77, 117
  files 118
untitled window 52, 53
upgrades, memory 245
user groups for Macintosh 251
user name 205–206
user, registered. *See* registered user
Users & Groups control panel
  assigning a password 206
  denying file sharing access 209
  gaining access to your computer over a network 214–215
  naming a registered group 207
  naming a registered user 205
  naming users for program linking 223
  removing a registered group 121
  removing a registered user from a group 211
  turning on guest access 203

V

variable-size fonts. *See* outline fonts
VGA monitor 236
video adapter cable 236–237
video mirroring 150, 240
video port 236–237
viewing hidden window contents 42–44
viewing hidden windows 94
View menu 136, 256
Views control panel, using to change the way Finder windows appear 168
virtual memory 173–174
  power use and 108
viruses 93, 261
VM Storage file 174

W, X, Y

waking the computer 18, 103, 109
warranty service 24, 250, 259
window 37, 38, 48
  active 38–41, 55, 254
  changing appearance 168
  changing border color 145
  changing name 66–67
  changing size 40–41, 254
  closing 44
  finding 264
  hiding and showing 94
  making active 38–41, 254
  moving 45–46, 254
  printing contents of 181
  rearranging items in 136
  scrolling through 255
  straightening items in 125
  title bar of 45
  troubleshooting 264
  untitled 52, 53
  viewing contents of 38–44, 136, 255
word wrap 53

Z

zones
  comparing time 286–287
  selecting AppleTalk 177, 196
zoom box 40–41

Apple Computer, Inc.
20525 Mariani Avenue
Cupertino, California 95014-6299
(408) 996-1010
TLX 171-576

030-2674-A
Printed in U.S.A.