



MATTEL ELECTRONICS® WORLD CHAMPIONSHIP™ FOOTBALL



INSTRUCTIONS




LINE UP WITH ELECTRONIC SUPERSTARS...FACE AN OPPONENT! OR FACE THE COMPUTER!



BATTERY INSTALLATION

Turn game over. Open and remove Battery Compartment door. Follow the battery instructions inside. Insert SIX C-CELL batteries as shown. Batteries go end-to-end in two rows.



This game has been designed to meet all applicable FCC rules. Because of this, there is very little chance that this game will cause interference to television or radio reception. However, the FCC has asked all electronic game manufacturers to give you the following information:

If you notice interference with radio or television reception while this game is on, move the game away from the television or radio. If the game is the cause of the interference, then moving the game away from the radio or television should eliminate the problem. If you are having problems with your radio or television reception you may find the following booklet (Stock #004-000-00345-4) helpful: "How To Identify and Resolve Radio and TV Interference Problems". This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402.

• CHECK OUT THE CONTROLS

HOME TEAM KEYPAD

(SAME CONTROLS BOTH SIDES)


VISITOR KEYPAD

PLAY CALLING
DIRECTION KEYS

STATISTICS
DISPLAY

DOOR (CONCEALS
PLAY CALLING)

RECEIVERS 1 & 2



KICK

ENTER

TIME OUTS

ON/OFF
SWITCH

ACTION DIRECTION KEYS
(CONTROLS RUNNING
AND PASSING)

PASS/CATCH


DOWN/YARDS
TO GO

TIME LEFT
IN QUARTER

SCOREBOARD

FIELD
POSITION

SCORE



PLAYFIELD

• 2 WAYS TO PLAY


Mattel Electronics® WORLD CHAMPIONSHIP™ Football is fast-paced gridiron action! Call your own plays and set your own defense! Throw the bomb or run it in for a touchdown! Blitz your safety & sack the quarterback! Punts, field goals and onside kicks are part of the action. Play the game in two ways...

LINE UP AGAINST SOMEONE ELSE! Players sit side by side and each has his own set of controls. One player controls Home Team offense and defense (blue teammates). The other player controls Visitors offense and defense (green teammates). Open the doors to conceal your strategy from your opponent!


PLAY ALONE! You control offense for both Home Team and Visitors. You alternate using the left and right keypads, depending whether Home or Visitors has the ball! Computer always plays defense!

• THE GRIDIRON

The playing field is regulation length, 100 yards plus two end zones. However you only see 8 yards of the field at a time. Whenever the ball gets to the end of this 8-yard section, the computer immediately flips to the next section. Keep on moving!



The ball is in the quarterback's hands during rushing plays. When the ball is kicked, passed forward or pitched back, the ball is shown separately.




• TEAMS ON THE FIELD

All team members are shaped figures. Offense has 5 teammates: the quarterback, 2 receivers and 2 linemen. When you play on offense, you choose formations, call plays for the primary & secondary receivers, and control the quarterback's scrambling, passing and kicking. The 2 linemen are computer controlled.

Defense has 4 teammates: the safety, 1 back and 2 linemen. When you play defense, you cover one of the receivers (or blitz the quarterback), assign the back to cover the other receiver, make pass interceptions and control the safety's running. The 2 linemen and the back are computer controlled.

Home & Visitors face off in Formation 5. Home has the ball.




IMPORTANT: The following instructions are written for a 2-player game. The only exceptions for a 1-player game are listed under speed selection, page 5; defensive play calling, page 13; and defensive catching, page 17.

• **TURN THE GAME ON**


After you have installed the batteries , turn the game **ON** .

At the start of the game, the field and scoreboard look like this:




• **SELECT A SPEED**

After the game has been turned ON, both players must enter a speed. The speed does not have to be the same for both players. Use the play calling **DIRECTION KEYS** on either side to select a speed. Then press **ENTER** . Hear a beep after both teams have entered a speed.



Before pressing Enter, the scoreboard shows:



HOME TEAM PRESSED SPEED 2.


VISITORS PRESSED SPEED 1.

As the speed increases from 1 to 4, play action is faster. It's best to start at the slowest speed and play your way up. If two people play and one is much better, make it a more equal contest. Have the better player use a faster speed.

IF YOU ARE PLAYING ALONE, you **only** select and enter a speed for the Home Team. If you only press Enter on the Home side, the speed is automatically set at 1. Then press **ENTER** on the Visitor's side. Note: Do not press a number on the Visitor's side, or the computer will think there are 2 players!

• SCOREBOARD

After the speeds are entered for both sides the scoreboard shows the number of time outs per player, and if the 30-second clock is on or off.




HOME TEAM HAS 3 TIME OUTS


CLOCK IS OFF

VISITORS HAVE 3 TIME OUTS


To check the stats, before the game and between plays, press:




(BLANK AT KICK-OFF & POINT AFTER)



(15:00 AT START OF GAME)




(BALL AT 35 FOR KICK OFF)




(00 TO 00 AT START OF GAME)

During play and at the end of each play, before resetting for next play, the yard line position of the ball shows on the scoreboard.



BALL IS ON THE 25 YARD LINE.



• **CLOCK**

The game clock starts when the ball is put into play. The clock continues running except when:

- A score occurs.
- Ball is run out of bounds.
- Pass is incomplete.
- Ball turns over.
- Time out is called.
- Play is over after a kick-off return.
- Penalty occurs.

The 30-“second” clock starts only when the play clock is running **and** after you reset for the next play. On offense, you must finish play calling and put the ball in play before 30 “seconds” is up!

Penalty: If the 30-second clock runs out while you’re play calling (whistle), it’s an automatic 5 yard penalty. The clock stops. Now you have all the time you want to again choose a formation and call your plays. Note: If you get a penalty inside the 10 yard line, the penalty is half the distance to the goal.



PENALTY CALLED.


BOTH TEAMS HAVE 3 TIME OUTS.

Time out: You can call a time out **only** when the 30-second clock is running. To do this, press **TIME**. There's no penalty for a time out. Now you must re-enter a formation and call your plays. There are 3 time-outs per half, per player. No matter how many you've taken during the first half, you can't carry them over.

LET'S GET STARTED

• KICK-OFF

The Home Team kicks off to Visitors at the beginning of the game or after Home scores. To do this, the player on the left presses **KICK** and the ball goes downfield. The scoreboard changes quickly and the field "scrolls" as the ball is in motion. (Visitors kick-off on the right side at the start of the second half.)



HOME TEAM KICKS OFF FIRST HALF!

• RETURN THE KICK-OFF

The receiving team automatically catches the ball and tries to run it back. Press the action **DIRECTION KEYS** to maneuver the kick-off returner downfield (see Running page 14.) If the ball goes into the end zone (whistle), it's a touchback and the ball goes to the 20 yard line for the next play. Reset for the next play.

- **PLAY IS OVER**

Play ends: When the quarterback is tackled (whistle). Quarterback & tackler flash.


When the quarterback runs out of bounds (whistle). Quarterback disappears.

If the quarterback scores (change tune). Field sets up for the point after.


Or if there's an incomplete pass (whistle). Just the quarterback flashes.

- **RESET FORMATION**

At the end of a play, press any of the 4 **STAT KEYS** to reset the field for the next play. The offense and defense automatically reset to Formation 5. After you reset, the scoreboard shows the number of time outs left, and if the 30-second clock is on or off. If the 30-second clock is on, you'd better hustle through play calling! Important: After a score and at the end of the half, the field automatically resets to the kick-off formation, see page 7.



FIELD RESETS TO FORMATION 5. VISITORS HAVE THE BALL.




FIELD RESETS TO FORMATION 5. HOME TEAM HAS THE BALL.

SET-UP THE NEXT PLAY

• OFFENSIVE PLAY CALLING


Before each play begins (except a kick-off or point after), the player on offense must enter a formation and program pass or running patterns for both receivers.

Choosing formations: First study the five formations below. Remember, the field automatically sets up formation 5 after resetting the game. If you want to start with another formation, use the play calling DIRECTION KEYS and press the corresponding key for the formation you want. Then press **ENTER**. If you change your mind, before pressing Enter, just press another Direction Key and offense changes to another formation.



HOME TEAM OFFENSIVE FORMATIONS


FORMATION 1 SLOT T LEFT




FORMATION 2 DOUBLE WING T LEFT




FORMATION 3 SLOT T RIGHT



FORMATION 4 WING T LEFT



FORMATION 5 SHOTGUN



(Field is reversed for Visitors offensive formations)


NOTE: Formations 1 & 3 and 2 & 4 look alike on the display, but the receivers are in different positions. Defense doesn't know which you've programmed.

Programming receivers: Check out the field position and downs, then program your receivers for the next play. Choose your own pattern or one shown on page 11. Either receiver can be programmed first. Begin by pressing RECEIVER **1** or **2**. Then press the play calling **DIRECTION KEYS** for the pattern you'd like him to run.

Pressing any outside Direction Key once will program the receiver to move one space. Pressing the center Key will cause the player to pause. Press the center once for a short pause, and press several times for a longer pause. If you want to change the pattern, before pressing Enter, merely press the receiver number and start again.

You can program 4 directional changes per play. And pressing Pause from 1 to maximum 16 times in succession, counts as one directional change. You can only program the receivers to run a pattern within one 8-yard section. And the number of times you press the key is the number of "steps" the receiver attempts to move once play begins.

When you finish programming both receivers, press **ENTER**. Don't forget, if the 30-second clock is running, you have to be fast!




As soon as the ball is in play, the two receivers begin running their assigned routes. Once either receiver runs the entire pattern, he then moves randomly. If a receiver meets an obstacle — sideline, offensive or defensive man — he waits until he can get past it to complete the pattern. **Receivers cannot run out of bounds!** They flash when running a play, and stop flashing when the play ends.

Important: If you intentionally want a receiver to stop somewhere in a play, just program him to run out of bounds. Because he cannot do this, when he gets to this portion of the program, he will be stationary at the sideline for the rest of the play. For example, see receiver 2 under Formation 1 below.

• OFFENSIVE PATTERNS


(These are examples of patterns to program for each formation. Arrows indicate the number of times to press the corresponding Direction Keys. P indicates a pause.)

FORMATION 1



HAND OFF TO 1* THEN MAKE A QUICK PASS DOWNFIELD TO RECEIVER 2.


FORMATION 2



USE RECEIVER 2 AS A BLOCKER FOR RECEIVER 1. ONE RUNS DIRECTLY BEHIND THE OTHER.


*FOR HAND-OFF, SEE LATERAL PASS, PAGE 15.

FORMATION 3




HAND-OFF* TO 1 OR MAKE A QUICK PASS OVER THE MIDDLE TO RECEIVER 2.

FORMATION 4




AN OPTION PLAY. RECEIVER 1 IS DELAYED, BACKFIELD IN MOTION. RECEIVER 2 HAS A CROSS FIELD PATTERN.


FORMATION 5



SHORT SIDELINE PATTERN



DOUBLE HAND OFF



CRISS-CROSS PATTERNS



*FOR HAND-OFF, SEE LATERAL PASS, PAGE 15.

• DEFENSIVE PLAY CALLING

Before each play begins (except a kick-off or point after), the player on defense must position the defensive back and cover a receiver.

Positioning defensive back: During play calling, the defensive back is the only teammate that can be moved to one of four vertical positions. Use the play calling **DIRECTION KEYS** to position the back, based on your defensive strategy.

DEFENSIVE BACK CAN START IN ANY OF THESE POSITIONS



PRESS TO MOVE DEFENSIVE BACK UP.

PRESS TO MOVE DEFENSIVE BACK DOWN.

Covering receivers: The defensive back can cover receiver 1 or receiver 2. Press **1** or **2**. You can switch back and forth until the hike. If you don't press either, he will cover the receiver he covered on the last play.



PRESS TO ASSIGN BACK TO RECEIVER 1.

PRESS TO ASSIGN BACK TO RECEIVER 2.

*****IF YOU ARE PLAYING ALONE**, the safety automatically covers receiver 1, the defensive back covers receiver 2. All defense is computer controlled.


THE BALL IS IN PLAY

• HIKING

After offense and defense have finished play calling, the game can begin. To hike the ball, offense first presses **PASS**, then the backward action **DIRECTION KEY**. The ball goes to the quarterback.

• RUNNING

Control offensive rushing by pressing the action **DIRECTION KEYS** to maneuver the quarterback downfield. Avoid tacklers. The quarterback can run through a receiver to gain yardage, but the receiver disappears. However the quarterback can't run through linemen.



Control defensive movement by pressing the action **DIRECTION KEYS** to move the safety. If you run the safety out of bounds, he disappears and is out of play. He reappears at the next play.

If any defensive man runs into any offensive man, or visa versa, 3 things can happen: Neither moves, one pushes the other back, or one goes through the other.


If any defensive man runs into the quarterback, or visa versa, the quarterback gets tackled. The safety can sometimes make the quarterback fumble by rushing him (double whistle). Note: In the case of a fumble, the safety gets possession of the ball.

Important: When you first begin, you might step out of bounds alot. Don't worry! You'll soon get used to the controls.

• PASSING

There are two steps necessary to throw a pass. After the hike, press **PASS**. The ball becomes invisible. The action Direction Keys now control the direction the ball will be thrown: forward, backward, and laterally. To throw the ball, make sure that the quarterback lines up with a receiver, then press the action **DIRECTION KEY** in the direction desired.

FOR A FORWARD PASS,
PRESS PASS THEN THE
FORWARD DIRECTION KEY



After the hike, if you go back for a pass, then decide to run, just press Pass a second time...instead of pressing a Direction Key to throw the ball. The action Direction Keys again control the quarterback. In this instance, the ball remains invisible until the quarterback crosses the line of scrimmage. Remember: Press Pass an odd number of times and the Direction Keys control passing. Press Pass an even number of times and the Direction Keys control the quarterback.

You can throw a maximum two lateral passes or one lateral and one forward pass per play. Unload the ball fast or you'll get sacked!

Forward Pass or Pitch Back: Press **PASS** and a horizontal action **DIRECTION KEY** to throw the ball. The ball becomes visible as soon as it is thrown. The quarterback can be tackled behind the line of scrimmage even though the ball is invisible. If the ball is past the line of scrimmage it can only be passed backwards.

Lateral Pass: Press **PASS** and a vertical action **DIRECTION KEY** and the ball is thrown. If there is a receiver in the backfield, in the direction of the pass, and behind the line of scrimmage, the receiver automatically catches it. But the ball remains invisible. This can also be used as a hand-off! The ball becomes visible when the ball crosses the line of scrimmage. No interceptions on vertical passes.


• PASS RECEPTIONS

Offense: During a play, when a passed ball is directly in front of the receiver, press the **[PASS/CATCH]** key. Time it right and the pass is complete. The quarterback disappears and the receiver becomes the new ball carrier. Play continues with 4 offensive men on the field: 1 receiver, 2 linemen and the receiver.


But if you press Catch too early, the receiver will drop the pass...incomplete. The quarterback flashes. Press Catch too late and the ball continues moving, and can be intercepted or go out of bounds.

Note: You can allow the ball to go past the first receiver in order to go downfield to the other receiver.

PASS COMPLETE




PASS INCOMPLETE



Defense: During a pass play, when the ball is directly in front of any defensive man, hit the **[PASS/CATCH]** key. Time it right and you'll intercept the ball. The defensive man catching the ball becomes the new ball carrier. Now you control his running. When there's an interception, play continues with 3 guys on the new offense: 2 linemen and the ball carrier. Note: After an interception, the new offense can't pass.

Important: If offense and defense are directly in front of one another, and both hit Pass/Catch, the first one to press the key gets the ball.




***** IF YOU ARE PLAYING ALONE,** the computer always plays defense! Defensive linemen cannot catch the ball, so passes are always over their heads. Defensive back and the safety always intercept the pass if the ball gets to them. Remember: You're always on offense! So you will use the left and right keypads, depending on who has the ball.

THE KICKING GAME

Normal Kick-Off: At the beginning of the half, and after any score, except a safety. Game automatically sets up with the ball on the 35 yard line. Offense lines up in kick-off formation. Press KICK .

OFFENSIVE LINE



KICK-OFF FORMATION

What happens:

Ball goes downfield. If it goes into the end zone, it's a touch-back...Play ends and the ball is set on the 20. If the ball falls short of the end zone the kick returner immediately runs it back. At this point, 4 special team defenders will appear, one at a time.

Play ends if the quarterback:
 runs out of bounds
 scores
 is tackled

THE KICKING GAME

Punt: During any down, at the field position of the ball. Reset formation. Offense and defense line up in Formation 5. Program a play. Then hike and press **KICK**. The 30-second clock could be running!

Free Kick: After a safety (tackled in opponent's end zone). Game automatically sets up with the ball on the 20. Offense lines up in kick-off formation. Press **KICK**.

Onside Kick: At the beginning of the half, after a TD or a safety. Game automatically sets up with the ball on the 35 yard line. Offense lines up in kick-off formation. Press **PASS** then **KICK**.

Field Goal: During any down, at the field position of the ball. Reset formation. Offense and defense line up in Formation 5. Program a play. First hike then press **PASS** & **KICK**. The 30-second clock could be on!

Point After: After a touchdown, there's no running. Game automatically sets up on the 2 yard line. Offense and defense line up in Formation 5. First hike then press **KICK**.

Important: You can't kick or punt if the quarterback moves first.

What happens:

Same as normal kick-off.

Same as normal kick-off.

Ball goes near mid-field. The ball stops and the team in possession flashes.

Ball goes downfield. If it goes into the end zone, it's a field goal. If it falls short of the end zone, the other side takes possession at the line of scrimmage. For example, attempt a field goal on the 19 and miss, the other team takes possession on the 19. Only the ball shows. Reset for the next play.

• GAME RULES

4 quarters

15 "minutes" per quarter

6 points per touchdown

1 point for point after

3 points for field goal

2 points for a safety (tackled in opponent's end zone)

Ball turns over after 4th down, if not advanced 10 yards.

No overtime. No 2-minute warning.

• SOUNDS

Beep	1st receiver's pattern entered Both players picked speeds Interception Ball kicked
Charge	Kick off Onside kick Touch down
2 whistles	Touchback Turnover Unsuccessful field goal attempt
1 whistle	Tackle Incomplete pass Out of bounds 30-second clock timed-out = penalty!
2 tone	Formation entered 2nd receiver's pattern entered Safety
5 tone	Point after td Field goal

• WINNING TIPS

Offense: Mix your plays! Shift formations!

Short passes are easier than long ones.

Use hand offs to fake out defense.

Avoid getting tackled by the safety! He can cause the quarter-back to fumble!

Stepping out of bounds can stop the clock. Good for play calling.

Call the plays quickly when the 30-second clock is running!

Develop your own playbook...and practice!

Defense: Don't run the safety out of bounds!

Only blitz occasionally or the offense will be able to pass around you.

When the safety is guarding a receiver, he might be able to push receiver back by hitting the forward button when right in front of him.

www.handheldmuseum.com

IF YOU NEED SERVICE FROM MATTEL ELECTRONICS® REPAIR CENTER...

it's available during **and** after the 90-day warranty period.

1. **Pack** the product carefully in its original box. If the box is not available, use a strong carton with plenty of newspaper or other padding. Enclose a brief note telling us the specific problem you are having with the unit, and your name and home address. Remove the batteries.

2. **Print** this address on the box:

MATTEL ELECTRONICS REPAIR CENTER

5000 WEST 147TH STREET

HAWTHORNE, CA 90250

...and your return address.

3. **Send** the package by insured parcel post.

During the warranty period, enclose proof of purchase date. After warranty has expired, enclose a check or money order for \$20.00.

90 DAY LIMITED WARRANTY

Mattel Electronics warrants to the original consumer purchaser of any of its electronic games (including hand-held electronic games) that the product will be free of defects in material or workmanship for 90 days from the date of purchase.


During this 90 Day Warranty Period, the game will either be repaired or it will be replaced with a reconditioned game of equivalent quality (at our option) without charge to the purchaser, when returned either to the dealer with proof of the date-of-purchase, or when returned prepaid and insured, with proof of the date-of-purchase, to:

Mattel Electronics Repair Center
5000 West 147th Street
Hawthorne, California 90250.

Units returned without proof of the date-of-purchase, or units returned after the 90-Day Warranty Period has expired, will be repaired or replaced (at our option) for a service charge of \$20.00. Payment must be made by check or money order. This non-warranty service will only be available for one year from the date of purchase. All non-warranty units must be returned postage prepaid and insured to **MATTEL ELECTRONICS REPAIR CENTER.**

This warranty gives you specific legal rights and you may also have other rights which vary from state to state. This warranty does not cover damage resulting from accident, unreasonable use, neglect, unauthorized service or other causes not arising out of defects in material or workmanship.

Proof of Purchase



Other electronic
games available from
Mattel Electronics.
Look for them!

Product No. 3202-0920-G 3